


# Operating Instructions

## Proline Promag D 400

### HART

Electromagnetic flowmeter



- Make sure the document is stored in a safe place such that it is always available when working on or with the device.
- To avoid danger to individuals or the facility, read the "Basic safety instructions" section carefully, as well as all other safety instructions in the document that are specific to working procedures.
- The manufacturer reserves the right to modify technical data without prior notice. Your Endress+Hauser Sales Center will supply you with current information and updates to these Instructions.

## Table of contents

<b>1</b>	<b>Document information</b> . . . . .	<b>6</b>			
1.1	Document function . . . . .	6			
1.2	Symbols used . . . . .	6			
1.2.1	Safety symbols . . . . .	6			
1.2.2	Electrical symbols . . . . .	6			
1.2.3	Tool symbols . . . . .	7			
1.2.4	Symbols for certain types of information . . . . .	7			
1.2.5	Symbols in graphics . . . . .	7			
1.3	Documentation . . . . .	8			
1.3.1	Standard documentation . . . . .	8			
1.3.2	Supplementary device-dependent documentation . . . . .	8			
1.4	Registered trademarks . . . . .	8			
<b>2</b>	<b>Basic safety instructions</b> . . . . .	<b>9</b>			
2.1	Requirements for the personnel . . . . .	9			
2.2	Designated use . . . . .	9			
2.3	Workplace safety . . . . .	10			
2.4	Operational safety . . . . .	10			
2.5	Product safety . . . . .	10			
2.6	IT security . . . . .	11			
<b>3</b>	<b>Product description</b> . . . . .	<b>12</b>			
3.1	Product design . . . . .	12			
<b>4</b>	<b>Incoming acceptance and product identification</b> . . . . .	<b>13</b>			
4.1	Incoming acceptance . . . . .	13			
4.2	Product identification . . . . .	13			
4.2.1	Transmitter nameplate . . . . .	14			
4.2.2	Sensor nameplate . . . . .	15			
4.2.3	Symbols on measuring device . . . . .	15			
<b>5</b>	<b>Storage and transport</b> . . . . .	<b>16</b>			
5.1	Storage conditions . . . . .	16			
5.2	Transporting the product . . . . .	16			
5.3	Packaging disposal . . . . .	17			
<b>6</b>	<b>Mounting</b> . . . . .	<b>17</b>			
6.1	Installation conditions . . . . .	17			
6.1.1	Mounting position . . . . .	17			
6.1.2	Requirements from environment and process . . . . .	19			
6.1.3	Special mounting instructions . . . . .	21			
6.2	Mounting the measuring device . . . . .	21			
6.2.1	Required tools . . . . .	21			
6.2.2	Preparing the measuring device . . . . .	21			
6.2.3	Mounting the sensor . . . . .	22			
6.2.4	Mounting the transmitter of the remote version . . . . .	25			
			6.2.5	Turning the transmitter housing . . . . .	26
			6.2.6	Turning the display module . . . . .	28
			6.3	Post-installation check . . . . .	29
<b>7</b>	<b>Electrical connection</b> . . . . .	<b>30</b>			
7.1	Connection conditions . . . . .	30			
7.1.1	Required tools . . . . .	30			
7.1.2	Requirements for connecting cable . . . . .	30			
7.1.3	Terminal assignment . . . . .	32			
7.1.4	Preparing the measuring device . . . . .	33			
7.1.5	Preparing the connecting cable for the remote version . . . . .	34			
7.2	Connecting the measuring device . . . . .	35			
7.2.1	Connecting the transmitter . . . . .	36			
7.2.2	Connecting the remote version . . . . .	36			
7.2.3	Ensuring potential equalization . . . . .	38			
7.3	Special connection instructions . . . . .	40			
7.3.1	Connection examples . . . . .	40			
7.4	Ensuring the degree of protection . . . . .	40			
7.4.1	Degree of protection IP66/67, Type 4X enclosure . . . . .	40			
7.5	Post-connection check . . . . .	40			
<b>8</b>	<b>Operation options</b> . . . . .	<b>42</b>			
8.1	Overview of operation options . . . . .	42			
8.2	Structure and function of the operating menu . . . . .	43			
8.2.1	Structure of the operating menu . . . . .	43			
8.2.2	Operating philosophy . . . . .	44			
8.3	Access to the operating menu via the local display . . . . .	45			
8.3.1	Operational display . . . . .	45			
8.3.2	Navigation view . . . . .	47			
8.3.3	Editing view . . . . .	49			
8.3.4	Operating elements . . . . .	50			
8.3.5	Opening the context menu . . . . .	51			
8.3.6	Navigating and selecting from list . . . . .	53			
8.3.7	Calling the parameter directly . . . . .	53			
8.3.8	Calling up help text . . . . .	54			
8.3.9	Changing the parameters . . . . .	55			
8.3.10	User roles and related access authorization . . . . .	56			
8.3.11	Disabling write protection via access code . . . . .	56			
8.3.12	Enabling and disabling the keypad lock . . . . .	56			
8.4	Access to the operating menu via the Web browser . . . . .	57			
8.4.1	Function range . . . . .	57			
8.4.2	Prerequisites . . . . .	57			
8.4.3	Establishing a connection . . . . .	58			
8.4.4	Logging on . . . . .	59			
8.4.5	User interface . . . . .	59			
8.4.6	Disabling the Web server . . . . .	60			

8.4.7	Logging out . . . . .	60	11.4.4	Output values . . . . .	99
8.5	Access to the operating menu via the operating tool . . . . .	61	11.5	Adapting the measuring device to the process conditions . . . . .	100
8.5.1	Connecting the operating tool . . . . .	61	11.6	Performing a totalizer reset . . . . .	100
8.5.2	Field Xpert SFX350, SFX370 . . . . .	62	11.7	Showing data logging . . . . .	101
8.5.3	FieldCare . . . . .	62			
8.5.4	AMS Device Manager . . . . .	63	<b>12</b>	<b>Diagnostics and troubleshooting . .</b>	<b>103</b>
8.5.5	SIMATIC PDM . . . . .	63	12.1	General troubleshooting . . . . .	103
8.5.6	Field Communicator 475 . . . . .	64	12.2	Diagnostic information via light emitting diodes . . . . .	104
<b>9</b>	<b>System integration . . . . .</b>	<b>65</b>	12.2.1	Transmitter . . . . .	104
9.1	Overview of device description files . . . . .	65	12.3	Diagnostic information on local display . . . . .	106
9.1.1	Current version data for the device . . . . .	65	12.3.1	Diagnostic message . . . . .	106
9.1.2	Operating tools . . . . .	65	12.3.2	Calling up remedial measures . . . . .	108
9.2	Measured variables via HART protocol . . . . .	65	12.4	Diagnostic information in the Web browser . . . . .	109
9.3	Other settings . . . . .	66	12.4.1	Diagnostic options . . . . .	109
9.3.1	Burst mode functionality in accordance with HART 7 Specification . . . . .	66	12.4.2	Calling up remedy information . . . . .	109
<b>10</b>	<b>Commissioning . . . . .</b>	<b>69</b>	12.5	Diagnostic information in FieldCare . . . . .	110
10.1	Function check . . . . .	69	12.5.1	Diagnostic options . . . . .	110
10.2	Switching on the measuring device . . . . .	69	12.5.2	Calling up remedy information . . . . .	111
10.3	Setting the operating language . . . . .	69	12.6	Adapting the diagnostic information . . . . .	111
10.4	Configuring the measuring device . . . . .	69	12.6.1	Adapting the diagnostic behavior . . . . .	111
10.4.1	Defining the tag name . . . . .	70	12.6.2	Adapting the status signal . . . . .	111
10.4.2	Configuring the status input . . . . .	71	12.7	Overview of diagnostic information . . . . .	112
10.4.3	Configuring the current output . . . . .	72	12.8	Pending diagnostic events . . . . .	115
10.4.4	Configuring the pulse/frequency/ switch output . . . . .	73	12.9	Diagnostic list . . . . .	115
10.4.5	Configuring the local display . . . . .	80	12.10	Event logbook . . . . .	116
10.4.6	Configuring the HART input . . . . .	82	12.10.1	Event history . . . . .	116
10.4.7	Configuring the output conditioning . . . . .	83	12.10.2	Filtering the event logbook . . . . .	117
10.4.8	Configuring the low flow cut off . . . . .	85	12.10.3	Overview of information events . . . . .	117
10.4.9	Configuring empty pipe detection . . . . .	87	12.11	Resetting the measuring device . . . . .	118
10.5	Advanced settings . . . . .	88	12.12	Device information . . . . .	118
10.5.1	Setting the system units . . . . .	89	12.13	Firmware history . . . . .	120
10.5.2	Carrying out a sensor adjustment . . . . .	90	<b>13</b>	<b>Maintenance . . . . .</b>	<b>121</b>
10.5.3	Configuring the totalizer . . . . .	90	13.1	Maintenance tasks . . . . .	121
10.5.4	Carrying out additional display configurations . . . . .	91	13.1.1	Exterior cleaning . . . . .	121
10.6	Simulation . . . . .	93	13.1.2	Interior cleaning . . . . .	121
10.7	Protecting settings from unauthorized access . . . . .	95	13.1.3	Replacing seals . . . . .	121
10.7.1	Write protection via access code . . . . .	95	13.2	Measuring and test equipment . . . . .	121
10.7.2	Write protection via write protection switch . . . . .	96	13.3	Endress+Hauser services . . . . .	121
<b>11</b>	<b>Operation . . . . .</b>	<b>98</b>	<b>14</b>	<b>Repair . . . . .</b>	<b>122</b>
11.1	Reading device locking status . . . . .	98	14.1	General notes . . . . .	122
11.2	Adjusting the operating language . . . . .	98	14.2	Spare parts . . . . .	122
11.3	Configuring the display . . . . .	98	14.3	Endress+Hauser services . . . . .	122
11.4	Reading measured values . . . . .	98	14.4	Return . . . . .	122
11.4.1	Process variables . . . . .	98	14.5	Disposal . . . . .	122
11.4.2	Totalizer . . . . .	99	14.5.1	Removing the measuring device . . . . .	122
11.4.3	Input values . . . . .	99	14.5.2	Disposing of the measuring device . . . . .	123
			<b>15</b>	<b>Accessories . . . . .</b>	<b>124</b>
			15.1	Device-specific accessories . . . . .	124
			15.1.1	For the transmitter . . . . .	124
			15.1.2	For the sensor . . . . .	124
			15.2	Communication-specific accessories . . . . .	124

---

15.3	Service-specific accessories .....	125
15.4	System components .....	125
<b>16</b>	<b>Technical data .....</b>	<b>126</b>
16.1	Application .....	126
16.2	Function and system design .....	126
16.3	Input .....	126
16.4	Output .....	128
16.5	Power supply .....	130
16.6	Performance characteristics .....	131
16.7	Installation .....	133
16.8	Environment .....	133
16.9	Process .....	133
16.10	Mechanical construction .....	134
16.11	Operability .....	139
16.12	Certificates and approvals .....	141
16.13	Application packages .....	142
16.14	Accessories .....	142
16.15	Supplementary documentation .....	143
<b>17</b>	<b>Appendix .....</b>	<b>144</b>
17.1	Overview of the operating menu .....	144
17.1.1	Main menu .....	144
17.1.2	"Operation" menu .....	144
17.1.3	"Setup" menu .....	145
17.1.4	"Diagnostics" menu .....	149
17.1.5	"Expert" menu .....	153
<b>Index</b> .....	<b>167</b>	





# 1 Document information

## 1.1 Document function







These Operating Instructions contain all the information that is required in various phases of the life cycle of the device: from product identification, incoming acceptance and storage, to mounting, connection, operation and commissioning through to troubleshooting, maintenance and disposal.

## 1.2 Symbols used




### 1.2.1 Safety symbols

Symbol	Meaning
 <b>DANGER</b>	<b>DANGER!</b> This symbol alerts you to a dangerous situation. Failure to avoid this situation will result in serious or fatal injury.
 <b>WARNING</b>	<b>WARNING!</b> This symbol alerts you to a dangerous situation. Failure to avoid this situation can result in serious or fatal injury.
 <b>CAUTION</b>	<b>CAUTION!</b> This symbol alerts you to a dangerous situation. Failure to avoid this situation can result in minor or medium injury.
 <b>NOTICE</b>	<b>NOTE!</b> This symbol contains information on procedures and other facts which do not result in personal injury.












### 1.2.2 Electrical symbols

Symbol	Meaning
	<b>Direct current</b> A terminal to which DC voltage is applied or through which direct current flows.
	<b>Alternating current</b> A terminal to which alternating voltage is applied or through which alternating current flows.
	<b>Direct current and alternating current</b> <ul style="list-style-type: none"> <li>▪ A terminal to which alternating voltage or DC voltage is applied.</li> <li>▪ A terminal through which alternating current or direct current flows.</li> </ul>
	<b>Ground connection</b> A grounded terminal which, as far as the operator is concerned, is grounded via a grounding system.
	<b>Protective ground connection</b> A terminal which must be connected to ground prior to establishing any other connections.
	<b>Equipotential connection</b> A connection that has to be connected to the plant grounding system: This may be a potential equalization line or a star grounding system depending on national or company codes of practice.








### 1.2.3 Tool symbols

Symbol	Meaning
	Torx screwdriver
	Phillips head screwdriver
	Open-ended wrench



### 1.2.4 Symbols for certain types of information

Symbol	Meaning
	<b>Permitted</b> Indicates procedures, processes or actions that are permitted.
	<b>Preferred</b> Indicates procedures, processes or actions that are preferred.
	<b>Forbidden</b> Indicates procedures, processes or actions that are forbidden.
	<b>Tip</b> Indicates additional information.
	<b>Reference to documentation</b> Refers to the corresponding device documentation.
	<b>Reference to page</b> Refers to the corresponding page number.
	<b>Reference to graphic</b> Refers to the corresponding graphic number and page number.
	<b>Series of steps</b>
	<b>Result of a sequence of actions</b>
	<b>Help in the event of a problem</b>
	<b>Visual inspection</b>

### 1.2.5 Symbols in graphics

Symbol	Meaning
	Item numbers
	Series of steps
	Views
	Sections
	Flow direction
	<b>Hazardous area</b> Indicates a hazardous area.
	<b>Safe area (non-hazardous area)</b> Indicates the non-hazardous area.

## 1.3 Documentation

-  For an overview of the scope of the associated Technical Documentation, refer to the following:
- The CD-ROM provided for the device (depending on the device version, the CD-ROM might not be part of the delivery!)
  - The *W@M Device Viewer* : Enter the serial number from the nameplate ([www.endress.com/deviceviewer](http://www.endress.com/deviceviewer))
  - The *Endress+Hauser Operations App*: Enter the serial number from the nameplate or scan the 2-D matrix code (QR code) on the nameplate.
-  For a detailed list of the individual documents along with the documentation code

### 1.3.1 Standard documentation

Document type	Purpose and content of the document
Technical Information	<b>Planning aid for your device</b> The document contains all the technical data on the device and provides an overview of the accessories and other products that can be ordered for the device.
Brief Operating Instructions	<b>Guide that takes you quickly to the 1st measured value</b> The Brief Operating Instructions contain all the essential information from incoming acceptance to initial commissioning.

### 1.3.2 Supplementary device-dependent documentation

Additional documents are supplied depending on the device version ordered: Always comply strictly with the instructions in the supplementary documentation. The supplementary documentation is an integral part of the device documentation.

## 1.4 Registered trademarks

### HART®

Registered trademark of the HART Communication Foundation, Austin, USA

### Microsoft®

Registered trademark of the Microsoft Corporation, Redmond, Washington, USA

### Applicator®, FieldCare®, Field Xpert™, HistoROM®, Heartbeat Technology™

Registered or registration-pending trademarks of the Endress+Hauser Group

## 2 Basic safety instructions

### 2.1 Requirements for the personnel

The personnel for installation, commissioning, diagnostics and maintenance must fulfill the following requirements:

- ▶ Trained, qualified specialists must have a relevant qualification for this specific function and task
- ▶ Are authorized by the plant owner/operator
- ▶ Are familiar with federal/national regulations
- ▶ Before beginning work, the specialist staff must have read and understood the instructions in the Operating Instructions and supplementary documentation as well as in the certificates (depending on the application)
- ▶ Following instructions and basic conditions

The operating personnel must fulfill the following requirements:

- ▶ Being instructed and authorized according to the requirements of the task by the facility's owner-operator
- ▶ Following the instructions in these Operating Instructions

### 2.2 Designated use


#### Application and media

The measuring device described in these Instructions is intended only for flow measurement of liquids with a minimum conductivity of 5  $\mu\text{S}/\text{cm}$ .

Depending on the version ordered, the measuring device can also measure potentially explosive, flammable, poisonous and oxidizing media.

Measuring devices for use in hazardous areas, in hygienic applications or in applications where there is an increased risk due to process pressure, are labeled accordingly on the nameplate.

To ensure that the measuring device remains in proper condition for the operation time:

- ▶ Only use the measuring device in full compliance with the data on the nameplate and the general conditions listed in the Operating Instructions and supplementary documentation.
- ▶ Based on the nameplate, check whether the ordered device is permitted for the intended use in the hazardous area (e.g. explosion protection, pressure vessel safety).
- ▶ Use the measuring device only for media against which the process-wetted materials are adequately resistant.
- ▶ If the measuring device is not operated at atmospheric temperature, compliance with the relevant basic conditions specified in the associated device documentation is absolutely essential: "Documentation" section ( $\rightarrow$   8).

#### Incorrect use

Non-designated use can compromise safety. The manufacturer is not liable for damage caused by improper or non-designated use.

#### **WARNING**

#### **Danger of breakage of the sensor due to corrosive or abrasive fluids!**

- ▶ Verify the compatibility of the process fluid with the sensor material.
- ▶ Ensure the resistance of all fluid-wetted materials in the process.
- ▶ Observe the specified pressure and temperature range.

Verification for borderline cases:

- ▶ For special fluids and fluids for cleaning, Endress+Hauser is glad to provide assistance in verifying the corrosion resistance of fluid-wetted materials, but does not accept any

warranty or liability as minute changes in the temperature, concentration or level of contamination in the process can alter the corrosion resistance properties.

#### **Residual risks**

The external surface temperature of the housing can increase by max. 10 K due to the power consumption of the electronic components. Hot process fluids passing through the measuring device will further increase the surface temperature of the housing. The surface of the sensor, in particular, can reach temperatures which are close to the fluid temperature.

Possible burn hazard due to fluid temperatures!

- ▶ For elevated fluid temperature, ensure protection against contact to prevent burns.

## **2.3 Workplace safety**

For work on and with the device:

- ▶ Wear the required personal protective equipment according to federal/national regulations.

For welding work on the piping:

- ▶ Do not ground the welding unit via the measuring device.

If working on and with the device with wet hands:

- ▶ It is recommended to wear gloves on account of the higher risk of electric shock.

## **2.4 Operational safety**

Risk of injury.

- ▶ Operate the device in proper technical condition and fail-safe condition only.
- ▶ The operator is responsible for interference-free operation of the device.

#### **Conversions to the device**

Unauthorized modifications to the device are not permitted and can lead to unforeseeable dangers.

- ▶ If, despite this, modifications are required, consult with Endress+Hauser.

#### **Repair**

To ensure continued operational safety and reliability,

- ▶ Carry out repairs on the device only if they are expressly permitted.
- ▶ Observe federal/national regulations pertaining to repair of an electrical device.
- ▶ Use original spare parts and accessories from Endress+Hauser only.

#### **Environmental requirements**

If a plastic transmitter housing is permanently exposed to certain steam and air mixtures, this can damage the housing.

- ▶ If you are unsure, please contact your Endress+Hauser Sales Center for clarification.
- ▶ If used in an approval-related area, observe the information on the nameplate.

## **2.5 Product safety**

This measuring device is designed in accordance with good engineering practice to meet state-of-the-art safety requirements, has been tested, and left the factory in a condition in which it is safe to operate.

It meets general safety standards and legal requirements. It also complies with the EC directives listed in the device-specific EC Declaration of Conformity. Endress+Hauser confirms this by affixing the CE mark to the device.


## **2.6 IT security**

We only provide a warranty if the device is installed and used as described in the Operating Instructions. The device is equipped with security mechanisms to protect it against any inadvertent changes to the device settings.


IT security measures in line with operators' security standards and designed to provide additional protection for the device and device data transfer must be implemented by the operators themselves.

## 3 Product description

### 3.1 Product design




A0021563

 1 Important components of the compact version


- 1 Display module
- 2 Smart sensor electronics module
- 3 HistoROM DAT (plug-in memory)
- 4 Main electronics module
- 5 Terminals (screw terminals, some available as plug-in terminals)
- 6 Transmitter housing, compact version
- 7 Cable glands
- 8 Sensor, compact version

## 4 Incoming acceptance and product identification


### 4.1 Incoming acceptance




Are the order codes on the delivery note (1) and the product sticker (2) identical?





Are the goods undamaged?



Do the nameplate data match the ordering information on the delivery note?



Is the CD-ROM with the Technical Documentation (depends on device version) and documents present?



-  If one of the conditions is not satisfied, contact your Endress+Hauser Sales Center.
- Depending on the device version, the CD-ROM might not be part of the delivery! In such cases, the technical documentation is available via the Internet or via the *Endress+Hauser Operations App*, see the "Product identification" section (→  14).

### 4.2 Product identification


The following options are available for identification of the measuring device:

- Nameplate specifications
- Order code with breakdown of the device features on the delivery note
- Enter serial numbers from nameplates in *W@M Device Viewer* ([www.endress.com/deviceviewer](http://www.endress.com/deviceviewer)): All information about the measuring device is displayed.
- Enter the serial number from the nameplates into the *Endress+Hauser Operations App* or scan the 2-D matrix code (QR code) on the nameplate with the *Endress+Hauser Operations App*: all the information for the measuring device is displayed.


For an overview of the scope of the associated Technical Documentation, refer to the following:

- The chapters "Additional standard documentation on the device" (→  8) and "Supplementary device-dependent documentation" (→  8)
- The *W@M Device Viewer*: Enter the serial number from the nameplate ([www.endress.com/deviceviewer](http://www.endress.com/deviceviewer))
- The *Endress+Hauser Operations App*: Enter the serial number from the nameplate or scan the 2-D matrix code (QR code) on the nameplate.

#### 4.2.1 Transmitter nameplate




A0017346

 2 Example of a transmitter nameplate

- 1 Manufacturing location
- 2 Name of the transmitter
- 3 Order code
- 4 Serial number
- 5 Extended order code
- 6 Permitted ambient temperature range ( $T_a$ )
- 7 Firmware version (FW) and device revision (Dev.Rev.) from the factory
- 8 Degree of protection
- 9 Permitted temperature range for cable
- 10 2-D matrix code
- 11 Manufacturing date: year-month
- 12 CE mark, C-Tick
- 13 Electrical connection data, e.g. available inputs and outputs, supply voltage

### 4.2.2 Sensor nameplate



A0017224

3 Example of sensor nameplate

- 1 Name of the sensor
- 2 Manufacturing location
- 3 Order code
- 4 Serial number (Ser. no.)
- 5 Extended order code (Ext. ord. cd.)
- 6 Nominal diameter of sensor
- 7 Nominal pressure
- 8 Medium temperature range
- 9 Material of lining and electrodes
- 10 Permitted ambient temperature range
- 11 Degree of protection
- 12 2-D matrix code

#### Order code

The measuring device is reordered using the order code.

##### Extended order code

- The device type (product root) and basic specifications (mandatory features) are always listed.
- Of the optional specifications (optional features), only the safety and approval-related specifications are listed (e.g. LA). If other optional specifications are also ordered, these are indicated collectively using the # placeholder symbol (e.g. #LA#).
- If the ordered optional specifications do not include any safety and approval-related specifications, they are indicated by the + placeholder symbol (e.g. XXXXXX-ABCDE+).

### 4.2.3 Symbols on measuring device

Symbol	Meaning
 <small>A0011194</small>	<b>WARNING!</b> This symbol alerts you to a dangerous situation. Failure to avoid this situation can result in serious or fatal injury.
 <small>A0011194</small>	<b>Reference to documentation</b> Refers to the corresponding device documentation.
 <small>A0011199</small>	<b>Protective ground connection</b> A terminal which must be connected to ground prior to establishing any other connections.

## 5 Storage and transport

### 5.1 Storage conditions

Observe the following notes for storage:

- Store in the original packaging to ensure protection from shock.
- Do not remove protective covers or protective caps installed on process connections. They prevent mechanical damage to the sealing surfaces and contamination in the measuring tube.
- Protect from direct sunlight to avoid unacceptably high surface temperatures.
- Select a storage location where moisture cannot collect in the measuring device as fungus and bacteria infestation can damage the lining.
- Store in a dry and dust-free place.
- Do not store outdoors.
- Storage temperature(→ 📄 133)


### 5.2 Transporting the product

#### **⚠ WARNING**

**Center of gravity of the measuring device is higher than the suspension points of the webbing slings.**

Risk of injury if the measuring device slips.

- ▶ Secure the measuring device from rotating or slipping.
- ▶ Observe the weight specified on the packaging (stick-on label).
- ▶ Observe the transport instructions on the stick-on label on the electronics compartment cover.



A0015606

- i** ▪ Transport the measuring device to the measuring point in the original packaging.
- Lifting gear
  - Webbing slings: Do not use chains, as they could damage the housing.
  - For wood crates, the floor structure enables these to be loaded lengthwise or broadside using a forklift.
- Use the webbing slings to lift the measuring device at the process connections; do not lift by the transmitter housing or by the connection housing of the remote version.
- Do not remove protective covers or protective caps installed on process connections. They prevent mechanical damage to the sealing surfaces and contamination in the measuring tube.

## 5.3 Packaging disposal

All packaging materials are environmentally friendly and 100% recyclable:


- Measuring device secondary packaging: polymer stretch film that conforms to EC Directive 2002/95/EC (RoHS).
- Packaging:
  - Wood crate, treated in accordance with ISPM 15 standard, which is confirmed by the affixed IPPC logo.
  - or
  - Carton in accordance with European Packaging Directive 94/62EC; recyclability is confirmed by the affixed RESY symbol.
- Seaworthy packaging (optional): Wood crate, treated in accordance with ISPM 15 standard, which is confirmed by the affixed IPPC logo.
- Carrying and mounting hardware:
  - Disposable plastic pallet
  - Plastic straps
  - Plastic adhesive strips
- Dunnage: Paper cushion

## 6 Mounting

### 6.1 Installation conditions

#### 6.1.1 Mounting position

##### Mounting location



A0023343



Preferably install the sensor in an ascending pipe, and ensure a sufficient distance to the next pipe elbow:  $h \geq 2 \times DN$


To prevent measuring errors arising from accumulation of gas bubbles in the measuring tube, avoid the following mounting locations in the pipe:

- Highest point of a pipeline.
- Directly upstream of a free pipe outlet in a down pipe.

##### Installation in down pipes

Install a siphon with a vent valve downstream of the sensor in down pipes whose length  $h \geq 5 \text{ m}$  (16.4 ft). This precaution is to avoid low pressure and the consequent risk of damage to the measuring tube. This measure also prevents the system losing prime.

 For information on the liner's resistance to partial vacuum ( $\rightarrow$   133)




4 Installation in a down pipe

- 1 Vent valve
- 2 Pipe siphon
- h Length of down pipe

*Installation in partially filled pipes*

A partially filled pipe with a gradient necessitates a drain-type configuration. The empty pipe detection (EPD) function offers additional protection by detecting empty or partially filled pipes.




**Orientation**

The direction of the arrow on the sensor nameplate helps you to install the sensor according to the flow direction (direction of medium flow through the piping).


An optimum orientation position helps avoid gas and air accumulations and deposits in the measuring tube.

*Vertical*



This is the optimum for self-emptying piping systems.

*Horizontal*




1 Measuring electrodes for signal detection

**i** The measuring electrode plane must be horizontal. This prevents brief insulation of the two measuring electrodes by entrained air bubbles.

**Inlet and outlet runs**

If possible, install the sensor upstream from fittings such as valves, T-pieces or elbows. Observe the following inlet and outlet runs to comply with accuracy specifications:



*Installation dimensions*

**i** For the dimensions and installation lengths of the device, see the "Technical Information" document, "Mechanical construction" section


**6.1.2 Requirements from environment and process**

**Ambient temperature range**


Transmitter	-40 to +60 °C (-40 to +140 °F)
Local display	-20 to +60 °C (-4 to +140 °F), the readability of the display may be impaired at temperatures outside the temperature range.
Sensor	-20 to +60 °C (-4 to +140 °F)
Liner	Do not exceed or fall below the permitted temperature range of the liner (→ 133).

If operating outdoors:

- Install the measuring device in a shady location.
- Avoid direct sunlight, particularly in warm climatic regions.
- Avoid direct exposure to weather conditions.
- Protect the display against impact.
- Protect the display from abrasion by sand in desert areas.

**i** A display protector can be ordered from Endress+Hauser: "Accessories" section  
 (→  124)




**System pressure**



A0015594

Never install the sensor on the pump suction side in order to avoid the risk of low pressure, and thus damage to the liner.

**i** Furthermore, install pulse dampers if reciprocating, diaphragm or peristaltic pumps are used.

- i**
  - For information on the liner's resistance to partial vacuum (→  133)
  - Information on the shock resistance of the measuring system (→  133)
  - Information on the vibration resistance of the measuring system (→  133)


**Vibrations**

In the event of very strong vibrations, the pipe and sensor must be supported and fixed.

It is also advisable to mount the sensor and transmitter separately.

**i** Information on the shock resistance of the measuring system (→  133)

Information on the vibration resistance of the measuring system (→  133)



A0016266


 5 Measures to avoid device vibrations ( $L > 10\text{ m (33 ft)}$ )

**Adapters**

Suitable adapters to DIN EN 545 (double-flange reducers) can be used to install the sensor in larger-diameter pipes. The resultant increase in the rate of flow improves measuring accuracy with very slow-moving fluids. The nomogram shown here can be used to calculate the pressure loss caused by reducers and expanders.

**i** The nomogram only applies to liquids with a viscosity similar to that of water.

1. Calculate the ratio of the diameters  $d/D$ .
2. From the nomogram read off the pressure loss as a function of flow velocity (downstream from the reduction) and the  $d/D$  ratio.



A0016359

### 6.1.3 Special mounting instructions

#### Display protection

- To ensure that the optional display protection can be easily opened, maintain the following minimum head clearance: 350 mm (13.8 in)

## 6.2 Mounting the measuring device

### 6.2.1 Required tools

#### For transmitter

- Torque wrench
- For wall mounting:
  - Open-ended wrench for hexagonal screw max. M5
- For pipe mounting:
  - Open-ended wrench AF 8
  - Phillips head screwdriver PH 2
- For turning the transmitter housing (compact version):
  - Phillips head screwdriver PH 2
  - Torx screwdriver TX 20
  - Open-ended wrench AF 7

#### For sensor

For flanges and other process connections:

- Screws, nuts, seals etc. are not included in the scope of supply and must be provided by the customer.
- Appropriate mounting tools

### 6.2.2 Preparing the measuring device

1. Remove all remaining transport packaging.
2. Remove any protective covers or protective caps present from the sensor.


3. Remove stick-on label on the electronics compartment cover.

### 6.2.3 Mounting the sensor

#### Mounting kit

The sensor is installed between the pipe flanges using a mounting kit. The device is centered using the recesses on the sensor. Centering sleeves are also provided depending on the flange standard or the diameter of the pitch circle.

**i** A mounting kit – consisting of mounting bolts, seals, nuts and washers – can be ordered separately (see "Accessories" section (→ 124)).



A0018060









**6** *Mounting the sensor*

- 1 Nut
- 2 Washer
- 3 Mounting bolts
- 4 Centering sleeve
- 5 Seal

#### Arranging the mounting bolts and centering sleeves

The device is centered using recesses on the sensor. The arrangement of the mounting bolts and the use of the centering sleeves supplied depend on the nominal diameter, the flange standard and the diameter of the pitch circle.

Nominal diameter		Process connection		
[mm]	[in]5	EN 1092-1 (DIN 2501)	ASME B16.5	JIS B2220
25...40	1...1 ½	<p>A0010896</p>	<p>A0010824</p>	<p>A0010896</p>
50	2	<p>A0010897</p>	<p>A0010825</p>	<p>A0010825</p>

Nominal diameter		Process connection		
[mm]	[in]5	EN 1092-1 (DIN 2501)	ASME B16.5	JIS B2220
65	2 ½	 A0012170	—	 A0012171
80	3	 A0010898	 A0010827	 A0010826
100	4	 A0012168	 A0012168	 A0012169
1 = Mounting bolts with centering sleeves 2 = EN (DIN) flange: 4-hole → with centering sleeves 3 = EN (DIN) flange: 8-hole → without centering sleeves				

**Mounting the seals**



**An electrically conductive layer could form on the inside of the measuring tube!**  
 Risk of measuring signal short circuit.

- ▶ Do not use electrically conductive sealing compounds such as graphite.

Comply with the following instructions when installing seals:

- Make sure that the seals do not protrude into the piping cross-section.
- For DIN flanges: only use seals according to DIN EN 1514-1.
- Use seals with a hardness rating of 70° Shore.

**Mounting the ground cable/ground disks**

Comply with the information on potential equalization and detailed mounting instructions for the use of ground cables/ground disks (→ 38).

**Screw tightening torques**

Please note the following:

- The screw tightening torques listed below apply only to lubricated threads and to pipes not subjected to tensile stress.
- Tighten the screws uniformly and in diagonally opposite sequence.
- Overtightening the screws will deform the sealing faces or damage the seals.

The tightening torques apply to situations where an EPDM soft material flat seal (e.g. 70° Shore) is used.

*Screw tightening torques, mounting bolts and centering sleeves for EN 1092-1 (DIN 2501), PN 16*

Nominal diameter [mm]	Mounting bolts [mm]	Length Centering sleeve [mm]	Max. screw tightening torque [Nm] for a process flange with ...	
			smooth seal face	Raised face
25	4 × M12 × 145	54	19	19
40	4 × M16 × 170	68	33	33
50	4 × M16 × 185	82	41	41
65 <sup>1)</sup>	4 × M16 × 200	92	44	44
65 <sup>2)</sup>	8 × M16 × 200	– <sup>3)</sup>	29	29
80	8 × M16 × 225	116	36	36
100	8 × M16 × 260	147	40	40

- 1) EN (DIN) flange: 4-hole → with centering sleeves
- 2) EN (DIN) flange: 8-hole → without centering sleeves
- 3) A centering sleeve is not required. The device is centered directly via the sensor housing.

*Screw tightening torques, mounting bolts and centering sleeves for ASME B16.5, Class 150*

Nominal diameter		Mounting bolts [in]	Length Centering sleeve [in]	Max. screw tightening torque [Nm] ([lbf · ft]) for a process flange with ...	
[mm]	[in]			smooth seal face	Raised face
25	1	4 × UNC ½" × 5.70	– <sup>1)</sup>	19 (14)	10 (7)
40	1 ½	4 × UNC ½" × 6.50	– <sup>1)</sup>	29 (21)	19 (14)
50	2	4 × UNC 5/8" × 7.50	– <sup>1)</sup>	41 (30)	37 (27)
80	3	4 × UNC 5/8" × 9.25	– <sup>1)</sup>	43 (31)	43 (31)
100	4	8 × UNC 5/8" × 10.4	5.79	38 (28)	38 (28)

- 1) A centering sleeve is not required. The device is centered directly via the sensor housing.

*Screw tightening torques, mounting bolts and centering sleeves for JIS B2220, 10K*

Nominal diameter [mm]	Mounting bolts [mm]	Length Centering sleeve [mm]	Max. screw tightening torque [Nm] for a process flange with ...	
			smooth seal face	Raised face
25	4 × M16 × 170	54	24	24
40	4 × M16 × 170	68	32	25
50	4 × M16 × 185	– <sup>1)</sup>	38	30
65	4 × M16 × 200	– <sup>1)</sup>	42	42
80	8 × M16 × 225	– <sup>1)</sup>	36	28
100	8 × M16 × 260	– <sup>1)</sup>	39	37

- 1) A centering sleeve is not required. The device is centered directly via the sensor housing.

### 6.2.4 Mounting the transmitter of the remote version

#### ⚠ CAUTION

#### Ambient temperature too high!

Danger of electronics overheating and housing deformation.

- ▶ Do not exceed the permitted maximum ambient temperature (→ 19).
- ▶ If operating outdoors: Avoid direct sunlight and exposure to weathering, particularly in warm climatic regions.

#### ⚠ CAUTION


#### Excessive force can damage the housing!

- ▶ Avoid excessive mechanical stress.

The transmitter of the remote version can be mounted in the following ways:

- Wall mounting
- Pipe mounting

#### Wall mounting



7 Engineering unit mm (in)

1. Drill the holes.
2. Insert wall plugs into the drilled holes.
3. Screw in the securing screws slightly at first.
4. Fit the transmitter housing over the securing screws and mount in place.
5. Tighten the securing screws.


#### Post mounting

#### ⚠ WARNING

#### Excessive tightening torque applied to the fixing screws on plastic housing!

Risk of damaging the plastic transmitter.

- ▶ Tighten the fixing screws as per the tightening torque: 2 Nm (1.5 lbf ft)




A0020705


8 Engineering unit mm (in)

### 6.2.5 Turning the transmitter housing


To provide easier access to the connection compartment or display module, the transmitter housing can be turned.




A0021602




A0021603



A0021830



A0021831



A0021832

1. Loosen the fixing screws of the housing cover (when reassembling, pay attention to the tightening torque (→ 28)).
2. Open the housing cover.
3. Unlock the display module.
4. Remove the display module.
5. Loosen the fixing screws of the smart sensor electronics module (when reassembling, pay attention to the tightening torque (→ 28)).
6. Remove the smart sensor electronics module (when reassembling, pay attention to the coding of the plug (→ 0)).
7. Loosen the fixing screws of the main electronics module (when reassembling, pay attention to the tightening torque (→ 28)).
8. Remove the main electronics module.

9. Remove the electronics module from the main electronics module.
10. Loosen the fixing screws of the transmitter housing (when reassembling, pay attention to the tightening torque (→ 28)).
11. Lift the transmitter housing.
12. Turn the housing to the desired position in increments of 90°.

**Reassembling the transmitter housing**

**⚠ WARNING**

**Excessive tightening torque applied to the fixing screws!**

Damage to the transmitter.

- ▶ When reassembling, tighten the fixing screws as per the tightening torque:


Step	Fixing screw	Tightening torques for housing made of:	
		Aluminum	Plastic
1	Housing cover	2.5 Nm (1.8 lbf ft)	1 Nm (0.7 lbf ft)
5	Smart sensor electronics module	0.6 Nm (0.4 lbf ft)	
7	Main electronics module	1.5 Nm (1.1 lbf ft)	
10	Transmitter housing	5.5 Nm (4.1 lbf ft)	

**NOTICE**

**Plug of the smart sensor electronics module connected incorrectly!**

No measuring signal is output.

- ▶ Plug in the plug of the smart sensor electronics module as per the coding.



A0021585

**NOTICE**

**Incorrect routing of the connecting cables between the sensor and transmitter in the transmitter housing!**


This can interfere with the measuring signal.

- ▶ Route the connecting cables directly at the level of the plugs.

- ▶ Reverse the procedure to reassemble the measuring device.

**6.2.6 Turning the display module**

The display module can be turned to optimize display readability and operability.



A0021617

1. Loosen the fixing screws of the housing cover (when reassembling, pay attention to the tightening torque (→ 29)).
2. Open the housing cover.
3. Unlock the display module.
4. Pull out the display module and turn it to the desired position in increments of 90°.

**Reassembling the transmitter housing**

**⚠ WARNING**

**Excessive tightening torque applied to the fixing screws!**

Damage to the transmitter.

- ▶ When reassembling, tighten the fixing screws as per the tightening torque:

Step	Fixing screw	Tightening torque for housing made of:	
		Aluminum	Plastic
1	Housing cover	2.5 Nm (1.8 lbf ft)	1 Nm (0.7 lbf ft)

- ▶ Reverse the procedure to reassemble the measuring device.

**6.3 Post-installation check**

Is the device undamaged (visual inspection)?	<input type="checkbox"/>
Does the measuring device conform to the measuring point specifications? For example: <ul style="list-style-type: none"> <li>▪ Process temperature</li> <li>▪ Process pressure (refer to the section on "Pressure-temperature ratings" in the "Technical Information" document)</li> <li>▪ Ambient temperature</li> <li>▪ Measuring range</li> </ul>	<input type="checkbox"/>
Has the correct orientation for the sensor been selected ? <ul style="list-style-type: none"> <li>▪ According to sensor type</li> <li>▪ According to medium temperature</li> <li>▪ According to medium properties (outgassing, with entrained solids)</li> </ul>	<input type="checkbox"/>
Does the arrow on the sensor nameplate match the direction of flow of the fluid through the piping ?	<input type="checkbox"/>
Are the measuring point identification and labeling correct (visual inspection)?	<input type="checkbox"/>
Is the device adequately protected from precipitation and direct sunlight?	<input type="checkbox"/>
Have the fixing screws been tightened with the correct tightening torque?	<input type="checkbox"/>

## 7 Electrical connection

**i** The measuring device does not have an internal circuit breaker. For this reason, assign the measuring device a switch or power-circuit breaker so that the power supply line can be easily disconnected from the mains.

### 7.1 Connection conditions

#### 7.1.1 Required tools

- Torque wrench
- For cable entries: Use corresponding tools
- For housing cover: Torx screwdriver or flat-blade screwdriver
- Wire stripper
- When using stranded cables: crimping tool for ferrule

#### 7.1.2 Requirements for connecting cable

The connecting cables provided by the customer must fulfill the following requirements.

##### Electrical safety

In accordance with applicable federal/national regulations.

##### Permitted temperature range

- $-40\text{ °C}$  ( $-40\text{ °F}$ ) to  $+80\text{ °C}$  ( $+176\text{ °F}$ )
- Minimum requirement: cable temperature range  $\geq$  ambient temperature  $+20\text{ K}$

##### Power supply cable

Standard installation cable is sufficient.

##### Signal cable

###### *Current output*

- For 0-20 mA and 4-20 mA: standard installation cable is sufficient.
- For 4-20 mA HART: Shielded cable recommended. Observe grounding concept of the plant.

###### *Pulse/frequency/switch output*

Standard installation cable is sufficient.

###### *Status input*

Standard installation cable is sufficient.

##### Connecting cable for remote version


###### *Electrode cable*

<b>Standard cable</b>	3 × 0.38 mm <sup>2</sup> (20 AWG) with common, braided copper shield ( $\phi \sim 7\text{ mm}$ (0.28")) and individually shielded cores
<b>Conductor resistance</b>	$\leq 50\ \Omega/\text{km}$ (0.015 $\Omega/\text{ft}$ )

<b>Capacitance: core/shield</b>	≤420 pF/m (128 pF/ft)
<b>Operating temperature</b>	-20 to +80 °C (-68 to +176 °F)

*Coil current cable*

<b>Standard cable</b>	2 ×0.75 mm <sup>2</sup> (18 AWG) with common, braided copper shield (ϕ ~ 7 mm (0.28")) and individually shielded cores
<b>Conductor resistance</b>	≤37 Ω/km (0.011 Ω/ft)
<b>Capacitance: core/core, shield grounded</b>	≤120 pF/m (37 pF/ft)
<b>Operating temperature</b>	-20 to +80 °C (-68 to +176 °F)
<b>Test voltage for cable insulation</b>	≤ AC 1433 V r.m.s. 50/60 Hz or ≥ DC 2026 V



A0003194

9 Cable cross-section

- a Electrode cable
- b Coil current cable
- 1 Core
- 2 Core insulation
- 3 Core shield
- 4 Core jacket
- 5 Core reinforcement
- 6 Cable shield
- 7 Outer jacket

*Operation in zones of severe electrical interference*

The measuring system meets the general safety requirements (→ 141) and EMC specifications (→ 133).

Grounding is by means of the ground terminal provided for the purpose inside the connection housing. The stripped and twisted lengths of cable shield to the ground terminal must be as short as possible.


**Cable diameter**

- Cable glands supplied:
  - For standard cable: M20 × 1.5 with cable ϕ6 to 12 mm (0.24 to 0.47 in)
  - For reinforced cable: M20 × 1.5 with cable ϕ9.5 to 16 mm (0.37 to 0.63 in)
- (Plug-in) spring terminals for wire cross-sections 0.5 to 2.5 mm<sup>2</sup> (20 to 14 AWG)

### 7.1.3 Terminal assignment

#### Transmitter

0-20 mA/4-20 mA HART connection version with additional outputs and inputs



A0020424

- 1 Supply voltage
- 2 Output 1 (26/27) and output 2 (24/25)
- 3 Output 3 (22/23) and input 1 (20/21)


#### Supply voltage

Order code for "Power supply"	Terminal numbers	
	1 (L+/L)	2 (L-/N)
Option L (wide range power unit)	AC100 to 240 V	
	AC/DC24 V	

Signal transmission 0-20 mA/4-20 mA HART with additional outputs and inputs

Order code for "Output" and "Input"	Terminal numbers							
	Output 1		Output 2		Output 3		Input	
	26 (+)	27 (-)	24 (+)	25 (-)	22 (+)	23 (-)	20 (+)	21 (-)
Option H	<ul style="list-style-type: none"> <li>▪ 4-20 mA HART (active)</li> <li>▪ 0-20 mA (active)</li> </ul>		Pulse/frequency output (passive)			Switch output (passive)		-
Option I	<ul style="list-style-type: none"> <li>▪ 4-20 mA HART (active)</li> <li>▪ 0-20 mA (active)</li> </ul>		Pulse/frequency/switch output (passive)		Pulse/frequency/switch output (passive)		Status input	

## Remote version



A0020539

10 Remote version terminal assignment

A Transmitter wall-mount housing

B Sensor connection housing

1 Electrode cable

2 Coil current cable

n.c. Not connected, insulated cable shields

Terminal No. and cable colors: 6/5 = brown; 7/8 = white; 4 = green

#### 7.1.4 Preparing the measuring device

1. Remove dummy plug if present.
2. If measuring device is delivered with cable glands:  
Observe cable specification (→ 30).

### 7.1.5 Preparing the connecting cable for the remote version

When terminating the connecting cable, pay attention to the following points:


- In the case of electrode cables, make sure that the ferrules do not touch the core shields on the sensor side. Minimum distance = 1 mm (exception: green "GND" cable)
- In the case of coil current cables, insulate one core of the three-core wire at the level of the core reinforcement. You only require two cores for the connection.
- Fit the fine-wire cores with ferrules.

#### Transmitter

Electrode cable	Coil current cable
<p>100 (3.94)* 80 (3.15) 50 (1.97) 17 (0.67) 8 (0.31)</p> <p>A</p> <p>1 2 1 2 1 2 GND</p> <p>B</p> <p>11 Engineering unit mm (in)</p> <p>A0021324</p>	<p>90 (3.54)* 70 (2.76) 50 (1.97) 8 (0.31) 10 (0.39)</p> <p>A</p> <p>1</p> <p>B</p> <p>12 Engineering unit mm (in)</p> <p>A0021325</p>
<p>A = Termination of the cables                      B = Termination of the fine-wire cores with ferrules                      1 = Red ferrules, <math>\phi</math>1.0 mm (0.04 in)                      2 = White ferrules, <math>\phi</math>0.5 mm (0.02 in)                      * = Stripping only for reinforced cables</p>	



### 7.2.1 Connecting the transmitter



13 Connecting the supply voltage and 0-20 mA/4-20 mA HART with additional outputs and inputs

1. Loosen the 4 fixing screws on the housing cover.
2. Open the housing cover.
3. Push the cable through the cable entry. To ensure tight sealing, do not remove the sealing ring from the cable entry.
4. Strip the cable and cable ends. In the case of stranded cables, also fit ferrules.
5. Connect the cable in accordance with the terminal assignment (→ 32). For supply voltage: open the shock protection cover. For HART communication: When connecting the cable shielding to the ground terminal, observe the grounding concept of the facility.
6. Firmly tighten the cable glands.
7. **WARNING!** Housing degree of protection may be voided due to insufficient sealing of the housing. Screw in the screw without using any lubricant. Reverse the removal procedure to reassemble the transmitter.

### 7.2.2 Connecting the remote version


#### **WARNING**

#### **Risk of damaging the electronic components!**

- ▶ Ground the remote version and in doing so connect the sensor and transmitter to the same potential equalization.
- ▶ Only connect the sensor to a transmitter with the same serial number.
- ▶ Ground the connection housing of the sensor via the external screw terminal.

The following procedure (in the action sequence given) is recommended for the remote version:


1. Mount the transmitter and sensor.
2. Connect the connecting cable.
3. Connect the transmitter.



A0017445

14 Transmitter: main electronics module with terminals

1. Loosen the 4 fixing screws on the housing cover.
2. Open the housing cover.
3. Push the cable through the cable entry . To ensure tight sealing, do not remove the sealing ring from the cable entry.
4. Strip the cable and cable ends. In the case of stranded cables, also fit ferrules (→ 34).
5. Connect the cable in accordance with the terminal assignment (→ 33).
6. Firmly tighten the cable glands.
7. **WARNING!** Housing degree of protection may be voided due to insufficient sealing of the housing. Screw in the screw without using any lubricant. Reverse the removal procedure to reassemble the transmitter.



A0017446

15 Sensor: connection module

1. Loosen the securing clamp of the housing cover.
2. Unscrew and lift off the housing cover.
3. Push the cable through the cable entry . To ensure tight sealing, do not remove the sealing ring from the cable entry.
4. Strip the cable and cable ends. In the case of stranded cables, also fit ferrules (→ 34).
5. Connect the cable in accordance with the terminal assignment (→ 33).

6. Firmly tighten the cable glands.
7. **WARNING!** Housing degree of protection may be voided due to insufficient sealing of the housing. Screw in the screw without using any lubricant. The threads on the cover are coated with a dry lubricant.  
Reverse the procedure to reassemble the sensor.

### 7.2.3 Ensuring potential equalization

#### **⚠ CAUTION**

**Electrode damage can result in the complete failure of the device!**


- ▶ Make sure that the fluid and sensor have the same electrical potential.
- ▶ Pay attention to internal grounding concepts in the company.
- ▶ Pay attention to the pipe material or grounding.

#### Connection examples for standard situations

*Metal, grounded pipe*

This connection method also applies:

- For plastic pipes
- For pipes with insulating liner



A0017516


#### Connection example in special situations

*Unlined and ungrounded metal pipe*

This connection method also applies in situations where:

- The customary potential equalization is not used
- Equalizing currents are present

<b>Ground cable</b>	Copper wire, at least $6 \text{ mm}^2$ ( $0.0093 \text{ in}^2$ )
---------------------	--



A0017517

1. Connect both pipe flanges to one another via a ground cable and ground them.
2. Mount the ground cable directly on the conductive flange coating of the pipe with the flange screws.

3. Connect the connection housing of the transmitter or sensor to ground potential by means of the ground terminal provided for the purpose.


**i** For remote device versions, the ground terminal in the example always refers to the sensor and **not** to the transmitter.

#### *Pipe with a cathodic protection unit*

This connection method is only used if the following two conditions are met:

- Metal pipe without liner or pipe with electrically conductive liner
- Cathodic protection is integrated in the personal protection equipment

Ground cable	Copper wire, at least 6 mm <sup>2</sup> (0.0093 in <sup>2</sup> )
--------------	---



A0017518

Prerequisite: The sensor is installed in the pipe in a way that provides electrical insulation.


1. Connect the two flanges of the pipe to one another via a ground cable.
2. Guide the shield of the signal lines through a capacitor.
3. Connect the measuring device to the power supply such that it is floating in relation to the protective ground (isolation transformer).

**i** For remote device versions, the ground terminal in the example always refers to the sensor and **not** to the transmitter.

## 7.3 Special connection instructions

### 7.3.1 Connection examples

#### Status input



16 Connection example for status input

- 1 Automation system with status output (e.g. PLC)
- 2 Power supply
- 3 Transmitter: observe input values


## 7.4 Ensuring the degree of protection

### 7.4.1 Degree of protection IP66/67, Type 4X enclosure

The measuring device fulfills all the requirements for the IP66/67 degree of protection, Type 4X enclosure.

To guarantee IP66/67 degree of protection, Type 4X enclosure, carry out the following steps after the electrical connection:




1. Check that the housing seals are clean and fitted correctly. Dry, clean or replace the seals if necessary.
2. Tighten all housing screws and screw covers.
3. Firmly tighten the cable glands.
4. To ensure that moisture does not enter the cable entry, route the cable so that it loops down before the cable entry ("water trap").



5. Insert dummy plugs into unused cable entries.


## 7.5 Post-connection check

Are cables or the device undamaged (visual inspection)?	<input type="checkbox"/>
Do the cables comply with the requirements (→ 30)?	<input type="checkbox"/>

Do the cables have adequate strain relief?	<input type="checkbox"/>
Are all the cable glands installed, firmly tightened and leak-tight? Cable run with "water trap" (→  40) ?	<input type="checkbox"/>
Only for remote version: is the sensor connected to the right transmitter? Check the serial number on the nameplate of the sensor and transmitter.	<input type="checkbox"/>
Does the supply voltage match the specifications on the transmitter nameplate (→  130)?	<input type="checkbox"/>
Is the terminal assignment correct ?	<input type="checkbox"/>
If supply voltage is present, do values appear on the display module?	<input type="checkbox"/>
Is the potential equalization established correctly (→  38)?	<input type="checkbox"/>
Are all housing covers installed and the screws tightened with the correct tightening torque?	<input type="checkbox"/>

## 8 Operation options

### 8.1 Overview of operation options






A0015607


- 1 Local operation via display module
- 2 Computer with Web browser (e.g. Internet Explorer) or with operating tool (e.g. FieldCare, AMS Device Manager, SIMATIC PDM)
- 3 Field Xpert SFX350 or SFX370
- 4 Field Communicator 475
- 5 Control system (e.g. PLC)

## 8.2 Structure and function of the operating menu

### 8.2.1 Structure of the operating menu

 For an overview of the operating menu with menus and parameters (→  144)



 17 Schematic structure of the operating menu

A0018237-EN

### 8.2.2 Operating philosophy


The individual parts of the operating menu are assigned to certain user roles. Each user role corresponds to typical tasks within the device lifecycle.

Menu		User role and tasks	Content/meaning
Language	task-oriented	<b>Role "Operator", "Maintenance"</b> Tasks during operation:	Defining the operating language
Operation		<ul style="list-style-type: none"> <li>▪ Configuring the operational display</li> <li>▪ Reading measured values</li> </ul>	<ul style="list-style-type: none"> <li>▪ Configuring the operational display (e.g. display format, display contrast)</li> <li>▪ Resetting and controlling totalizers</li> </ul>
Setup		<b>"Maintenance" role</b> Commissioning: <ul style="list-style-type: none"> <li>▪ Configuration of the measurement</li> <li>▪ Configuration of the inputs and outputs</li> </ul>	Wizards for fast commissioning: <ul style="list-style-type: none"> <li>▪ Setting the input</li> <li>▪ Configuring the outputs</li> <li>▪ Configuring the operational display</li> <li>▪ Defining the output conditioning</li> <li>▪ Configuring the low flow cut off</li> <li>▪ Configuring the empty pipe detection</li> </ul> <b>"Advanced setup" submenu:</b> <ul style="list-style-type: none"> <li>▪ For more customized configuration of the measurement (adaptation to special measuring conditions)</li> <li>▪ Configuration of totalizers</li> <li>▪ Configuration of electrode cleaning (optional)</li> <li>▪ Administration (define access code, reset measuring device)</li> </ul>
Diagnostics	<b>"Maintenance" role</b> Fault elimination: <ul style="list-style-type: none"> <li>▪ Diagnostics and elimination of process and device errors</li> <li>▪ Measured value simulation</li> </ul>	Contains all parameters for error detection and analyzing process and device errors: <ul style="list-style-type: none"> <li>▪ <b>"Diagnostic list" submenu</b> Contains up to 5 currently pending diagnostic messages.</li> <li>▪ <b>"Event logbook" submenu</b> Contains up to 20 or 100 (order option "Extended HistoROM") event messages that have occurred.</li> <li>▪ <b>"Device information" submenu</b> Contains information for identifying the device.</li> <li>▪ <b>"Measured values" submenu</b> Contains all current measured values.</li> <li>▪ <b>"Data logging" submenu (order option "Extended HistoROM")</b> Storage and visualization of up to 1000 measured values</li> <li>▪ <b>"Heartbeat Technology" submenu</b> The functionality of the device is checked on demand and the verification results are documented.</li> <li>▪ <b>"Simulation" submenu</b> Is used to simulate measured values or output values.</li> </ul>	
Expert	function-oriented	Tasks that require detailed knowledge of the function of the device: <ul style="list-style-type: none"> <li>▪ Commissioning measurements under difficult conditions</li> <li>▪ Optimal adaptation of the measurement to difficult conditions</li> <li>▪ Detailed configuration of the communication interface</li> <li>▪ Error diagnostics in difficult cases</li> </ul>	Contains all the parameters of the device and makes it possible to access these parameters directly using an access code. The structure of this menu is based on the function blocks of the device: <ul style="list-style-type: none"> <li>▪ <b>"System" submenu</b> Contains all higher-order device parameters that do not pertain either to measurement or the measured value communication.</li> <li>▪ <b>"Sensor" submenu</b> Configuration of the measurement.</li> <li>▪ <b>"Input" submenu (order option)</b> Configuring the status input.</li> <li>▪ <b>"Output" submenu</b> Configuring of the analog current outputs as well as the pulse/frequency and switch output.</li> <li>▪ <b>"Communication" submenu</b> Configuration of the digital communication interface and the Web server.</li> <li>▪ <b>"Application" submenu</b> Configuration of the functions that go beyond the actual measurement (e.g. totalizer).</li> <li>▪ <b>"Diagnostics" submenu</b> Error detection and analysis of process and device errors and for device simulation and Heartbeat Technology.</li> </ul>










### Display area


In the display area, each measured value is prefaced by certain symbol types for further description:



### Measured variables



Symbol	Meaning
	Volume flow
	Mass flow
	Totalizer  The measurement channel number indicates which of the three totalizers is displayed.
	Output  The measurement channel number indicates which of the outputs is displayed.
	Status input

### Measurement channel numbers


Symbol	Meaning
	Measurement channel 1 to 4
The measurement channel number is displayed only if more than one channel is present for the same measured variable type (e.g. Totalizer 1 to 3).	

### Diagnostic behavior

The diagnostic behavior pertains to a diagnostic event that is relevant to the displayed measured variable. For information on the symbols (→  107)

 The number and display format of the measured values can be configured via the **"Format display" parameter**(→  80). "Operation" menu → Display → Format display

### 8.3.2 Navigation view



#### Navigation path

The navigation path - displayed at the top left in the navigation view - consists of the following elements:

	<ul style="list-style-type: none"> <li>In the submenu: Display symbol for menu</li> <li>In the wizard: Display symbol for wizard</li> </ul>	Omission symbol for operating menu levels in between	Name of current <ul style="list-style-type: none"> <li>Submenu</li> <li>Wizard</li> <li>Parameter</li> </ul>
	↓	↓	↓
Examples		/ .. /	Display
		/ .. /	Display

For more information about the menu icons, refer to the "Display area" section (→ 48)

#### Status area





The following appears in the status area of the navigation view in the top right corner:

- Of the submenu
  - The direct access code for the parameter you are navigating to (e.g. 0022-1)
  - If a diagnostic event is present, the diagnostic behavior and status signal
- In the wizard
  - If a diagnostic event is present, the diagnostic behavior and status signal





- For information on the diagnostic behavior and status signal (→ 106)
- For information on the function and entry of the direct access code (→ 53)

## Display area


### Menus

Symbol	Meaning
	<b>Operation</b> Appears: <ul style="list-style-type: none"> <li>In the menu next to the "Operation" selection</li> <li>At the left in the navigation path in the "Operation" menu</li> </ul>
	<b>Setup</b> Appears: <ul style="list-style-type: none"> <li>In the menu next to the "Setup" selection</li> <li>At the left in the navigation path in the "Setup" menu</li> </ul>
	<b>Diagnostics</b> Appears: <ul style="list-style-type: none"> <li>In the menu next to the "Diagnostics" selection</li> <li>At the left in the navigation path in the "Diagnostics" menu</li> </ul>
	<b>Expert</b> Appears: <ul style="list-style-type: none"> <li>In the menu next to the "Expert" selection</li> <li>At the left in the navigation path in the "Expert" menu</li> </ul>




### Submenus, wizards, parameters

Symbol	Meaning
	Submenu
	Wizard
	Parameters within a wizard  No display symbol exists for parameters in submenus.


### Locking

Symbol	Meaning
	<b>Parameter locked</b> When displayed in front of a parameter name, indicates that the parameter is locked. <ul style="list-style-type: none"> <li>By a user-specific access code (→ ⓘ 95)</li> <li>By the hardware write protection switch (→ ⓘ 96)</li> </ul>

### Wizard operation

Symbol	Meaning
	Switches to the previous parameter.
	Confirms the parameter value and switches to the next parameter.
	Opens the editing view of the parameter.

### 8.3.3 Editing view



#### Input mask









The following input symbols are available in the input mask of the numeric and text editor:


##### Numeric editor





Symbol	Meaning
0 ... 9	Selection of numbers from 0 to 9.
.	Inserts decimal separator at the input position.
-	Inserts minus sign at the input position.
✓	Confirms selection.
←	Moves the input position one position to the left.
X	Exits the input without applying the changes.
C	Clears all entered characters.

##### Text editor



Symbol	Meaning
Aa1@ ... XYZ	Toggle <ul style="list-style-type: none"> <li>Between upper-case and lower-case letters</li> <li>For entering numbers</li> <li>For entering special characters</li> </ul>
ABC_ ... XYZ	Selection of letters from A to Z.

 	Selection of letters from a to z.
 	Selection of special characters.
	Confirms selection.
	Switches to the selection of the correction tools.
	Exits the input without applying the changes.
	Clears all entered characters.

Correction symbols under 

Symbol	Meaning
	Clears all entered characters.
	Moves the input position one position to the right.
	Moves the input position one position to the left.
	Deletes one character immediately to the left of the input position.

### 8.3.4 Operating elements

Key	Meaning
	<p><b>Minus key</b></p> <p><i>In a menu, submenu</i>                      Moves the selection bar upwards in a choose list.</p> <p><i>With a Wizard</i>                      Confirms the parameter value and goes to the previous parameter.</p> <p><i>With a text and numeric editor</i>                      In the input mask, moves the selection bar to the left (backwards).</p>
	<p><b>Plus key</b></p> <p><i>In a menu, submenu</i>                      Moves the selection bar downwards in a choose list.</p> <p><i>With a Wizard</i>                      Confirms the parameter value and goes to the next parameter.</p> <p><i>With a text and numeric editor</i>                      Moves the selection bar to the right (forwards) in an input screen.</p>

Key	Meaning
Ⓔ	<p><b>Enter key</b></p> <p><i>For operational display</i></p> <ul style="list-style-type: none"> <li>Pressing the key briefly opens the operating menu.</li> <li>Pressing the key for 2 s opens the context menu.</li> </ul> <p><i>In a menu, submenu</i></p> <ul style="list-style-type: none"> <li>Pressing the key briefly:                     <ul style="list-style-type: none"> <li>Opens the selected menu, submenu or parameter.</li> <li>Starts the wizard.</li> <li>If help text is open, closes the help text of the parameter.</li> </ul> </li> <li>Pressing the key for 2 s for parameter:                     <ul style="list-style-type: none"> <li>If present, opens the help text for the function of the parameter.</li> </ul> </li> </ul> <p><i>With a Wizard</i></p> <p>Opens the editing view of the parameter.</p> <p><i>With a text and numeric editor</i></p> <ul style="list-style-type: none"> <li>Pressing the key briefly:                     <ul style="list-style-type: none"> <li>Opens the selected group.</li> <li>Carries out the selected action.</li> </ul> </li> <li>Pressing the key for 2 s confirms the edited parameter value.</li> </ul>
⊖ + ⊕	<p><b>Escape key combination (press keys simultaneously)</b></p> <p><i>In a menu, submenu</i></p> <ul style="list-style-type: none"> <li>Pressing the key briefly:                     <ul style="list-style-type: none"> <li>Exits the current menu level and takes you to the next higher level.</li> <li>If help text is open, closes the help text of the parameter.</li> </ul> </li> <li>Pressing the key for 2 s returns you to the operational display ("home position").</li> </ul> <p><i>With a Wizard</i></p> <p>Exits the wizard and takes you to the next higher level.</p> <p><i>With a text and numeric editor</i></p> <p>Closes the text or numeric editor without applying changes.</p>
⊖ + Ⓔ	<p><b>Minus/Enter key combination (press the keys simultaneously)</b></p> <p>Reduces the contrast (brighter setting).</p>
⊕ + Ⓔ	<p><b>Plus/Enter key combination (press and hold down the keys simultaneously)</b></p> <p>Increases the contrast (darker setting).</p>
⊖ + ⊕ + Ⓔ	<p><b>Minus/Plus/Enter key combination (press the keys simultaneously)</b></p> <p><i>For operational display</i></p> <p>Enables or disables the keypad lock (only SD02 display module).</p>

### 8.3.5 Opening the context menu


Using the context menu, the user can call up the following menus quickly and directly from the operational display:

- Setup
- Simulation

#### Calling up and closing the context menu

The user is in the operational display.

- Press Ⓔ for 2 s.  
 ↳ The context menu opens.



- Press ⊖ + ⊕ simultaneously.

↳ The context menu is closed and the operational display appears.

**Calling up the menu via the context menu**


1. Open the context menu.
2. Press  $\oplus$  to navigate to the desired menu.
3. Press  $\boxtimes$  to confirm the selection.
  - ↳ The selected menu opens.

### 8.3.6 Navigating and selecting from list

Different operating elements are used to navigate through the operating menu. The navigation path is displayed on the left in the header. Icons are displayed in front of the individual menus. These icons are also shown in the header during navigation.

**i** For an explanation of the navigation view with symbols and operating elements (→ 47)

**Example: Setting the number of displayed measured values to "2 values"**



A0017448-EN


### 8.3.7 Calling the parameter directly

A parameter number is assigned to every parameter to be able to access a parameter directly via the onsite display. Entering this access code in the **Direct access** parameter calls up the desired parameter directly.

**Navigation path**

"Expert" menu → Direct access


The direct access code consists of a 4-digit number and the channel number, which identifies the channel of a process variable: e.g. 0914-1. In the navigation view, this appears on the right-hand side in the header of the selected parameter.



1 Direct access code

Note the following when entering the direct access code:

- The leading zeros in the direct access code do not have to be entered.  
Example: Input of "914" instead of "0914"
- If no channel number is entered, channel 1 is jumped to automatically.  
Example: Input of "0914" → Parameter **Totalizer 1**
- If a different channel is jumped to: Enter the direct access code with the corresponding channel number.  
Example: Input of "0914-2" → Parameter **Totalizer 2**

 For the direct access codes of the individual parameters


**8.3.8 Calling up help text**


For some parameters, help texts exist, which the user can call up from the navigation view. These briefly describe the function of the parameter and thus support fast and reliable commissioning.



**Calling up and closing the help text**

The user is in the navigation view and the selection bar is on a parameter.

1. Press  for 2 s.  
↳ The help text for the selected parameter opens.




 18 Example: Help text for parameter "Enter access code"

2. Press  +  simultaneously.  
↳ The help text is closed.

### 8.3.9 Changing the parameters


**i** For a description of the editing display - consisting of text editor and numeric editor - with symbols (→ 49), for a description of the operating elements (→ 50)

**Example:** Changing the tag name in the "Tag description" parameter from 001-FT-101 to 001-FT-102



A0014020-EN

A message is displayed if the value entered is outside the permitted value range.



A0014049-EN

### 8.3.10 User roles and related access authorization

The two user roles "Operator" and "Maintenance" have different write access to the parameters if the customer defines a user-specific access code. This protects the device configuration via the local display from unauthorized access (→ 95).

#### Access authorization to parameters

User role	Read access		Write access	
	Without access code (from the factory)	With access code	Without access code (from the factory)	With access code
Operator	✓	✓	✓	-- 1)
Maintenance	✓	✓	✓	✓

- 1) Despite the defined access code, certain parameters can always be modified and thus are excepted from the write protection, as they do not affect the measurement. Refer to the "Write protection via access code" section

If an incorrect access code is entered, the user obtains the access rights of the "Operator" role.

**i** The user role with which the user is currently logged on is indicated by the **Access status display** parameter. Navigation path: Operation → Access status display

### 8.3.11 Disabling write protection via access code

If the -symbol appears on the local display in front of a parameter, the parameter is write-protected by a user-specific access code and its value cannot be changed at the moment using the local display (→ 95).

The locking of the write access via local operation can be disabled by entering the customer-defined access code via the respective access option.

1. After you press , the input prompt for the access code appears.
2. Enter the access code.
  - ↳ The -symbol in front of the parameters disappears; all previously write-protected parameters are now re-enabled.

### 8.3.12 Enabling and disabling the keypad lock

The keypad lock makes it possible to block access to the entire operating menu via local operation. As a result, it is no longer possible to navigate through the operating menu or change the values of individual parameters. Users can only read the measured values on the operational display.


#### Local operation with touch control

The keypad lock is switched on and off via the context menu.

*Switching on the keypad lock*


The keypad lock is switched on automatically:

- Each time the device is restarted.
- If the device has not been operated for longer than one minute in the measured value display.

1. The device is in the measured value display.  
Press the  key for longer than 2 seconds.  
↳ A context menu appears.
2. In the context menu, select the **Keylock on** option.  
↳ The keypad lock is switched on.

 If the user attempts to access the operating menu while the keypad lock is active, the message **Keylock on** appears.

*Switching off the keypad lock*

1. The keypad lock is switched on.  
Press the  key for longer than 2 seconds.  
↳ A context menu appears.
2. In the context menu, select the **Keylock off** option.  
↳ The keypad lock is switched off.



## 8.4 Access to the operating menu via the Web browser

### 8.4.1 Function range

Thanks to the integrated Web server the device can be operated and configured via a Web browser. The operating menu structure is the same as in the local display. In addition to the measured values, status information on the device is also displayed and allows the user to monitor the status of the device. Furthermore the device data can be managed and the network parameters can be configured.

### 8.4.2 Prerequisites

*Hardware*

Connecting cable	Standard Ethernet cable with RJ45 connector
Computer	RJ45 interface
Measuring device:	Web server must be enabled; factory setting: ON  For information on enabling the Web server (→  60)

*Software of the computer*

Web browsers supported	<ul style="list-style-type: none"> <li>■ Microsoft Internet Explorer (min. 8.x)</li> <li>■ Mozilla Firefox</li> <li>■ Google chrome</li> </ul>
Recommended operating systems	<ul style="list-style-type: none"> <li>■ Windows XP</li> <li>■ Windows 7</li> </ul>


User rights for TCP/IP settings	User rights required for TCP/IP settings (e.g. for changes to IP address, subnet mask)
Computer configuration	<ul style="list-style-type: none"> <li>▪ JavaScript is enabled</li> <li>▪ If JavaScript cannot be enabled, enter http://192.168.1.212/basic.html in the address line of the Web browser. A fully functional but simplified version of the operating menu structure starts in the Web browser.</li> </ul>

**i** When installing a new firmware version:  
To enable correct data display, clear the temporary memory (cache) of the Web browser under **Internet options**.

### 8.4.3 Establishing a connection

#### Configuring the Internet protocol of the computer


IP address	192.168.1.XXX; for XXX all numerical values except: 0, 212 and 255 → e.g. 192.168.1.213
Subnet mask	255.255.255.0
Default gateway	192.168.1.212 or leave cells empty

1. Switch on the measuring device and connect to the computer via the cable (→  61).
2. If a 2nd network card is not used: all the applications on the notebook should be closed, or all the applications that require the Internet or network, such as e-mail, SAP applications, Internet or Windows Explorer, i.e. close all open Internet browsers.
3. Configure the properties of the Internet protocol (TCP/IP) as defined in the table above.


#### Starting the Web browser


1. Start the Web browser on the computer.
2. Enter the IP address of the Web server in the address line of the Web browser: 192.168.1.212

The login page appears.



A0017362

- 1 Device tag (→  70)
- 2 Picture of device

**i** If a login page does not appear, or if the page is incomplete (→  104)

### 8.4.4 Logging on

1. Select the preferred operating language for the Web browser.
2. Enter the access code.
3. Press **OK** to confirm your entry.

<b>Access code</b>	0000 (factory setting); can be changed by customer (→ ⓘ 95)
--------------------	---

**i** If no action is performed for 10 minutes, the Web browser automatically returns to the login page.

### 8.4.5 User interface

The screenshot shows the web interface with the following elements:

- 1**: Picture of device
- 2**: Function row with 6 functions (Measured values, Menu, Health status, Data management, Network, Logout)
- 3**: Device tag (Device tag, Actual diagnos. Device OK)
- 4**: Header (Volume flow 0.0000 l/h, Mass flow 0.0000 kg/h, Endress+Hauser logo)
- 5**: Working area (Health status, Diagnostics 1-5 OK)
- 6**: Navigation area (Health status icon)

A0017757-EN

#### Header

The following information appears in the header:

- Device tag (→ ⓘ 70)
- Device status with status signal (→ ⓘ 109)
- Current measured values (→ ⓘ 98)

#### Function row

Functions	Meaning
Measured values	The measured values of the device are displayed
Menu	Access to the operating menu structure of the device, same as for the local display and operating tool
Device status	Displays the diagnostic messages currently pending, listed in order of priority
Data management	Data exchange between PC and measuring device: <ul style="list-style-type: none"> <li>- Upload the configuration from the device (XML format, create configuration back-up)</li> <li>- Save the configuration to the device (XML format, restore configuration)</li> <li>- Export the event list (.csv file)</li> <li>- Export parameter settings (.csv file, create documentation of the measuring point configuration)</li> <li>- Export the Heartbeat verification log (PDF file, only available with the "Heartbeat Verification" application package)</li> </ul>

Functions	Meaning
Network configuration	Configuration and checking of all the parameters required for establishing the connection to the device: <ul style="list-style-type: none"> <li>▪ Network settings (e.g. IP address, MAC address)</li> <li>▪ Device information (e.g. serial number, firmware version)</li> </ul>
Logout	End the operation and call up the login page

**Navigation area**

If a function is selected in the function bar, the submenus of the function open in the navigation area. The user can now navigate through the menu structure.

**Working area**

Depending on the selected function and the related submenus, various actions can be performed in this area:

- Configuring parameters
- Reading measured values
- Calling up help text
- Starting an upload/download

**8.4.6 Disabling the Web server**

The Web server for the measuring device can enabled and disabled as required via the **Web server functionality** parameter.

**Navigation**

"Expert" menu → Communication → Web server

**Parameter overview with brief description**


Parameter	Description	Selection	Factory setting
Web server functionality	Switch the Web server on and off.	<ul style="list-style-type: none"> <li>▪ Off</li> <li>▪ On</li> </ul>	On


**Enabling the Web server**

If the Web server is disabled it can only be re-enabled with the **Web server functionality** parameter via the following operating options:

- Via local display
- Via "FieldCare" operating tool

**8.4.7 Logging out**

 Before logging out, perform a data backup via the **Data management** function (upload configuration from device) if necessary.


1. Select the **Logout** entry in the function row.
  - ↳ The home page with the Login box appears.
2. Close the Web browser.
3. Reset the modified properties of the Internet protocol (TCP/IP) if they are no longer needed (→  58).

## 8.5 Access to the operating menu via the operating tool

The structure of the operating menu in the operating tools is the same as for operation via the local display.

### 8.5.1 Connecting the operating tool

#### Via HART protocol




A0017124

19 Options for remote operation via HART protocol

- 1 Control system (e.g. PLC)
- 2 Field Communicator 475
- 3 Computer with operating tool (e.g. FieldCare, AMS Device Manager, SIMATIC PDM)
- 4 Commubox FXA195 (USB)
- 5 Field Xpert SFX350 or SFX370
- 6 VIATOR Bluetooth modem with connecting cable
- 7 Transmitter

#### Via service interface (CDI-RJ45)



A0020481

- 1 Computer with Web browser (e.g. Internet Explorer) for accessing the integrated device Web server or with "FieldCare" operating tool with COM DTM "CDI Communication TCP/IP"
- 2 Standard Ethernet connecting cable with RJ45 plug
- 3 Service interface (CDI -RJ45) of the measuring device with access to the integrated Web server


## 8.5.2 Field Xpert SFX350, SFX370

### Function scope

Field Xpert SFX350 and Field Xpert SFX370 are mobile computers for commissioning and maintenance. They enable efficient device configuration and diagnostics for HART and FOUNDATION fieldbus devices in the **non-Ex area** (SFX350, SFX370) and the **Ex area** (SFX370).

 For details, see Operating Instructions BA01202S

### Source for device description files



See data (→  65)

## 8.5.3 FieldCare

### Function scope

FDT-based plant asset management tool from Endress+Hauser. It can configure all smart field devices in a system and helps you manage them. By using the status information, it is also a simple but effective way of checking their status and condition.

Access takes place via:


- HART protocol (→  61)
- Service interface CDI-RJ45 (→  61)

Typical functions:

- Configuring parameters of transmitters
- Loading and saving device data (upload/download)
- Documentation of the measuring point
- Visualization of the measured value memory (line recorder) and event logbook

 For details, see Operating Instructions BA00027S and BA00059S

### Source for device description files

See data (→  65)


### Establishing a connection

Via service interface (CDI-RJ45)

1. Start FieldCare and launch the project.
2. In the network: Add a device.
  - ↳ The **Add device** window opens.
3. Select the **CDI Communication TCP/IP** option from the list and press **OK** to confirm.
4. Right-click **CDI Communication TCP/IP** and select the **Add device** option in the context menu that opens.
5. Select the desired device from the list and press **OK** to confirm.
  - ↳ The **CDI Communication TCP/IP (Configuration)** window opens.
6. Enter the device address in the **IP address** field: 192.168.1.212 and press **Enter** to confirm.
7. Establish the online connection to the device.

 For details, see Operating Instructions BA00027S and BA00059S

## User interface



A0021053-EN

- 1 Header
- 2 Picture of device
- 3 Device tag (→ 70)
- 4 Status area with status signal (→ 109)
- 6 Display area for current measured values (→ 98)
- 5 Event list with additional functions such as save/load, events list and document creation
- 7 Navigation area with operating menu structure
- 8 Operating range

### 8.5.4 AMS Device Manager

#### Function scope

Program from Emerson Process Management for operating and configuring measuring devices via HART protocol.

#### Source for device description files

See data (→ 65)

### 8.5.5 SIMATIC PDM

#### Function scope

SIMATIC PDM is a standardized, manufacturer-independent program from Siemens for the operation, configuration, maintenance and diagnosis of intelligent field devices via HART protocol.

#### Source for device description files


See data (→ 65)

## 8.5.6 Field Communicator 475

### Function scope

Industrial handheld terminal from Emerson Process Management for remote configuration and measured value display via HART protocol.

### Source for device description files

See data (→  65)

## 9 System integration

### 9.1 Overview of device description files

#### 9.1.1 Current version data for the device

Firmware version	01.05.zz	<ul style="list-style-type: none"> <li>▪ On the title page of the Operating instructions</li> <li>▪ On transmitter nameplate(→ 13)</li> <li>▪ Parameter <b>firmware version</b> Diagnostics → Device info → Firmware version</li> </ul>
Release date of firmware version	05.2014	---
Manufacturer ID	0x11	<b>Manufacturer ID</b> parameter Diagnostics → Device info → Manufacturer ID
Device type ID	0x67	<b>Device type</b> parameter Diagnostics → Device info → Device type
HART protocol revision	7	---
Device revision	6	<ul style="list-style-type: none"> <li>▪ On transmitter nameplate(→ 13)</li> <li>▪ <b>Device revision</b> parameter Diagnostics → Device info → Device revision</li> </ul>

#### 9.1.2 Operating tools

The suitable device description file for the individual operating tools is listed in the table below, along with information on where the file can be acquired.

Operating tool via HART protocol	Sources for obtaining device descriptions
<ul style="list-style-type: none"> <li>▪ Field Xpert SFX350</li> <li>▪ Field Xpert SFX370</li> </ul>	Use update function of handheld terminal
FieldCare	<ul style="list-style-type: none"> <li>▪ <a href="http://www.endress.com">www.endress.com</a> → Download Area</li> <li>▪ CD-ROM (contact Endress+Hauser)</li> <li>▪ DVD (contact Endress+Hauser)</li> </ul>
AMS Device Manager (Emerson Process Management)	<a href="http://www.endress.com">www.endress.com</a> → Download Area
SIMATIC PDM (Siemens)	<a href="http://www.endress.com">www.endress.com</a> → Download Area
Field Communicator 475 (Emerson Process Management)	Use update function of handheld terminal

## 9.2 Measured variables via HART protocol

The following measured variables (HART device variables) are assigned to the dynamic variables at the factory:

Dynamic variables	Measured variables (HART device variables)
Primary dynamic variable (PV)	Volume flow
Secondary dynamic variable (SV)	Totalizer 1
Tertiary dynamic variable (TV)	Totalizer 2
Quaternary dynamic variable (QV)	Totalizer 3

The assignment of the measured variables to the dynamic variables can be modified and assigned as desired via local operation and the operating tool using the following parameters:

- Expert → Communication → HART output → Output → Assign PV
- Expert → Communication → HART output → Output → Assign SV
- Expert → Communication → HART output → Output → Assign TV
- Expert → Communication → HART output → Output → Assign QV

The following measured variables can be assigned to the dynamic variables:

#### Measured variables for PV (primary dynamic variable)

- Off
- Volume flow
- Mass flow
- Flow velocity
- Electronic temperature

#### Measured variables for SV, TV, QV (secondary, tertiary and quaternary dynamic variable)

- Volume flow
- Mass flow
- Electronic temperature
- Totalizer 1
- Totalizer 2
- Totalizer 3

#### Device variables

The device variables are permanently assigned. A maximum of 8 device variables can be transmitted:

- 0 = volume flow
- 1 = Mass flow
- 2 = conductivity
- 3 = flow velocity
- 4 = electronic temperature
- 5 = totalizer 1
- 6 = totalizer 2
- 7 = totalizer 3


## 9.3 Other settings

### 9.3.1 Burst mode functionality in accordance with HART 7 Specification

#### Navigation


"Expert" menu → Communication → HART output → Burst configuration → Burst configuration 1 to 3

#### Structure of the submenu



	Burst variable 7
	Burst trigger mode
	Burst trigger level
	Burst min period
	Burst max period

**Parameter overview with brief description**

Parameter	Description	Selection / User entry	Factory setting
Burst mode #	Activation of the HART burst mode for burst message X.  An external pressure or temperature sensor must also be in the Burst mode.	<ul style="list-style-type: none"> <li>▪ Off</li> <li>▪ On</li> </ul>	Off
Burst command #	Select the HART command that is sent to the HART master. <ul style="list-style-type: none"> <li>▪ <b>Command 1</b> option: Read out the primary variable.</li> <li>▪ <b>Command 2</b> option: Read out the current and the main measured value as a percentage.</li> <li>▪ <b>Command 3</b> option: Read out the dynamic HART variables and the current.</li> <li>▪ <b>Command 9</b> option: Read out the dynamic HART variables including the related status.</li> <li>▪ <b>Command 33</b> option: Read out the dynamic HART variables including the related unit.</li> <li>▪ <b>Command 48</b> option: Read out the complete device diagnostics.</li> </ul>	<ul style="list-style-type: none"> <li>▪ Command 1</li> <li>▪ Command 2</li> <li>▪ Command 3</li> <li>▪ Command 9</li> <li>▪ Command 33</li> <li>▪ Command 48</li> </ul>	Command 2
Burst variable 0	Assignment of the individual HART variables (PV, SV, TV, QV) and assignment of the process variables available in the device to the HART command.	<ul style="list-style-type: none"> <li>▪ Volume flow</li> <li>▪ Mass flow</li> <li>▪ Flow velocity</li> <li>▪ Electronic temperature</li> <li>▪ Totalizer 1</li> <li>▪ Totalizer 2</li> <li>▪ Totalizer 3</li> <li>▪ Density</li> <li>▪ HART input</li> <li>▪ Percent Of Range</li> <li>▪ Measured current</li> <li>▪ Primary variable (PV)</li> <li>▪ Secondary variable (SV)</li> <li>▪ Tertiary variable (TV)</li> <li>▪ Quaternary variable (QV)</li> <li>▪ Not used</li> </ul>	Volume flow
Burst variable 1	See burst variable 0.	See burst variable 0.	Not used
Burst variable 2	See burst variable 0.	See burst variable 0.	Not used
Burst variable 3	See burst variable 0.	See burst variable 0.	Not used
Burst variable 4	See burst variable 0.	See burst variable 0.	Not used
Burst variable 5	See burst variable 0.	See burst variable 0.	Not used
Burst variable 6	See burst variable 0.	See burst variable 0.	Not used
Burst variable 7	See burst variable 0.	See burst variable 0.	Not used

Parameter	Description	Selection / User entry	Factory setting
Burst trigger mode	<p>Use this function to select the event that triggers burst message X.</p> <ul style="list-style-type: none"> <li>▪ <b>Continuous</b> option: The message is triggered in a time-controlled manner, at least observing the time interval defined in the <b>Burst min period</b> parameter.</li> <li>▪ <b>Window</b> option: The message is triggered if the specified measured value has changed by the value in the <b>Burst trigger level</b> parameter.</li> <li>▪ <b>Rising</b> option: The message is triggered if the specified measured value exceeds the value in the <b>Burst trigger level</b> parameter.</li> <li>▪ <b>Falling</b> option: The message is triggered if the specified measured value drops below the value in the <b>Burst trigger level</b> parameter.</li> <li>▪ <b>On change</b> option: The message is triggered if the measured value changes.</li> </ul>	<ul style="list-style-type: none"> <li>▪ Continuous</li> <li>▪ Window</li> <li>▪ Rising</li> <li>▪ Falling</li> <li>▪ On change</li> </ul>	Continuous
Burst trigger level	<p>For entering the burst trigger value.</p> <p>Together with the option selected in the <b>Burst trigger mode</b> parameter the burst trigger value determines the time of burst message X.</p>	Positive floating-point number	2.0E-38
Min. update period	Use this function to enter the minimum time span between two burst commands of burst message X.	Positive integer	1 000 ms
Max. update period	Use this function to enter the maximum time span between two burst commands of burst message X.	Positive integer	2 000 ms

## 10 Commissioning

### 10.1 Function check

Before commissioning the device, make sure that the post-installation and post-connection checks have been performed.

- "Post-installation check" checklist (→ 📄 29)
- "Post-connection check" checklist (→ 📄 40)

### 10.2 Switching on the measuring device


After a successful function check, switch on the measuring device.

After a successful startup, the local display switches automatically from the startup display to the operational display.

**i** If nothing appears on the local display or a diagnostic message is displayed, refer to the section on "Diagnostics and troubleshooting" (→ 📄 103).

### 10.3 Setting the operating language

Factory setting: English or ordered local language




**20** Using the example of the local display

A0013996

### 10.4 Configuring the measuring device

The **Setup** menu with its guided wizards contains all the parameters needed for standard operation.

Navigation to the **Setup** menu



A0017444-EN

21 Illustrated using the example of the local display

Overview of the wizards in the "Setup" menu


Setup	→	Device tag	(→ 📖 70)
		Status input	(→ 📖 71)
		Current output 1	(→ 📖 72)
		Pulse/frequency/switch output 1 to 2	(→ 📖 73)
		Display	(→ 📖 80)
		Output conditioning	(→ 📖 83)
		Low flow cut off	(→ 📖 85)
		Empty pipe detection	(→ 📖 87)
		HART input	(→ 📖 82)
		Advanced setup	(→ 📖 88)

### 10.4.1 Defining the tag name

To enable fast identification of the measuring point within the system, you can enter a unique designation using the **Device tag** parameter and thus change the factory setting.

**i** The number of characters displayed depends on the characters used.

**i** For information on the tag name in the "FieldCare" operating tool (→ 📖 63)



A0013375

22 Header of the operational display with tag name

1 Device tag

**Navigation**

"Setup" menu → Device tag

**Parameter overview with brief description**

Parameter	Description	User entry	Factory setting
Device tag	Enter tag for measuring point.	Max. 32 characters, such as letters, numbers or special characters (e.g. @, %, /).	Promag

**10.4.2 Configuring the status input**


The **Status input** submenu guides you systematically through all the parameters that have to be set for configuring the input.

 The submenu only appears if the device was ordered with a status input .

**Navigation**

"Setup" menu → Status input

**Structure of the submenu**



**Parameter overview with brief description**

Parameter	Description	Selection / User entry	Factory setting
Assign status input	Select the function for the status input.	<ul style="list-style-type: none"> <li>■ Off</li> <li>■ Reset totalizer 1</li> <li>■ Reset totalizer 2</li> <li>■ Reset totalizer 3</li> <li>■ Reset all totalizers</li> <li>■ Flow override</li> </ul>	Off
Active level	Specify the input signal level at which the assigned function is triggered.	<ul style="list-style-type: none"> <li>■ High</li> <li>■ Low</li> </ul>	High
Response time status input	Specify the minimum amount of time the input signal level must be present before the selected function is triggered.	5 to 200 ms	50 ms


### 10.4.3 Configuring the current output

The "Current output 1 to 2" wizard guides you systematically through all the parameters that have to be set for configuring the particular current output.

#### Navigation

"Setup" menu → Current output 1 to 2

#### Structure of the wizard



A0023209-EN

23 Graphic of "Current output" wizard in the "Setup" menu

### Parameter overview with brief description

Parameter	Description	Selection / User entry	Factory setting
Assign current output	Select process variable for current output.	<ul style="list-style-type: none"> <li>■ Off</li> <li>■ Volume flow</li> <li>■ Mass flow</li> </ul>	Volume flow
Mass flow unit	Select mass flow unit. <i>Result</i> The selected unit applies for: <ul style="list-style-type: none"> <li>■ Output</li> <li>■ Low flow cut off</li> <li>■ Simulation process variable</li> </ul>	Unit choose list	Country-specific: <ul style="list-style-type: none"> <li>■ kg/h</li> <li>■ lb/min</li> </ul>
Volume flow unit	Select volume flow unit. <i>Result</i> The selected unit applies for: <ul style="list-style-type: none"> <li>■ Output</li> <li>■ Low flow cut off</li> <li>■ Simulation process variable</li> </ul>	Unit choose list	Country-specific: <ul style="list-style-type: none"> <li>■ l/h</li> <li>■ gal/min (us)</li> </ul>
Density unit	Select density unit. <i>Result</i> The selected unit applies for: <ul style="list-style-type: none"> <li>■ Output</li> <li>■ Simulation process variable</li> <li>■ Density adjustment (in <b>Expert</b> menu)</li> </ul>	Unit choose list	Country-specific: <ul style="list-style-type: none"> <li>■ kg/l</li> <li>■ lb/ft<sup>3</sup></li> </ul>
Fixed density	Enter fixed value for medium density.	0.01 to 15 000 kg/m <sup>3</sup>	1 000 kg/m <sup>3</sup>
Current span	Select current range for process value output and upper/lower level for alarm signal.	<ul style="list-style-type: none"> <li>■ 4...20 mA NAMUR</li> <li>■ 4...20 mA US</li> <li>■ 4...20 mA</li> <li>■ 0...20 mA</li> <li>■ Fixed current</li> </ul>	4...20 mA NAMUR
0/4 mA value	Enter 4 mA value.	Signed floating-point number	0 l/h
20 mA value	Enter 20 mA value.	Signed floating-point number	0.025 l/h
Failure mode	Define output behavior in alarm condition.	<ul style="list-style-type: none"> <li>■ Min.</li> <li>■ Max.</li> <li>■ Last valid value</li> <li>■ Actual value</li> <li>■ Defined value</li> </ul>	Max.
Failure current	Enter current output value in alarm condition.	3.59 <sup>-3</sup> to 22.5 <sup>-3</sup> mA	22.5 mA

#### 10.4.4 Configuring the pulse/frequency/switch output


The **Pulse/frequency/switch output 1 to 2** submenu guides you systematically through all the parameters that can be set for configuring the selected output type.

##### Pulse output

##### Navigation

"Setup" menu → Pulse/frequency/switch output 1 to 2

Structure of the wizard for the pulse output



A0017435-EN

24 "Pulse/frequency/switch output 1-2" wizard in the "Setup" menu: "Pulse" operating mode

Parameter overview with brief description

Parameter	Description	Selection / User entry	Factory setting
Operating mode	Define the output as a pulse, frequency or switch output.	<ul style="list-style-type: none"> <li>▪ Pulse</li> <li>▪ Frequency</li> <li>▪ Switch</li> </ul>	Pulse
Assign pulse output	Select process variable for pulse output.	<ul style="list-style-type: none"> <li>▪ Off</li> <li>▪ Volume flow</li> <li>▪ Mass flow</li> </ul>	Off
Mass unit	Select mass unit. <i>Result</i> The selected unit is taken from: <b>Mass flow unit</b> parameter	Unit choose list	Country-specific: <ul style="list-style-type: none"> <li>▪ kg</li> <li>▪ lb</li> </ul>
Volume unit	Select volume unit. <b>Result</b> The selected unit is taken from: <b>Volume flow unit</b> parameter	Unit choose list	Country-specific: <ul style="list-style-type: none"> <li>▪ l</li> <li>▪ gal (us)</li> </ul>


Parameter	Description	Selection / User entry	Factory setting
Density unit	Select density unit. <i>Result</i> The selected unit applies for: <ul style="list-style-type: none"> <li>▪ Output</li> <li>▪ Simulation process variable</li> <li>▪ Density adjustment (in <b>Expert</b> menu)</li> </ul>	Unit choose list	Country-specific: <ul style="list-style-type: none"> <li>▪ kg/l</li> <li>▪ lb/ft<sup>3</sup></li> </ul>
Fixed density	Enter fixed value for medium density.	0.01 to 15 000 kg/m <sup>3</sup>	1 000 kg/m <sup>3</sup>
Value per pulse	Enter measured value at which a pulse is output.	Signed floating-point number	0
Pulse width	Define time width of the output pulse.	0.05 to 2 000 ms	100 ms
Failure mode	Define output behavior in alarm condition.	<ul style="list-style-type: none"> <li>▪ Actual value</li> <li>▪ No pulses</li> </ul>	No pulses
Invert output signal	Invert the output signal.	<ul style="list-style-type: none"> <li>▪ No</li> <li>▪ Yes</li> </ul>	No

### Frequency output

#### Navigation

"Setup" menu → Pulse/frequency/switch output 1 to 2

**Structure of the wizard for the frequency output**



A0023208-EN

25 "Pulse/frequency/switch output 1-2" wizard in the "Setup" menu: "Frequency" operating mode

**Parameter overview with brief description**

Parameter	Description	Selection / User entry	Factory setting
Operating mode	Define the output as a pulse, frequency or switch output.	<ul style="list-style-type: none"> <li>■ Pulse</li> <li>■ Frequency</li> <li>■ Switch</li> </ul>	Pulse
Assign frequency output	Select process variable for frequency output.	<ul style="list-style-type: none"> <li>■ Off</li> <li>■ Volume flow</li> <li>■ Mass flow</li> <li>■ Flow velocity</li> <li>■ Electronic temperature</li> </ul>	Off


Parameter	Description	Selection / User entry	Factory setting
Mass flow unit	Select mass flow unit. <i>Result</i> The selected unit applies for: <ul style="list-style-type: none"> <li>▪ Output</li> <li>▪ Low flow cut off</li> <li>▪ Simulation process variable</li> </ul>	Unit choose list	Country-specific: <ul style="list-style-type: none"> <li>▪ kg/h</li> <li>▪ lb/min</li> </ul>
Volume flow unit	Select volume flow unit. <i>Result</i> The selected unit applies for: <ul style="list-style-type: none"> <li>▪ Output</li> <li>▪ Low flow cut off</li> <li>▪ Simulation process variable</li> </ul>	Unit choose list	Country-specific: <ul style="list-style-type: none"> <li>▪ l/h</li> <li>▪ gal/min (us)</li> </ul>
Minimum frequency value	Enter minimum frequency.	0.0 to 12 500.0 Hz	0.0 Hz
Maximum frequency value	Enter maximum frequency.	0.0 to 12 500.0 Hz	12 500.0 Hz
Measuring value at minimum frequency	Enter measured value for minimum frequency.	Signed floating-point number	0
Measuring value at maximum frequency	Enter measured value for maximum frequency.	Signed floating-point number	0
Failure mode	Define output behavior in alarm condition.	<ul style="list-style-type: none"> <li>▪ Actual value</li> <li>▪ Defined value</li> <li>▪ 0 Hz</li> </ul>	0 Hz
Failure frequency	Enter frequency output value in alarm condition.	0.0 to 12 500.0 Hz	0.0 Hz
Invert output signal	Invert the output signal.	<ul style="list-style-type: none"> <li>▪ No</li> <li>▪ Yes</li> </ul>	No

### Switch output

#### Navigation


"Setup" menu → Pulse/frequency/switch output 1 to 2

Structure of the wizard for the switch output



A0017439-EN

26 "Pulse/frequency/switch output 1-2" wizard in the "Setup" menu: "Switch" operating mode (Part 1)



A0023207-EN

27 "Pulse/frequency/switch output 1-2" wizard in the "Setup" menu: "Switch" operating mode (Part 2)

**Parameter overview with brief description**

Parameter	Description	Selection / User entry	Factory setting
Operating mode	Define the output as a pulse, frequency or switch output.	<ul style="list-style-type: none"> <li>■ Pulse</li> <li>■ Frequency</li> <li>■ Switch</li> </ul>	Pulse
Switch output function	Select function for switch output.	<ul style="list-style-type: none"> <li>■ Off</li> <li>■ On</li> <li>■ Diagnostic behavior</li> <li>■ Limit</li> <li>■ Flow direction check</li> <li>■ Status</li> </ul>	Off
Assign diagnostic behavior	Select diagnostic behavior for switch output.	<ul style="list-style-type: none"> <li>■ Alarm</li> <li>■ Alarm or warning</li> <li>■ Warning</li> </ul>	Alarm

Parameter	Description	Selection / User entry	Factory setting
Assign limit	Select process variable for limit function.	<ul style="list-style-type: none"> <li>▪ Off</li> <li>▪ Volume flow</li> <li>▪ Mass flow</li> <li>▪ Flow velocity</li> <li>▪ Electronic temperature</li> <li>▪ Totalizer 1</li> <li>▪ Totalizer 2</li> <li>▪ Totalizer 3</li> </ul>	Volume flow
Assign flow direction check	Select process variable for flow direction monitoring.	<ul style="list-style-type: none"> <li>▪ Off</li> <li>▪ Volume flow</li> <li>▪ Mass flow</li> </ul>	Volume flow
Assign status	Select device status for switch output.	<ul style="list-style-type: none"> <li>▪ Empty pipe detection</li> <li>▪ Low flow cut off</li> </ul>	Empty pipe detection
Mass flow unit	Select mass flow unit. <i>Result</i> The selected unit applies for: <ul style="list-style-type: none"> <li>▪ Output</li> <li>▪ Low flow cut off</li> <li>▪ Simulation process variable</li> </ul>	Unit choose list	Country-specific: <ul style="list-style-type: none"> <li>▪ kg/h</li> <li>▪ lb/min</li> </ul>
Volume flow unit	Select volume flow unit. <i>Result</i> The selected unit applies for: <ul style="list-style-type: none"> <li>▪ Output</li> <li>▪ Low flow cut off</li> <li>▪ Simulation process variable</li> </ul>	Unit choose list	Country-specific: <ul style="list-style-type: none"> <li>▪ l/h</li> <li>▪ gal/min (us)</li> </ul>
Unit totalizer	Select process variable totalizer unit.	Unit choose list	l
Switch-on value	Enter measured value for the switch-on point.	Signed floating-point number	0 l/h
Switch-off value	Enter measured value for the switch-off point.	Signed floating-point number	0 l/h
Switch-on delay	Define delay for the switch-on of status output.	0.0 to 100.0 s	0.0 s
Switch-off delay	Define delay for the switch-off of status output.	0.0 to 100.0 s	0.0 s
Failure mode	Define output behavior in alarm condition.	<ul style="list-style-type: none"> <li>▪ Actual status</li> <li>▪ Open</li> <li>▪ Closed</li> </ul>	Open
Invert output signal	Invert the output signal.	<ul style="list-style-type: none"> <li>▪ No</li> <li>▪ Yes</li> </ul>	No


### 10.4.5 Configuring the local display

The **Display** wizard guides you systematically through all the parameters that can be configured for configuring the local display.

#### Navigation

"Setup" menu → Display

**Structure of the wizard**



A0013797-EN

28 "Display" wizard in the "Setup" menu

**Parameter overview with brief description**

Parameter	Description	Selection / User entry	Factory setting
Format display	Select how measured values are shown on the display.	<ul style="list-style-type: none"> <li>■ 1 value, max. size</li> <li>■ 1 bargraph + 1 value</li> <li>■ 2 values</li> <li>■ 1 value large + 2 values</li> <li>■ 4 values</li> </ul>	1 value, max. size
Value 1 display	Select the measured value that is shown on the local display.	<ul style="list-style-type: none"> <li>■ Volume flow</li> <li>■ Mass flow</li> <li>■ Totalizer 1</li> <li>■ Totalizer 2</li> <li>■ Totalizer 3</li> <li>■ Current output 1</li> </ul>	Volume flow
0% bargraph value 1	Enter 0% value for bar graph display.	Signed floating-point number	0 l/h
100% bargraph value 1	Enter 100% value for bar graph display.	Signed floating-point number	0.025 l/h
Value 2 display	Select the measured value that is shown on the local display.	Picklist (see 1st display value)	None


Parameter	Description	Selection / User entry	Factory setting
Value 3 display	Select the measured value that is shown on the local display.	Picklist (see 1st display value)	None
0% bargraph value 3	Enter 0% value for bar graph display.	Signed floating-point number	0
100% bargraph value 3	Enter 100% value for bar graph display.	Signed floating-point number	0
Value 4 display	Select the measured value that is shown on the local display.	Picklist (see 1st display value)	None

### 10.4.6 Configuring the HART input

The **HART input** submenu contains all the parameters that must be configured for the configuration of the HART input.

#### Navigation


"Expert" menu → Communication → HART input → Configuration



29 "HART input" wizard in the "Setup" menu

A0016338-EN

### Parameter overview with brief description


Parameter	Description	Selection / User entry	Factory setting
Capture mode	Select capture mode via burst or master communication.	<ul style="list-style-type: none"> <li>▪ Off</li> <li>▪ Burst network</li> <li>▪ Master network</li> </ul>	Off
Manufacturer ID	Enter manufacture ID of external device.	0 to 255	0
Device ID	Enter device ID of external device.	Positive integer	0
Device type	Enter device type of external device.	0 to 255	0
Burst command	Select command to read in external process variable.	<ul style="list-style-type: none"> <li>▪ Command 1</li> <li>▪ Command 3</li> <li>▪ Command 9</li> <li>▪ Command 33</li> </ul>	Command 1
Slot number	Define position of external process variable in burst command.	1 to 4	1
Timeout	Enter deadline for process variable of external device.  If the deadline is exceeded, diagnostic message <b>F410 data transmission</b> is output.	1 to 120 s	5 s
Failure mode	Define behavior if external process variable is missed.	<ul style="list-style-type: none"> <li>▪ Alarm</li> <li>▪ Last valid value</li> <li>▪ Defined value</li> </ul>	Alarm
Failure value	Enter value to be used by the device if input value from external device is missing.	Signed floating-point number	0

## 10.4.7 Configuring the output conditioning

### Navigation

"Setup" menu → Output conditioning

Structure of the wizard



A0023200-EN

30 "Output conditioning" wizard in the "Setup" menu

Reverse flow\* = option only for pulse and frequency output

Parameter overview with brief description

Parameter	Description	User entry / Selection	Factory setting
Display damping	Set display reaction time to fluctuations in the measured value.	0.0 to 999.9 s	0.0 s
Damping output 1	Set reaction time for output signal to fluctuations in the measured value.	0 to 999.9 s	1 s
Damping output 1	Set reaction time for output signal to fluctuations in the measured value.	0 to 999.9 s	1 s
Assign current output	Select process variable for current output.	<ul style="list-style-type: none"> <li>■ Off</li> <li>■ Volume flow</li> <li>■ Mass flow</li> </ul>	Volume flow
Assign pulse output	Select process variable for pulse output.	<ul style="list-style-type: none"> <li>■ Off</li> <li>■ Volume flow</li> <li>■ Mass flow</li> </ul>	Off

Parameter	Description	User entry / Selection	Factory setting
Assign frequency output	Select process variable for frequency output.	<ul style="list-style-type: none"> <li>■ Off</li> <li>■ Volume flow</li> <li>■ Mass flow</li> <li>■ Flow velocity</li> <li>■ Electronic temperature</li> </ul>	Off
Measuring mode output 1	Select measuring mode for output.	<ul style="list-style-type: none"> <li>■ Forward flow</li> <li>■ Forward/Reverse flow</li> <li>■ Reverse flow compensation</li> </ul>	Forward flow
Measuring mode output 1	Select measuring mode for output.	<ul style="list-style-type: none"> <li>■ Forward flow</li> <li>■ Forward/Reverse flow</li> <li>■ Reverse flow</li> <li>■ Reverse flow compensation</li> </ul>	Forward flow
Measuring mode output 1	Select measuring mode for output.	<ul style="list-style-type: none"> <li>■ Forward flow</li> <li>■ Forward/Reverse flow</li> <li>■ Reverse flow</li> <li>■ Reverse flow compensation</li> </ul>	Forward flow


### 10.4.8 Configuring the low flow cut off

The **Low flow cut off** wizard guides you systematically through all the parameters that have to be set for configuring the low flow cut off.

#### Navigation

"Setup" menu → Low flow cut off

#### Structure of the wizard



31 "Low flow cut off" wizard in the "Setup" menu

A0020524-EN

#### Parameter overview with brief description

Parameter	Description	Selection / User entry	Factory setting
Assign process variable	Select process variable for low flow cut off.	<ul style="list-style-type: none"> <li>■ Off</li> <li>■ Volume flow</li> <li>■ Mass flow</li> </ul>	Volume flow
On value low flow cutoff	Enter on value for low flow cut off.	Signed floating-point number	0 l/h

Parameter	Description	Selection / User entry	Factory setting
Off value low flow cutoff	Enter off value for low flow cut off.	0 to 100.0 %	50 %
Pressure shock suppression	Enter time frame for signal suppression (= active pressure shock suppression).	0 to 100 s	0 s


### 10.4.9 Configuring empty pipe detection

The **Empty pipe detection** wizard guides you systematically through all the parameters that have to be set for configuring the low flow cut off.

#### Navigation

"Setup" menu → Empty pipe detection

#### Structure of the wizard



32 "Empty pipe detection" wizard in the "Setup" menu

A0017210-EN


#### Parameter overview with brief description

Parameter	Description	Selection / User interface / User entry	Factory setting
Empty pipe detection	Switch empty pipe detection on and off.	<ul style="list-style-type: none"> <li>▪ Off</li> <li>▪ On</li> </ul>	Off
New adjustment	Select type of adjustment.	<ul style="list-style-type: none"> <li>▪ Cancel</li> <li>▪ Empty pipe adjust</li> <li>▪ Full pipe adjust</li> </ul>	Cancel
Progress		<ul style="list-style-type: none"> <li>▪ Ok</li> <li>▪ Busy</li> <li>▪ Not ok</li> </ul>	
Switch point empty pipe detection	Enter hysteresis in %, below this value the measuring tube will be detected as empty.	0 to 100 %	50 %
Response time empty pipe detection	Enter the time before diagnostic message S862 'Pipe empty' is displayed for empty pipe detection.	0 to 100 s	1 s

## 10.5 Advanced settings

The **Advanced setup** submenu with its submenus contains parameters for specific settings.

*Navigation to the "Advanced setup" submenu*




33 Using the example of the local display

A0017519-EN

### Navigation

"Setup" menu → Advanced setup

### Overview of the parameters and submenus in the "Advanced setup" submenu




### 10.5.1 Setting the system units

In the **System units** submenu the units of all the measured values can be set.

#### Navigation

"Setup" menu → System units



#### Parameter overview with brief description

Parameter	Description	Selection	Factory setting
Volume flow unit	Select volume flow unit. <i>Result</i> The selected unit applies for: <ul style="list-style-type: none"> <li>▪ Output</li> <li>▪ Low flow cut off</li> <li>▪ Simulation process variable</li> </ul>	Unit choose list	Country-specific: <ul style="list-style-type: none"> <li>▪ l/h</li> <li>▪ gal/min (us)</li> </ul>
Volume unit	Select volume unit. <b>Result</b> The selected unit is taken from: <b>Volume flow unit</b> parameter	Unit choose list	Country-specific: <ul style="list-style-type: none"> <li>▪ l</li> <li>▪ gal (us)</li> </ul>
Temperature unit	Select temperature unit. <i>Result</i> The selected unit applies for: <ul style="list-style-type: none"> <li>▪ Output</li> <li>▪ Reference temperature</li> <li>▪ Simulation process variable</li> </ul>	Unit choose list	Country-specific: <ul style="list-style-type: none"> <li>▪ °C (Celsius)</li> <li>▪ °F (Fahrenheit)</li> </ul>
Mass flow unit	Select mass flow unit. <i>Result</i> The selected unit applies for: <ul style="list-style-type: none"> <li>▪ Output</li> <li>▪ Low flow cut off</li> <li>▪ Simulation process variable</li> </ul>	Unit choose list	Country-specific: <ul style="list-style-type: none"> <li>▪ kg/h</li> <li>▪ lb/min</li> </ul>
Mass unit	Select mass unit. <i>Result</i> The selected unit is taken from: <b>Mass flow unit</b> parameter	Unit choose list	Country-specific: <ul style="list-style-type: none"> <li>▪ kg</li> <li>▪ lb</li> </ul>
Density unit	Select density unit. <i>Result</i> The selected unit applies for: <ul style="list-style-type: none"> <li>▪ Output</li> <li>▪ Simulation process variable</li> <li>▪ Density adjustment (in <b>Expert</b> menu)</li> </ul>	Unit choose list	Country-specific: <ul style="list-style-type: none"> <li>▪ kg/l</li> <li>▪ lb/ft<sup>3</sup></li> </ul>

## 10.5.2 Carrying out a sensor adjustment

The **Sensor adjustment** submenu contains parameters that pertain to the functionality of the sensor.

### Navigation

"Setup" menu → Advanced setup → Sensor adjustment

### Structure of the submenu



### Parameter overview with brief description


Parameter	Description	Selection	Factory setting
Installation direction	Set sign of flow direction to match the direction of the arrow on the sensor.	<ul style="list-style-type: none"> <li>▪ Flow in arrow direction</li> <li>▪ Flow against arrow direction</li> </ul>	Flow in arrow direction

## 10.5.3 Configuring the totalizer

In the **"Totalizer 1 to 3"** submenu the individual totalizers can be configured.

### Navigation

"Setup" menu → Advanced setup → Totalizer 1 to 3



### Parameter overview with brief description

Parameter	Description	Selection	Factory setting
Assign process variable	Select process variable for totalizer.	<ul style="list-style-type: none"> <li>▪ Off</li> <li>▪ Volume flow</li> <li>▪ Mass flow</li> </ul>	Volume flow
Unit totalizer	Select process variable totalizer unit.	Unit choose list	1
Totalizer operation mode	Select totalizer calculation mode.	<ul style="list-style-type: none"> <li>▪ Net flow total</li> <li>▪ Forward flow total</li> <li>▪ Reverse flow total</li> </ul>	Net flow total
Failure mode	Define totalizer behavior in alarm condition.	<ul style="list-style-type: none"> <li>▪ Stop</li> <li>▪ Actual value</li> <li>▪ Last valid value</li> </ul>	Stop

### 10.5.4 Carrying out additional display configurations

In the **"Display"** submenu you can set all the parameters involved in the configuration of the local display.

#### Navigation

"Setup" menu → Advanced setup → Display

#### Structure of the submenu

Display	→	Format display
		Value 1 display
		0% bargraph value 1
		100% bargraph value 1
		Decimal places 1
		Value 2 display
		Decimal places 2
		Value 3 display
		0% bargraph value 3
		100% bargraph value 3
		Decimal places 3
		Value 4 display
		Decimal places 4
		Display language
		Display interval
		Display damping
		Header
		Header text
		Separator
		Backlight

## Parameter overview with brief description

Parameter	Description	Selection / User entry	Factory setting
Format display	Select how measured values are shown on the display.	<ul style="list-style-type: none"> <li>▪ 1 value, max. size</li> <li>▪ 1 bargraph + 1 value</li> <li>▪ 2 values</li> <li>▪ 1 value large + 2 values</li> <li>▪ 4 values</li> </ul>	1 value, max. size
Value 1 display	Select the measured value that is shown on the local display.	<ul style="list-style-type: none"> <li>▪ Volume flow</li> <li>▪ Mass flow</li> <li>▪ Totalizer 1</li> <li>▪ Totalizer 2</li> <li>▪ Totalizer 3</li> <li>▪ Current output 1</li> </ul>	Volume flow
0% bargraph value 1	Enter 0% value for bar graph display.	Signed floating-point number	0 l/h
100% bargraph value 1	Enter 100% value for bar graph display.	Signed floating-point number	0.025 l/h
Decimal places 1	Select the number of decimal places for the display value.	<ul style="list-style-type: none"> <li>▪ x</li> <li>▪ x.x</li> <li>▪ x.xx</li> <li>▪ x.xxx</li> <li>▪ x.xxxx</li> </ul>	x.xx
Value 2 display	Select the measured value that is shown on the local display.	Picklist (see 1st display value)	None
Decimal places 2	Select the number of decimal places for the display value.	<ul style="list-style-type: none"> <li>▪ x</li> <li>▪ x.x</li> <li>▪ x.xx</li> <li>▪ x.xxx</li> <li>▪ x.xxxx</li> </ul>	x.xx
Value 3 display	Select the measured value that is shown on the local display.	Picklist (see 1st display value)	None
0% bargraph value 3	Enter 0% value for bar graph display.	Signed floating-point number	0
100% bargraph value 3	Enter 100% value for bar graph display.	Signed floating-point number	0
Decimal places 3	Select the number of decimal places for the display value.	<ul style="list-style-type: none"> <li>▪ x</li> <li>▪ x.x</li> <li>▪ x.xx</li> <li>▪ x.xxx</li> <li>▪ x.xxxx</li> </ul>	x.xx
Value 4 display	Select the measured value that is shown on the local display.	Picklist (see 1st display value)	None
Decimal places 4	Select the number of decimal places for the display value.	<ul style="list-style-type: none"> <li>▪ x</li> <li>▪ x.x</li> <li>▪ x.xx</li> <li>▪ x.xxx</li> <li>▪ x.xxxx</li> </ul>	x.xx

Parameter	Description	Selection / User entry	Factory setting
Display language	Set display language.	<ul style="list-style-type: none"> <li>▪ English</li> <li>▪ Deutsch</li> <li>▪ Français</li> <li>▪ Español</li> <li>▪ Italiano</li> <li>▪ Nederlands</li> <li>▪ Portuguesa</li> <li>▪ Polski</li> <li>▪ русский язык (Russian)</li> <li>▪ Svenska</li> <li>▪ Türkçe</li> <li>▪ 中文 (Chinese)</li> <li>▪ 日本語 (Japanese)</li> <li>▪ 한국어 (Korean)</li> <li>▪ العربية (Arabic)</li> <li>▪ Bahasa Indonesia</li> <li>▪ ภาษาไทย (Thai)</li> <li>▪ tiếng Việt (Vietnamese)</li> <li>▪ čeština (Czech)</li> </ul>	English (alternatively, the ordered language is preset in the device)
Display interval	Set time measured values are shown on display if display alternates between values.	1 to 10 s	5 s
Display damping	Set display reaction time to fluctuations in the measured value.	0.0 to 999.9 s	0.0 s
Header	Select header contents on local display.	<ul style="list-style-type: none"> <li>▪ Device tag</li> <li>▪ Free text</li> </ul>	Device tag
Header text	Enter display header text.		-----
Separator	Select decimal separator for displaying numerical values.	<ul style="list-style-type: none"> <li>▪ .</li> <li>▪ ,</li> </ul>	.
Backlight	Switch the local display backlight on and off.	<ul style="list-style-type: none"> <li>▪ Disable</li> <li>▪ Enable</li> </ul>	Enable

## 10.6 Simulation

The **"Simulation" submenu** enables you to simulate, without a real flow situation, various process variables in the process and the device alarm mode and to verify downstream signal chains (switching valves or closed-control loops).




The parameters displayed depend on:

- The selected device order
- The set operating mode of the pulse/frequency/switch outputs (→ 73)


### Navigation

"Diagnostics" menu → Simulation



Frequency value
Pulse simulation
Pulse value
Switch output simulation
Switch status
Simulation device alarm
Simulation diagnostic event




**Parameter overview with brief description**

Parameter	Prerequisite	Description	Selection / User entry	Factory setting
Assign simulation process variable	-	Select a process variable for the simulation process that is activated.	<ul style="list-style-type: none"> <li>▪ Off</li> <li>▪ Volume flow</li> <li>▪ Mass flow</li> </ul>	Off
Value process variable	A process variable is selected in the <b>Assign simulation process variable</b> parameter.	Enter the simulation value for the selected process variable.	Signed floating-point number	0
Simulation status input	-	Switch simulation of the status input on and off.	<ul style="list-style-type: none"> <li>▪ Off</li> <li>▪ On</li> </ul>	Off
Input signal level	-	Select the signal level for the simulation of the status input.	<ul style="list-style-type: none"> <li>▪ High</li> <li>▪ Low</li> </ul>	High
Simulation current output 1	-	Switch simulation of the current output on and off.	<ul style="list-style-type: none"> <li>▪ Off</li> <li>▪ On</li> </ul>	Off
Value current output 1	The <b>On</b> option is selected in the <b>Current output simulation</b> parameter.	Enter the current value for simulation.	3.59 <sup>-3</sup> to 22.5 <sup>-3</sup> mA	3.59 mA
Frequency simulation 1	-	Switch simulation of the frequency output on and off.	<ul style="list-style-type: none"> <li>▪ Off</li> <li>▪ On</li> </ul>	Off
Frequency value 1	The <b>On</b> option is selected in the <b>Frequency output simulation</b> parameter.	Enter the frequency value for simulation.	0.0 to 12 500.0 Hz	0.0 Hz
Pulse simulation 1	The <b>Down-count. val.</b> option is selected in the <b>Simulation pulse output</b> parameter.	Switch simulation of the pulse output on and off.  If the <b>Fixed value</b> option is selected, the <b>Pulse width</b> parameter defines the pulse width of the pulses output.	<ul style="list-style-type: none"> <li>▪ Off</li> <li>▪ Fixed value</li> <li>▪ Down-counting value</li> </ul>	Off
Pulse value 1	The <b>Down-count. val.</b> option is selected in the <b>Simulation pulse output</b> parameter.	Enter the number of pulses for simulation.	0 to 65 535	0
Switch output simulation 1	-	Switch simulation of switch output on and off.	<ul style="list-style-type: none"> <li>▪ Off</li> <li>▪ On</li> </ul>	Off
Switch status 1	The <b>On</b> option is selected in the <b>Switch output simulation</b> parameter.	Select the status of the status output for the simulation.	<ul style="list-style-type: none"> <li>▪ Open</li> <li>▪ Closed</li> </ul>	Open
Simulation device alarm	-	Switch the device alarm on and off.	<ul style="list-style-type: none"> <li>▪ Off</li> <li>▪ On</li> </ul>	Off

Parameter	Prerequisite	Description	Selection / User entry	Factory setting
Diagnostic event category	–	Select the category of the diagnostic event.	<ul style="list-style-type: none"> <li>■ Sensor</li> <li>■ Electronics</li> <li>■ Configuration</li> <li>■ Process</li> </ul>	Sensor
Simulation diagnostic event	–	Switch simulation of the diagnostic event on and off. For the simulation, you can choose from the diagnostic events of the category selected in the <b>Diagnostic event category</b> parameter.	<ul style="list-style-type: none"> <li>■ Off</li> <li>■ Picklist Diagnostic events (depends on the selected category)</li> </ul>	Off

## 10.7 Protecting settings from unauthorized access

The following options exist for protecting the configuration of the measuring device from unintentional modification after commissioning:

- Write protection via access code for the local display and Web browser (→  95)
- Write protection via write protection switch (→  96)
- Write protection via keypad lock (→  56)

### 10.7.1 Write protection via access code


The effects of the customer-specific access code are as follows:

- Via local operation, the parameters for the measuring device configuration are write-protected and their values can no longer be changed.
- Device access via the Web browser is protected, as are the parameters for the measuring device configuration.


#### Navigation

"Setup" menu → Advanced setup → Administration → Define access code



*Structure of the submenu*



#### Defining the access code via local display


1. Navigate to the **Enter access code** parameter.
2. Define a max. 4-digit numeric code as an access code.
3. Enter the access code again to confirm the code.
  - ↳ The -symbol appears in front of all write-protected parameters.

The device automatically locks the write-protected parameters again if a key is not pressed for 10 minutes in the navigation and editing view. The device locks the write-protected parameters automatically after 60 s if the user skips back to the operational display mode from the navigation and editing view.

-  ■ If write access is activated via access code, it can be also be deactivated only via the access code (→  56).
- The user role with which the user is currently logged on via the local display is indicated by the **Access status display** parameter. Navigation path: "Operation" menu → Access status display.

### Parameters which can always be modified via the local display

Certain parameters that do not affect the measurement are excepted from write protection via the local display. Despite the defined access code, these parameters can always be modified even if the other parameters are locked.



### Defining the access code via the Web browser

1. Navigate to the **Enter access code** parameter.
2. Define a max. 4-digit numeric code as an access code.
3. Enter the access code again to confirm the code.
  - ↳ The Web browser switches to the login page.

**i** If no action is performed for 10 minutes, the Web browser automatically returns to the login page.


**i** The user role with which the user is currently logged on via the Web browser is indicated by the **Access status tooling** parameter. Navigation path: Operation → Access status tooling

### 10.7.2 Write protection via write protection switch

Unlike write protection via user-specific access code, this allows write access to the entire operating menu - other than the **"Contrast display" parameter** - to be locked.


The parameter values are now read only and cannot be edited any more (exception **"Contrast display" parameter**):


- Via local display
- Via service interface (CDI-RJ45)
- Via HART protocol




A0017260

1. Loosen the 4 fixing screws on the housing cover and open the housing cover.
2. Setting the write protection switch (WP) on the main electronics module to the ON position enables the hardware write protection. Setting the write protection switch (WP) on the main electronics module to the OFF position (factory setting) disables the hardware write protection.

- ↳ If hardware write protection is enabled, the **Hardware locked** option is displayed in the **Locking status** parameter (→ 98). In addition, on the local display the -symbol appears in front of the parameters in the header of the operational display and in the navigation view.



If hardware write protection is disabled, no option is displayed in the **Locking status** parameter (→ 98). On the local display, the -symbol disappears from in front of the parameters in the header of the operational display and in the navigation view.

3. **WARNING!** Excessive tightening torque applied to the fixing screws! Risk of damaging the plastic transmitter. Tighten the fixing screws as per the tightening torque (→ 26).

Reverse the removal procedure to reassemble the transmitter.

# 11 Operation



## 11.1 Reading device locking status

The write protection types that are currently active can be determined using the **Locking status** parameter.


### Navigation



"Operation" menu → Locking status

*Function scope of "Locking status" parameter*



Options	Description
None	The access status displayed in " <b>Access status display</b> " parameter applies (→  56). Only appears on local display.
Hardware locked	The DIP switch for hardware locking is activated on the main electronics module. This prevents write access to the parameters (→  96).
Temporarily locked	Due to internal processing in the device (e.g. up-/downloading of data, reset), write access to the parameters is blocked for a short time. Once the internal processing has been completed, the parameters can be changed once again.

## 11.2 Adjusting the operating language

Information (→  69)

 For information on the operating languages supported by the measuring device (→  141)

## 11.3 Configuring the display

- Basic settings for local display (→  80)
- Advanced settings for local display (→  91)

## 11.4 Reading measured values

Using the **Measured values** submenu, it is possible to read all the measured values.

"Diagnostics" menu → Measured values


### 11.4.1 Process variables

The **Process variables** submenu contains all the parameters needed to display the current measured values for every process variable.

### Navigation

"Diagnostics" menu → Measured values → Process variables

### Structure of the submenu



**Structure of the submenu**

**Parameter overview with brief description**

Parameter	Description	User interface
Volume flow	Displays the volume flow currently measured.	Signed floating-point number
Mass flow	Displays the mass flow currently calculated.	Signed floating-point number


**11.4.2 Totalizer**

The **"Totalizer"** submenu contains all the parameters needed to display the current measured values for every totalizer.

**Navigation**

"Diagnostics" menu → Measured values → Totalizer

**Structure of the submenu**



**Parameter overview with brief description**

Parameter	Description	User interface	Factory setting
Totalizer value 1	Displays the current totalizer counter value.	Signed floating-point number	0 1
Totalizer overflow 1	Displays the current totalizer overflow.	-32 000.0 to 32 000.0	0

**11.4.3 Input values**


The **"Input values"** submenu guides you systematically to the individual input values.

 The submenu only appears if the device was ordered with a status input .

**Navigation**

"Diagnostics" menu → Measured values → Input values

**Structure of the submenu**





**Parameter overview with brief description**

Parameter	Description	User interface	Factory setting
Value status input	Displays the current input signal level.	<ul style="list-style-type: none"> <li>▪ High</li> <li>▪ Low</li> </ul>	Low

**11.4.4 Output values**


The **"Output values"** submenu contains all the parameters needed to display the current measured values for every output.

-  The parameters displayed depend on:
- The selected device order
  - The set operating mode of the pulse/frequency/switch outputs (→  73)

**Navigation**

"Diagnostics" menu → Measured values → Output values

**Structure of the submenu**





**Parameter overview with brief description**

Parameter	Description	User interface	Factory setting
Output current 1	Displays the current value currently calculated for the current output.	3.59 to 22.5 mA	3.59 mA
Measured current 1	Displays the current value currently measured for the current output.	0 to 30 mA	0 mA
Pulse output 1	Displays the value currently measured for the pulse output.	Positive floating-point number	0 Hz
Output frequency 1	Displays the value currently measured for the frequency output.	0.0 to 12 500.0 Hz	0.0 Hz
Switch status 1	Displays the current switch output status.	<ul style="list-style-type: none"> <li>▪ Open</li> <li>▪ Closed</li> </ul>	Open

## 11.5 Adapting the measuring device to the process conditions

The following are available for this purpose:

- Basic settings using the **Setup** menu(→  69)
- Advanced settings using the **Advanced setup** submenu(→  88)

## 11.6 Performing a totalizer reset

In the **Operation** submenu the totalizers are reset:

- Control Totalizer
- Reset all totalizers

*Function scope of "Control Totalizer " parameter*

Options	Description
Totalize	The totalizer is started.
Stop	Totalizing is stopped.
Reset + hold	The totaling process is stopped and the totalizer is reset to 0.

Options	Description
Preset + hold	The totaling process is stopped and the totalizer is set to its defined start value from the <b>Preset value</b> parameter.
Reset + totalize	The totalizer is reset to 0 and the totaling process is restarted.
Preset + totalize	The totalizer is set to the defined start value in <b>Preset value</b> parameter and the totaling process is restarted.


*Function scope of "Reset all totalizers" parameter*

Options	Description
Reset + totalize	Resets all totalizers to 0 and restarts the totaling process. This deletes all the flow values previously totalized.

**Navigation**

"Operation" menu → Operation

**Structure of the submenu**



**Parameter overview with brief description**


Parameter	Description	Selection / User entry	Factory setting
Control Totalizer #	Control totalizer value.	<ul style="list-style-type: none"> <li>■ Totalize</li> <li>■ Reset + hold</li> <li>■ Preset + hold</li> <li>■ Reset + totalize</li> <li>■ Preset + totalize</li> </ul>	Totalize
Preset value #	Specify start value for totalizer.	Signed floating-point number	0 1
Reset all totalizers	Reset all totalizers to 0 and start.	<ul style="list-style-type: none"> <li>■ Cancel</li> <li>■ Reset + totalize</li> </ul>	Cancel

**11.7 Showing data logging**

In the device, the extended function of the HistoROM must be enabled (order option) so that the **"Data logging" submenu** appears. This contains all the parameters for the measured value history.

**Function scope**

- A total of 1000 measured values can be stored
- 4 logging channels
- Adjustable logging interval for data logging
- Display of the measured value trend for each logging channel in the form of a chart



A0016222

34 Chart of a measured value trend

- x-axis: depending on the number of channels selected displays 250 to 1000 measured values of a process variable.
- y-axis: displays the approximate measured value span and constantly adapts this to the ongoing measurement.

**i** If the length of the logging interval or the assignment of the process variables to the channels is changed, the content of the data logging is deleted.

**Navigation**

"Diagnostics" menu → Data logging

**"Data logging" submenu**

Data logging	→	Assign channel 1
		Assign channel 2
		Assign channel 3
		Assign channel 4
		Logging interval
		Clear logging data

**Parameter overview with brief description**

Parameter	Description	Selection / User entry	Factory setting
Assign channel 1	Assign process variable to logging channel.	<ul style="list-style-type: none"> <li>■ Off</li> <li>■ Volume flow</li> <li>■ Mass flow</li> <li>■ Flow velocity</li> <li>■ Electronic temperature</li> <li>■ Current output 1</li> </ul>	Off
Assign channel 2	Assign process variable to logging channel.	Picklist (see <b>Assign channel 1</b> parameter)	Off
Assign channel 3	Assign process variable to logging channel.	Picklist (see <b>Assign channel 1</b> parameter)	Off
Assign channel 4	Assign process variable to logging channel.	Picklist (see <b>Assign channel 1</b> parameter)	Off
Logging interval	Define the logging interval for data logging. This value defines the time interval between the individual data points in the memory.	1.0 to 3 600.0 s	10.0 s
Clear logging data	Clear the entire logging data.	<ul style="list-style-type: none"> <li>■ Cancel</li> <li>■ Clear data</li> </ul>	Cancel

## 12 Diagnostics and troubleshooting

### 12.1 General troubleshooting










*For local display*

Problem	Possible causes	Remedy
Local display dark and no output signals	Supply voltage does not match that specified on the nameplate.	Apply the correct supply voltage .
Local display dark and no output signals	No contact between connecting cables and terminals.	Check the connection of the cables and correct if necessary.
Local display dark and no output signals	Terminals are not plugged into the main electronics module correctly.	Check terminals.
Local display dark and no output signals	Main electronics module is defective.	Order spare part (→ ☎ 122).
Local display dark and no output signals	The connector between the main electronics module and display module is not plugged in correctly.	Check the connection and correct if necessary.
Local display dark and no output signals	The connecting cable is not plugged in correctly.	<ol style="list-style-type: none"> <li>1. Check the connection of the electrode cable and correct if necessary.</li> <li>2. Check the connection of the coil current cable and correct if necessary.</li> </ol>
Local display is dark, but signal output is within the valid range	Display is set too bright or too dark.	<ul style="list-style-type: none"> <li>▪ Set the display brighter by simultaneously pressing <math>\oplus</math> + <math>\square</math>.</li> <li>▪ Set the display darker by simultaneously pressing <math>\ominus</math> + <math>\square</math>.</li> </ul>
Local display is dark, but signal output is within the valid range	Display module is defective.	Order spare part (→ ☎ 122).
Backlighting of local display is red	Diagnostic event with "Alarm" diagnostic behavior has occurred.	Take remedial measures (→ ☎ 112)
Text on local display appears in a foreign language and cannot be understood.	Incorrect operating language is configured.	<ol style="list-style-type: none"> <li>1. Press <math>\square</math> + <math>\oplus</math> for 2 s ("home position").</li> <li>2. Press <math>\square</math>.</li> <li>3. Set the desired language in the <b>Language</b> parameter.</li> </ol>
Message on local display: "Communication Error" "Check Electronics"	Communication between the display module and the electronics is interrupted.	<ul style="list-style-type: none"> <li>▪ Check the cable and the connector between the main electronics module and display module.</li> <li>▪ Order spare part (→ ☎ 122).</li> </ul>

*For output signals*

Problem	Possible causes	Remedy
Signal output outside the valid range	Main electronics module is defective.	Order spare part (→ ☎ 122).
Device shows correct value on local display, but signal output is incorrect, though in the valid range.	Configuration error	Check and correct parameter configuration.
Device measures incorrectly.	Configuration error or device is operated outside the application.	<ol style="list-style-type: none"> <li>1. Check and correct parameter configuration.</li> <li>2. Observe limit values specified in the "Technical Data".</li> </ol>

For access

Problem	Possible causes	Remedy
No write access to parameters	Hardware write protection enabled	Set the write protection switch on the main electronics module to the OFF position (→  96).
No write access to parameters	Current user role has limited access authorization	1. Check user role (→  56). 2. Enter correct customer-specific access code (→  56).
No connection via HART protocol	Missing or incorrectly installed communication resistor.	Install the communication resistor (250 Ω) correctly. Observe the maximum load (→  128).
No connection via HART protocol	Commubox <ul style="list-style-type: none"> <li>▪ Connected incorrectly</li> <li>▪ Configured incorrectly</li> <li>▪ Drivers not installed correctly</li> <li>▪ USB interface on computer configured incorrectly</li> </ul>	Observe the documentation for the Commubox.  FXA195 HART: Document "Technical Information" TI00404F
Not connecting to Web server	Incorrect IP address	Check the IP address: 192.168.1.212 (→  58)
Not connecting to Web server	Incorrect setting for the Ethernet interface of the computer	1. Check the properties of the Internet protocol (TCP/IP) (→  58). 2. Check the network settings with the IT manager.
Not connecting to Web server	Web server disabled	Via the "FieldCare" operating tool check whether the Web server of the measuring device is enabled and enable it if necessary (→  60).
No or incomplete display of contents in the Web browser	<ul style="list-style-type: none"> <li>▪ JavaScript not enabled</li> <li>▪ JavaScript cannot be enabled</li> </ul>	1. Enable JavaScript. 2. Enter http://192.168.1.212/basic.html as the IP address.
Web browser frozen and operation no longer possible	Data transfer active	Wait until data transfer or current action is finished.
Web browser frozen and operation no longer possible	Connection lost	1. Check cable connection and power supply. 2. Refresh the Web browser and restart if necessary.
Content of Web browser incomplete or difficult to read	Not using optimum version of Web server.	1. Use the correct Web browser version (→  57). 2. Clear the Web browser cache and restart the Web browser.
Content of Web browser incomplete or difficult to read	Unsuitable view settings.	Change the font size/display ratio of the Web browser.

## 12.2 Diagnostic information via light emitting diodes

### 12.2.1 Transmitter

Various light emitting diodes (LEDs) on the main electronics module of the transmitter provide information on device status.


LED	Color	Meaning
Power	Off	Supply voltage is off or too low
	Green	Supply voltage is ok
Link/Activity	Orange	Link available but no activity

LED	Color	Meaning
	Flashing orange	Activity present
Communication	Flashing white	HART communication is active.
Alarm	Green	Measuring device is ok
	Flashing green	Measuring device not configured
	Off	Firmware error
	Red	Main error
	Flashing red	Error
	Flashing red/green	Start measuring device

## 12.3 Diagnostic information on local display

### 12.3.1 Diagnostic message

Faults detected by the self-monitoring system of the measuring device are displayed as a diagnostic message in alternation with the operational display.



If two or more diagnostic events are pending simultaneously, only the message of the diagnostic event with the highest priority is shown.

- i** Other diagnostic events that have occurred can be called up in the **Diagnostics** menu:
  - Via parameters (→ 115)
  - Via submenus (→ 115)



#### Status signals

The status signals provide information on the state and reliability of the device by categorizing the cause of the diagnostic information (diagnostic event).

- i** The status signals are categorized according to VDI/VDE 2650 and NAMUR Recommendation NE 107: F = Failure, C = Function Check, S = Out of Specification, M = Maintenance Required


Symbol	Meaning
<b>F</b> <small>A0013956</small>	<b>Failure</b> A device error has occurred. The measured value is no longer valid.
<b>C</b> <small>A0013959</small>	<b>Function check</b> The device is in service mode (e.g. during a simulation).
<b>S</b> <small>A0013958</small>	<b>Out of specification</b> The device is operated: <ul style="list-style-type: none"> <li>▪ Outside its technical specification limits (e.g. outside the process temperature range)</li> <li>▪ Outside of the configuration carried out by the user (e.g. maximum flow in parameter <b>20 mA value</b>)</li> </ul>
<b>M</b> <small>A0013957</small>	<b>Maintenance required</b> Maintenance is required. The measured value remains valid.

### Diagnostic behavior



Symbol	Meaning
 <small>A0013961</small>	<b>Alarm</b> <ul style="list-style-type: none"> <li>Measurement is interrupted.</li> <li>Signal outputs and totalizers assume the defined alarm condition.</li> <li>A diagnostic message is generated.</li> <li>The background lighting changes to red.</li> </ul>
 <small>A0013962</small>	<b>Warning</b> Measurement is resumed. The signal outputs and totalizers are not affected. A diagnostic message is generated.

### Diagnostic information


The fault can be identified using the diagnostic information. The short text helps you by providing information about the fault. In addition, the corresponding symbol for the diagnostic behavior is displayed in front of the diagnostic information on the local display.



### Operating elements

Key	Meaning
 <small>A0013970</small>	<b>Plus key</b> <i>In a menu, submenu</i> Opens the message about the remedial measures.
 <small>A0013952</small>	<b>Enter key</b> <i>In a menu, submenu</i> Opens the operating menu.

### 12.3.2 Calling up remedial measures



A0013940-EN

#### 35 Message for remedial measures

- 1 Diagnostic information
- 2 Short text
- 3 Service ID
- 4 Diagnostic behavior with diagnostic code
- 5 Operation time of occurrence
- 6 Remedial measures

The user is in the diagnostic message.

1. Press  $\oplus$  (ⓘ symbol).  
↳ The **Diagnostic list** submenu opens.
2. Select the desired diagnostic event with  $\oplus$  or  $\ominus$  and press  $\text{E}$ .  
↳ The message for the remedial measures for the selected diagnostic event opens.
3. Press  $\ominus + \oplus$  simultaneously.  
↳ The message for the remedial measures closes.

The user is in the **Diagnostics** menu at an entry for a diagnostics event, e.g. in the **Diagnostic list** submenu or the **Previous diagnostics** parameter.

1. Press  $\text{E}$ .  
↳ The message for the remedial measures for the selected diagnostic event opens.
2. Press  $\ominus + \oplus$  simultaneously.  
↳ The message for the remedial measures closes.

## 12.4 Diagnostic information in the Web browser

### 12.4.1 Diagnostic options

Any faults detected by the measuring device are displayed in the Web browser on the home page once the user has logged on.

1 Status area with status signal  
 2 Diagnostic information (→ 107)  
 3 Remedial measures with Service ID

**i** Furthermore, diagnostic events that have occurred can be viewed in the **Diagnostics** menu:

- Via parameters (→ 115)
- Via submenus (→ 115)

### Status signals

The status signals provide information on the state and reliability of the device by categorizing the cause of the diagnostic information (diagnostic event).

Symbol	Meaning
 A0017271	<b>Failure</b> A device error has occurred. The measured value is no longer valid.
 A0017278	<b>Function check</b> The device is in service mode (e.g. during a simulation).
 A0017277	<b>Out of specification</b> The device is operated: <ul style="list-style-type: none"> <li>■ Outside its technical specification limits (e.g. outside the process temperature range)</li> <li>■ Outside of the configuration carried out by the user (e.g. maximum flow in parameter 20 mA value)</li> </ul>
 A0017276	<b>Maintenance required</b> Maintenance is required. The measured value is still valid.

**i** The status signals are categorized in accordance with VDI/VDE 2650 and NAMUR Recommendation NE 107.


### 12.4.2 Calling up remedy information

Remedy information is provided for every diagnostic event to ensure that problems can be rectified quickly. These measures are displayed in red along with the diagnostic event and the related diagnostic information.

## 12.5 Diagnostic information in FieldCare

### 12.5.1 Diagnostic options

Any faults detected by the measuring device are displayed on the home page of the operating tool once the connection has been established.




- 1 Status area with status signal (→ 106)
- 2 Diagnostic information (→ 107)
- 3 Remedial measures with Service ID

- i** Furthermore, diagnostic events that have occurred can be viewed in the **Diagnostics** menu:
  - Via parameters (→ 115)
  - Via submenu (→ 115)

### Diagnostic information

The fault can be identified using the diagnostic information. The short text helps you by providing information about the fault. In addition, the corresponding symbol for the diagnostic behavior is displayed in front of the diagnostic information on the local display.



### 12.5.2 Calling up remedy information

Remedy information is provided for every diagnostic event to ensure that problems can be rectified quickly:

- On the home page  
Remedy information is displayed in a separate field below the diagnostics information.
- In the **Diagnostics** menu  
Remedy information can be called up in the working area of the user interface.

The user is in the **Diagnostics** menu.


1. Call up the desired parameter.
2. On the right in the working area, mouse over the parameter.
  - ↳ A tool tip with remedy information for the diagnostic event appears.

## 12.6 Adapting the diagnostic information

### 12.6.1 Adapting the diagnostic behavior

Each item of diagnostic information is assigned a specific diagnostic behavior at the factory. The user can change this assignment for certain diagnostics information in the **Diagnostic behavior** submenu .

"Expert" menu → System → Diagnostic handling → Diagnostic behavior



A0014048-EN

36 Taking the example of the local display

You can assign the following options to the diagnostic number as the diagnostic behavior:

Options	Description
Alarm	Measurement is interrupted. Signal outputs and totalizers assume the defined alarm condition. A diagnostic message is generated. The background lighting changes to red.
Warning	Measurement is resumed. The signal outputs and totalizers are not affected. A diagnostic message is generated.
Logbook entry only	The device continues to measure. The diagnostic message is entered in the Event logbook (events list) submenu only and is not displayed in alternation with the measured value display.
Off	The diagnostic event is ignored, and no diagnostic message is generated or entered.

### 12.6.2 Adapting the status signal

Each item of diagnostic information is assigned a specific status signal at the factory. The user can change this assignment for certain diagnostic information in the **Diagnostic event category** submenu .


"Expert" menu → Communication → Diagnostic event category



### Available status signals

Configuration as per HART 7 Specification (Condensed Status), in accordance with NAMUR NE107.

Symbol	Meaning
<b>F</b> <small>A0013956</small>	<b>Failure</b> A device error has occurred. The measured value is no longer valid.
<b>C</b> <small>A0013959</small>	<b>Function check</b> The device is in service mode (e.g. during a simulation).
<b>S</b> <small>A0013958</small>	<b>Out of specification</b> The device is being operated: <ul style="list-style-type: none"> <li>▪ Outside its technical specification limits (e.g. outside the process temperature range)</li> <li>▪ Outside of the configuration carried out by the user (e.g. maximum flow in parameter <b>20 mA value</b>)</li> </ul>
<b>M</b> <small>A0013957</small>	<b>Maintenance required</b> Maintenance is required. The measured value is still valid.
<b>N</b> <small>A0023076</small>	Has no effect on the condensed status.

## 12.7 Overview of diagnostic information

 The amount of diagnostic information and the number of measured variables affected increase if the measuring device has one or more application packages.

 In the case of some items of diagnostic information, the status signal and the diagnostic behavior can be changed. Adapt the diagnostic information (→  111)

Diagnostic number	Short text	Remedy instructions	Status signal [from the factory]	Diagnostic behavior [from the factory]
<b>Diagnostic of sensor</b>				
004	Sensor	1. Change sensor 2. Contact service	S	Alarm
022	Sensor temperature	1. Change main electronic module 2. Change sensor	F	Alarm
043	Sensor short circuit	1. Check sensor and cable 2. Change sensor or cable	S	Warning
062	Sensor connection	1. Check sensor connections 2. Contact service	F	Alarm
082	Data storage	1. Check module connections 2. Contact service	F	Alarm
083	Memory content	1. Restart device 2. Contact service	F	Alarm
190	Special event 1	Contact service	F	Alarm
<b>Diagnostic of electronic</b>				
201	Device failure	1. Restart device 2. Contact service	F	Alarm
222	Electronic drift	Change main electronic module	F	Alarm
242	Software incompatible	1. Check software 2. Flash or change main electronics module	F	Alarm

Diagnostic number	Short text	Remedy instructions	Status signal [from the factory]	Diagnostic behavior [from the factory]
252	Modules incompatible	1. Check electronic modules 2. Change electronic modules	F	Alarm
261	Electronic modules	1. Restart device 2. Check electronic modules 3. Change I/O Modul or main electronics	F	Alarm
262	Module connection	1. Check module connections 2. Change main electronics	F	Alarm
270	Main electronic failure	Change main electronic module	F	Alarm
271	Main electronic failure	1. Restart device 2. Change main electronic module	F	Alarm
272	Main electronic failure	1. Restart device 2. Contact service	F	Alarm
273	Main electronic failure	Change electronic	F	Alarm
281	Electronic initialization	Firmware update active, please wait!	F	Alarm
283	Memory content	1. Reset device 2. Contact service	F	Alarm
302	Device verification active	Device verification active, please wait.	C	Warning
311	Electronic failure	1. Reset device 2. Contact service	F	Alarm
311	Electronic failure	1. Do not reset device 2. Contact service	M	Warning
322	Electronic drift	1. Perform verification manually 2. Change electronic	S	Warning
375	I/O communication failed	1. Restart device 2. Change main electronic module	F	Alarm
382	Data storage	1. Insert DAT module 2. Change DAT module	F	Alarm
383	Memory content	1. Restart device 2. Check or change DAT module 3. Contact service	F	Alarm
390	Special event 2	Contact service	F	Alarm
<b>Diagnostic of configuration</b>				
410	Data transfer	1. Check connection 2. Retry data transfer	F	Alarm
411	Up-/download active	Up-/download active, please wait	C	Warning
431	Trim 1	Carry out trim	C	Warning
437	Configuration incompatible	1. Restart device 2. Contact service	F	Alarm
438	Dataset	1. Check data set file 2. Check device configuration 3. Up- and download new configuration	M	Warning
441	Current output 1	1. Check process 2. Check current output settings	S	Warning <sup>1)</sup>
442	Frequency output 1 to 2	1. Check process 2. Check frequency output settings	S	Warning <sup>1)</sup>
443	Pulse output 1 to 2	1. Check process 2. Check pulse output settings	S	Warning <sup>1)</sup>
453	Flow override	Deactivate flow override	C	Warning


Diagnostic number	Short text	Remedy instructions	Status signal [from the factory]	Diagnostic behavior [from the factory]
484	Simulation failure mode	Deactivate simulation	C	Alarm
485	Simulation measured variable	Deactivate simulation	C	Warning
491	Simulation current output 1	Deactivate simulation	C	Warning
492	Simulation frequency output 1 to 2	Deactivate simulation frequency output	C	Warning
493	Simulation pulse output 1 to 2	Deactivate simulation pulse output	C	Warning
494	Switch output simulation 1 to 2	Deactivate simulation switch output	C	Warning
495	Simulation diagnostic event	Deactivate simulation	C	Warning
496	Simulation status input	Deactivate simulation status input	C	Warning
500	Electrode 1 potential exceeded	1. Check process cond. 2. Increase system pressure	F	Alarm
500	Electrode difference voltage too high	1. Check process cond. 2. Increase system pressure	F	Alarm
530	Electrode cleaning is running	1. Check process cond. 2. Increase system pressure	C	Warning
531	Empty pipe detection	Execute EPD adjustment	S	Warning
537	Configuration	1. Check IP addresses in network 2. Change IP address	F	Warning
540	Custody transfer mode failed	1. Deactivate custody transfer mode 2. Reactivate custody transfer mode	F	Alarm
590	Special event 3	Contact service	F	Alarm
<b>Diagnostic of process</b>				
803	Current loop	1. Check wiring 2. Change I/O module	F	Alarm
832	Electronic temperature too high	Reduce ambient temperature	S	Warning <sup>1)</sup>
833	Electronic temperature too low	Increase ambient temperature	S	Warning <sup>1)</sup>
834	Process temperature too high	Reduce process temperature	S	Warning <sup>1)</sup>
835	Process temperature too low	Increase process temperature	S	Warning <sup>1)</sup>
842	Process limit	Low flow cut off active! 1. Check low flow cut off configuration	S	Warning
862	Empty pipe	1. Check for gas in process 2. Adjust empty pipe detection	S	Warning
882	Input signal	1. Check input configuration 2. Check external device or process conditions	F	Alarm
937	EMC interference	Change main electronic module	S	Warning <sup>1)</sup>




Diagnostic number	Short text	Remedy instructions	Status signal [from the factory]	Diagnostic behavior [from the factory]
938	EMC interference	1. Check ambient conditions regarding EMC influence 2. Change main electronic module	F	Alarm
990	Special event 4	Contact service	F	Alarm


1) Diagnostic status is changeable.

## 12.8 Pending diagnostic events

The **Diagnostics** menu allows the user to view the current diagnostic event and the previous diagnostic event separately.

 To call up the measures to rectify a diagnostic event:


- Via local display (→  108)
- Via Web browser (→  109)
- Via "FieldCare" operating tool (→  111)

 Other pending diagnostic events can be displayed in the **Diagnostic list** submenu(→  115)


### Navigation

"Diagnostics" menu

### Structure of the submenu




### Parameter overview with brief description

Parameter	Prerequisite	Description	User interface	Factory setting
Actual diagnostics	1 diagnostic event has occurred.	Displays the current diagnostic event along with the diagnostic information.  If two or more messages occur simultaneously, the message with the highest priority is shown on the display.	Symbol for diagnostic behavior, diagnostic code and short message.	–
Previous diagnostics	2 diagnostic events have already occurred.	Displays the diagnostic event that occurred prior to the current diagnostic event along with the diagnostic information.	Symbol for diagnostic behavior, diagnostic code and short message.	–

## 12.9 Diagnostic list

In the **Diagnostic list** submenu, up to 5 currently pending diagnostic events can be displayed along with the related diagnostic information. If more than 5 diagnostic events are pending, the events with the highest priority are shown on the display.

**Navigation path****Diagnostics** menu → **Diagnostic list** submenu

A0014006-EN

37 Illustrated using the example of the local display

To call up the measures to rectify a diagnostic event:

- Via local display (→ 108)
- Via Web browser (→ 109)
- Via "FieldCare" operating tool (→ 111)


## 12.10 Event logbook

### 12.10.1 Event history

A chronological overview of the event messages that have occurred is provided in the **Events list** submenu.

**Navigation path**

"Diagnostics" menu → Event logbook → Events list



A0014006-EN

38 Illustrated using the example of the local display

A maximum of 20 event messages can be displayed in chronological order. If the advanced HistoROM function is enabled in the device (order option), up to 100 entries can be displayed.

The event history includes entries for:

- Diagnostic events (→ 112)
- Information events (→ 117)

In addition to the operation time of its occurrence, each event is also assigned a symbol that indicates whether the event has occurred or is ended:

- Diagnostic event
  - : Event has occurred
  - : Event has ended
- Information event
  - : Event has occurred

To call up the measures to rectify a diagnostic event:

- Via local display (→ 108)
- Via Web browser (→ 109)
- Via "FieldCare" operating tool (→ 111)

For filtering the displayed event messages (→ 117)

### 12.10.2 Filtering the event logbook

Using the **Filter options** parameter, you can define which category of event messages is displayed in the **Events list** submenu.

#### Navigation path

"Diagnostics" menu → Event logbook → Filter options

#### Filter categories

- All
- Failure (F)
- Function check (C)
- Out of specification (S)
- Maintenance required (M)
- Information (I)

### 12.10.3 Overview of information events

Unlike a diagnostic event, an information event is displayed in the event logbook only and not in the diagnostic list.

Info number	Info name
I1000	----- (Device ok)
I1089	Power on
I1090	Configuration reset
I1091	Configuration changed
I1092	Trend data deleted
I1110	Write protection switch changed
I1137	Electronic changed
I1151	History reset
I1155	Reset electronic temperature
I1156	Memory error trend
I1157	Memory error event list
I1184	Display connected
I1185	Display backup done
I1186	Restore via display done
I1187	Settings downloaded with display
I1188	Display data cleared
I1189	Backup compared
I1256	Display: access status changed
I1264	Safety sequence aborted
I1278	I/O module reset detected
I1335	Firmware changed
I1351	Empty pipe detection adjustment failure
I1353	Empty pipe detection adjustment ok
I1361	Wrong web server login
I1397	Fieldbus: access status changed
I1398	CDI: access status changed
I1444	Device verification passed
I1445	Device verification failed


Info number	Info name
I1457	Failed:Measured error verification
I1459	Failed: I/O module verification
I1461	Failed: Sensor verification
I1462	Failed:Sensor electronic module verific.
I1517	Custody transfer active
I1518	Custody transfe inactive

## 12.11 Resetting the measuring device

Using the **Device reset** parameter it is possible to reset the entire device configuration or some of the configuration to a defined state.

"Setup" menu → Advanced setup → Administration

*Function scope of "Device reset" parameter*

Options	Description
Cancel	No action is executed and the user exits the parameter.
To delivery settings	Every parameter for which a customer-specific default setting was ordered is reset to this customer-specific value. All other parameters are reset to the factory setting.  This option is not visible if no customer-specific settings have been ordered.
Restart device	The restart resets every parameter whose data are in the volatile memory (RAM) to the factory setting (e.g. measured value data). The device configuration remains unchanged.
History reset	Every parameter is reset to its factory setting.

## 12.12 Device information

The **Device information** submenu contains all the parameters that display different information for identifying the device.

### Navigation

"Diagnostics" menu → Device information

<b>Device information</b>	→	Device tag
		Serial number
		Firmware version
		Device name
		Order code
		Extended order code 1
		Extended order code 2
		Extended order code 3
		ENP version

Device revision
Device ID
Device type
Manufacturer ID
IP address
Subnet mask
Default gateway



### Parameter overview with brief description


Parameter	Description	User interface	Factory setting
Device tag	Enter tag for measuring point.	Max. 32 characters, such as letters, numbers or special characters (e.g. @, %, /)	Promag 400
Serial number	Displays the serial number of the measuring device.	Max. 11-digit character string comprising letters and numbers.	79AFF16000
Firmware version	Displays the device firmware version installed.	Character string with the following format: xx.yy.zz	01.05
Device name	Displays the name of the transmitter.	Character string composed of letters, numbers and certain punctuation marks.	Promag 400
Order code	Displays the device order code.	Character string composed of letters, numbers and certain punctuation marks	-
Extended order code 1	Displays the 1st part of the extended order code.	Character string	-
Extended order code 2	Displays the 2nd part of the extended order code.	Character string	-
Extended order code 3	Displays the 3rd part of the extended order code.	Character string	-
ENP version	Displays the version of the electronic nameplate.	Character string in the format xx.yy.zz	2.02.00
Custody transfer counter		0 to 65 535	0
Device revision	Displays the device revision with which the device is registered with the HART Communication Foundation.	0 to 255	6
Device ID	Displays the device ID for identifying the device in a HART network.	Positive integer	6-digit hexadecimal number
Device type	Displays the device type with which the measuring device is registered with the HART Communication Foundation.	0 to 255	103
Manufacturer ID	Displays the manufacturer ID with which the measuring device is registered with the HART Communication Foundation.	0 to 255	17
IP address	Displays the IP address of the Web server of the measuring device.	4 octet: 0 to 255 (in the particular octet)	192.168.1.212


Parameter	Description	User interface	Factory setting
Subnet mask	Displays the subnet mask.	4 octet: 0 to 255 (in the particular octet)	255.255.255.0
Default gateway	Displays the default gateway.	4 octet: 0 to 255 (in the particular octet)	0.0.0.0

## 12.13 Firmware history

Release date	Firmware version	Order code for "Firmware version"	Firmware changes	Documentation type	Documentation
10.2013	01.04.00	Option 76	Original firmware	Operating Instructions	BA01061D/06/EN/02.13
05.2014	01.05.00	Option 73	<ul style="list-style-type: none"> <li>▪ In accordance with HART 7 Specification</li> <li>▪ Integrated HART input</li> <li>▪ SD03 keypad lock</li> <li>▪ Modification of SIL functionality</li> <li>▪ HistoROM data logging in FieldCare "HistoROM" module</li> <li>▪ Simulation of diagnostic events</li> <li>▪ Ability to access Heartbeat Technology application package</li> </ul>	Operating Instructions	BA01061D/06/EN/03.14

 Flashing the firmware to the current version or to the previous version is possible via the service interface (CDI) (→  139).

 For the compatibility of the firmware version with the previous version, the installed device description files and operating tools, observe the information about the device in the "Manufacturer's information" document.

 The manufacturer's information is available:

- In the Download Area of the Endress+Hauser Internet site: [www.endress.com](http://www.endress.com) → Download
- Specify the following details:
  - Text search: Manufacturer's information
  - Search range: documentation

## 13 Maintenance

### 13.1 Maintenance tasks

No special maintenance work is required.

#### 13.1.1 Exterior cleaning

When cleaning the exterior of measuring devices, always use cleaning agents that do not attack the surface of the housing or the seals.

#### **WARNING**

**Cleaning agents can damage the plastic transmitter housing!**

- ▶ Do not use high-pressure steam.
- ▶ Only use the permitted cleaning agents specified.

**Permitted cleaning agents for the plastic transmitter housing**

- Commercially available household cleaners
- Methyl alcohol or isopropyl alcohol
- Mild soap solutions


#### 13.1.2 Interior cleaning

No interior cleaning is planned for the device.

#### 13.1.3 Replacing seals

The sensor's seals (particularly aseptic molded seals) must be replaced periodically.


The interval between changes depends on the frequency of the cleaning cycles, the cleaning temperature and the medium temperature.

Replacement seals (accessory) (→  142)

### 13.2 Measuring and test equipment


Endress+Hauser offers a wide variety of measuring and test equipment, such as W@M or device tests.

 Your Endress+Hauser Sales Center can provide detailed information on the services.

 For a list of some of the measuring and test equipment, refer to the "Accessories" chapter of the "Technical Information" document for the device.

### 13.3 Endress+Hauser services

Endress+Hauser offers a wide variety of services for maintenance such as recalibration, maintenance service or device tests.

 Your Endress+Hauser Sales Center can provide detailed information on the services.

## 14 Repair

### 14.1 General notes

#### Repair and conversion concept

The Endress+Hauser repair and conversion concept provides for the following:

- The measuring devices have a modular design.
- Spare parts are grouped into logical kits with the associated Installation Instructions.
- Repairs are carried out by Endress+Hauser Service or by correspondingly trained customers.
- Certified devices can be converted into other certified devices by Endress+Hauser Service or at the factory only.


#### Notes for repair and conversion

For repair and modification of a measuring device, observe the following notes:

- Use only original Endress+Hauser spare parts.
- Carry out the repair according to the Installation Instructions.
- Observe the applicable standards, federal/national regulations, Ex documentation (XA) and certificates.
- Document every repair and each conversion and enter them into the *W@M* life cycle management database.

### 14.2 Spare parts

 Measuring device serial number:

- Is located on the nameplate of the device.
- Can be read out via the **Serial number** parameter in the **Device information** submenu (→  118).

### 14.3 Endress+Hauser services

 Contact your Endress+Hauser Sales Center for information on services and spare parts.

### 14.4 Return

The measuring device must be returned if repairs or a factory calibration are required, or if the wrong measuring device has been ordered or delivered. According to legal regulations, Endress+Hauser, as an ISO-certified company, is required to follow certain procedures when handling returned products that are in contact with medium.

To ensure swift, safe and professional device returns, please read the return procedures and conditions on the Endress+Hauser website at

[www.services.endress.com/return-material](http://www.services.endress.com/return-material)

### 14.5 Disposal

#### 14.5.1 Removing the measuring device

1. Switch off the device.
2. **WARNING!** Danger to persons from process conditions. Beware of hazardous process conditions such as pressure in the measuring device, high temperatures or aggressive fluids.

Carry out the mounting and connection steps from the chapters "Mounting the measuring device" and "Connecting the measuring device" in the logically reverse sequence. Observe the safety instructions.

### 14.5.2 Disposing of the measuring device

**⚠ WARNING**

**Danger to personnel and environment from fluids that are hazardous to health.**

- ▶ Ensure that the measuring device and all cavities are free of fluid residues that are hazardous to health or the environment, e.g. substances that have permeated into crevices or diffused through plastic.

Observe the following notes during disposal:


- Observe valid federal/national regulations.
- Ensure proper separation and reuse of the device components.

## 15 Accessories

Various accessories, which can be ordered with the device or subsequently from Endress+Hauser, are available for the device. Detailed information on the order code in question is available from your local Endress+Hauser sales center or on the product page of the Endress+Hauser website: [www.endress.com](http://www.endress.com).

### 15.1 Device-specific accessories






#### 15.1.1 For the transmitter



Accessories	Description
Display protection	Is used to protect the display against impact or scoring from sand in desert areas.  For details, see Special Documentation SD00333F
Connecting cable for remote version	Coil current and electrode cables, various lengths, reinforced cables available on request.
Post mounting kit	Post mounting kit for transmitter.
Compact → remote conversion kit	For converting a compact device version to a remote device version.

#### 15.1.2 For the sensor


Accessories	Description
Mounting kit	Consists of: <ul style="list-style-type: none"> <li>▪ 2 process connections</li> <li>▪ Threaded fasteners</li> <li>▪ Seals</li> </ul>

### 15.2 Communication-specific accessories


Accessories	Description
Commubox FXA195 HART	For intrinsically safe HART communication with FieldCare via the USB interface.  For details, see "Technical Information" TI00404F
HART Loop Converter HMX50	Is used to evaluate and convert dynamic HART process variables to analog current signals or limit values.  For details, see "Technical Information" TI00429F and Operating Instructions BA00371F
Wireless HART adapter SWA70	Is used for the wireless connection of field devices. The WirelessHART adapter can be easily integrated into field devices and existing infrastructures, offers data protection and transmission safety and can be operated in parallel with other wireless networks with minimum cabling complexity.  For details, see Operating Instructions BA00061S
Fieldgate FXA320	Gateway for the remote monitoring of connected 4-20 mA measuring devices via a Web browser.  For details, see "Technical Information" TI00025S and Operating Instructions BA00053S
Fieldgate FXA520	Gateway for the remote diagnostics and remote configuration of connected HART measuring devices via a Web browser.  For details, see "Technical Information" TI00025S and Operating Instructions BA00051S

Field Xpert SFX350	Field Xpert SFX350 is a mobile computer for commissioning and maintenance. It enables efficient device configuration and diagnostics for HART and FOUNDATION Fieldbus devices in the <b>non-Ex area</b> .  For details, see Operating Instructions BA01202S
Field Xpert SFX370	Field Xpert SFX370 is a mobile computer for commissioning and maintenance. It enables efficient device configuration and diagnostics for HART and FOUNDATION Fieldbus devices in the <b>non-Ex area</b> and the <b>Ex area</b> .  For details, see Operating Instructions BA01202S

### 15.3 Service-specific accessories

Accessories	Description
Applicator	Software for selecting and sizing Endress+Hauser measuring devices: <ul style="list-style-type: none"> <li>Calculation of all the necessary data for identifying the optimum flowmeter: e.g. nominal diameter, pressure loss, accuracy or process connections.</li> <li>Graphic illustration of the calculation results</li> </ul> Administration, documentation and access to all project-related data and parameters over the entire life cycle of a project. Applicator is available: <ul style="list-style-type: none"> <li>Via the Internet: <a href="https://wapps.endress.com/applicator">https://wapps.endress.com/applicator</a></li> <li>On CD-ROM for local PC installation.</li> </ul>
W@M	Life cycle management for your plant W@M supports you with a wide range of software applications over the entire process: from planning and procurement, to the installation, commissioning and operation of the measuring devices. All the relevant device information, such as the device status, spare parts and device-specific documentation, is available for every device over the entire life cycle. The application already contains the data of your Endress+Hauser device. Endress+Hauser also takes care of maintaining and updating the data records. W@M is available: <ul style="list-style-type: none"> <li>Via the Internet: <a href="http://www.endress.com/lifecyclemanagement">www.endress.com/lifecyclemanagement</a></li> <li>On CD-ROM for local PC installation.</li> </ul>
FieldCare	FDT-based plant asset management tool from Endress+Hauser. It can configure all smart field units in your system and helps you manage them. By using the status information, it is also a simple but effective way of checking their status and condition.   For details, see Operating Instructions BA00027S and BA00059S

### 15.4 System components

Accessories	Description
Memograph M graphic display recorder	The Memograph M graphic display recorder provides information on all relevant measured variables. Measured values are recorded correctly, limit values are monitored and measuring points analyzed. The data are stored in the 256 MB internal memory and also on a SD card or USB stick.   For details, see "Technical Information" TI00133R and Operating Instructions BA00247R

## 16 Technical data

### 16.1 Application


The measuring device described in these Instructions is intended only for flow measurement of liquids with a minimum conductivity of 5 µS/cm.

Depending on the version ordered, the measuring device can also measure potentially explosive, flammable, poisonous and oxidizing media.

To ensure that the device remains in proper operating condition for its service life, use the measuring device only for media against which the process-wetted materials are adequately resistant.

### 16.2 Function and system design

Measuring principle Electromagnetic flow measurement on the basis of *Faraday's law of magnetic induction*.

Measuring system The device consists of a transmitter and a sensor.  
 Two device versions are available:  
 ■ Compact version - the transmitter and sensor form a mechanical unit.  
 ■ Remote version – the transmitter and sensor are mounted separately from one another.  
 For information on the structure of the device (→  12)

### 16.3 Input

Measured variable **Direct measured variables**  
 Volume flow (proportional to induced voltage)

**Calculated measured variables**  
 Mass flow

Measuring range Typically  $v = 0.01$  to 10 m/s (0.03 to 33 ft/s) with the specified accuracy  
 Electrical conductivity: 5 to 10 000 µS/cm/cm

*Flow characteristic values in SI units*

Nominal diameter		Recommended flow min./max. full scale value ( $v \sim 0.3/10$ m/s) [dm <sup>3</sup> /min]	Factory settings		
[mm]	[in]		Full scale value current output ( $v \sim 2.5$ m/s) [dm <sup>3</sup> /min]	Pulse value ( $\sim 2$ pulse/s) [dm <sup>3</sup> ]	Low flow cut off ( $v \sim 0.04$ m/s) [dm <sup>3</sup> /min]
25	1	9 to 300	75	0.5	1
40	1 ½	25 to 700	200	1.5	3
50	2	35 to 1 100	300	2.5	5
65	–	60 to 2 000	500	5	8
80	3	90 to 3 000	750	5	12
100	4	145 to 4 700	1 200	10	20

*Flow characteristic values in US units*


Nominal diameter		Recommended flow min./max. full scale value (v ~ 0.3/10 m/s)	Factory settings		
[in]	[mm]		Full scale value current output (v ~ 2.5 m/s)	Pulse value (~ 2 pulse/s)	Low flow cut off (v ~ 0.04 m/s)
		[gal/min]	[gal/min]	[gal]	[gal/min]
1	25	2.5 to 80	18	0.2	0.25
1 ½	40	7 to 190	50	0.5	0.75
2	50	10 to 300	75	0.5	1.25
–	65	16 to 500	130	1	2
3	80	24 to 800	200	2	2.5
4	100	40 to 1250	300	2	4

**Recommended measuring range**

"Flow limit" section (→  134)

Operable flow range Over 1000 : 1

**Input signal****External measured values**

 Various pressure transmitters and temperature measuring devices can be ordered from Endress+Hauser: see "Accessories" section (→  125)

It is recommended to read in external measured values to calculate the following measured variables:

Corrected volume flow

*HART protocol*

The measured values are written from the automation system to the measuring device via the HART protocol. The pressure transmitter must support the following protocol-specific functions:

- HART protocol
- Burst mode

**Status input**

Maximum input values	<ul style="list-style-type: none"> <li>■ DC 30 V</li> <li>■ 6 mA</li> </ul>
Response time	Adjustable: 5 to 200 ms
Input signal level	<ul style="list-style-type: none"> <li>■ Low signal: DC -3 to +5 V</li> <li>■ High signal: DC 12 to 30 V</li> </ul>
Assignable functions	<ul style="list-style-type: none"> <li>■ Off</li> <li>■ Reset totalizers 1-3 separately</li> <li>■ Reset all totalizers</li> <li>■ Flow override</li> </ul>

## 16.4 Output

Output signal

### Current output

<b>Current output</b>	Can be set as: <ul style="list-style-type: none"> <li>■ 4-20 mA NAMUR</li> <li>■ 4-20 mA US</li> <li>■ 4-20 mA HART</li> <li>■ 0-20 mA</li> </ul>
<b>Maximum output values</b>	<ul style="list-style-type: none"> <li>■ DC 24 V (no flow)</li> <li>■ 22.5 mA</li> </ul>
<b>Load</b>	0 to 700 Ω
<b>Resolution</b>	0.5 μA
<b>Damping</b>	Adjustable: 0.07 to 999 s
<b>Assignable measured variables</b>	<ul style="list-style-type: none"> <li>■ Volume flow</li> <li>■ Mass flow</li> <li>■ Flow velocity</li> <li>■ Electronic temperature</li> </ul>

### Pulse/frequency/switch output

<b>Function</b>	<ul style="list-style-type: none"> <li>■ With the order code for "Output; Input", option <b>H</b>: output 2 can be set as a pulse or frequency output</li> <li>■ With the order code for "Output; Input", option <b>I</b>: output 2 and 3 can be set as a pulse, frequency or switch output</li> </ul>
<b>Version</b>	Passive, open collector
<b>Maximum input values</b>	<ul style="list-style-type: none"> <li>■ DC 30 V</li> <li>■ 250 mA</li> </ul>
<b>Voltage drop</b>	For 25 mA: ≤ DC 2 V
<b>Pulse output</b>	
<b>Pulse width</b>	Adjustable: 0.05 to 2 000 ms
<b>Maximum pulse rate</b>	10 000 Impulse/s
<b>Pulse value</b>	Adjustable
<b>Assignable measured variables</b>	<ul style="list-style-type: none"> <li>■ Volume flow</li> <li>■ Mass flow</li> </ul>
<b>Frequency output</b>	
<b>Output frequency</b>	Adjustable: 0 to 12 500 Hz
<b>Damping</b>	Adjustable: 0 to 999 s
<b>Pulse/pause ratio</b>	1:1
<b>Assignable measured variables</b>	<ul style="list-style-type: none"> <li>■ Volume flow</li> <li>■ Mass flow</li> <li>■ Flow velocity</li> <li>■ Electronic temperature</li> </ul>
<b>Switch output</b>	
<b>Switching behavior</b>	Binary, conductive or non-conductive
<b>Switching delay</b>	Adjustable: 0 to 100 s

<b>Number of switching cycles</b>	Unlimited
<b>Assignable functions</b>	<ul style="list-style-type: none"> <li>▪ Off</li> <li>▪ On</li> <li>▪ Diagnostic behavior</li> <li>▪ Limit value:                             <ul style="list-style-type: none"> <li>- Off</li> <li>- Volume flow</li> <li>- Mass flow</li> <li>- Flow velocity</li> <li>- Totalizer 1-3</li> <li>- Electronic temperature</li> </ul> </li> <li>▪ Flow direction monitoring</li> <li>▪ Status                             <ul style="list-style-type: none"> <li>- Empty pipe detection</li> <li>- Low flow cut off</li> </ul> </li> </ul>

Signal on alarm

Depending on the interface, failure information is displayed as follows:

**Current output**

*4-20 mA*

<b>Failure mode</b>	Selectable (as per NAMUR recommendation NE 43): <ul style="list-style-type: none"> <li>▪ Minimum value: 3.6 mA</li> <li>▪ Maximum value: 22 mA</li> <li>▪ Defined value: 3.59 to 22.5 mA</li> <li>▪ Actual value</li> <li>▪ Last valid value</li> </ul>
---------------------	---

*0-20 mA*

<b>Failure mode</b>	Choose from: <ul style="list-style-type: none"> <li>▪ Maximum alarm: 22 mA</li> <li>▪ Defined value: 0 to 22.5 mA</li> </ul>
---------------------	--

*HART*

<b>Device diagnostics</b>	Device condition can be read out via HART Command 48
---------------------------	--

**Pulse/frequency/switch output**

<b>Pulse output</b>	
<b>Failure mode</b>	Choose from: <ul style="list-style-type: none"> <li>▪ Actual value</li> <li>▪ No pulses</li> </ul>
<b>Frequency output</b>	
<b>Failure mode</b>	Choose from: <ul style="list-style-type: none"> <li>▪ Actual value</li> <li>▪ Defined value: 0 to 12 500 Hz</li> <li>▪ 0 Hz</li> </ul>
<b>Switch output</b>	
<b>Failure mode</b>	Choose from: <ul style="list-style-type: none"> <li>▪ Current status</li> <li>▪ Open</li> <li>▪ Closed</li> </ul>

**Local display**

Plain text display	With information on cause and remedial measures
Backlight	Red backlighting indicates a device error.

 Status signal as per NAMUR recommendation NE 107

**Operating tool**

- Via digital communication:  
HART protocol
- Via service interface

Plain text display	With information on cause and remedial measures
--------------------	---

**Web browser**



Plain text display	With information on cause and remedial measures
--------------------	---

Low flow cut off                      The switch points for low flow cut off are user-selectable.

Galvanic isolation                    The following connections are galvanically isolated from each other:

- Inputs
- Outputs
- Power supply

Protocol-specific data                **HART**

- For information on the device description files (→  65)
- For information on the dynamic variables and measured variables (HART device variables) (→  65)

## 16.5 Power supply

Terminal assignment                 (→  32)

Supply voltage                        **Transmitter**

Order code for "Power supply"	Terminal voltage	Frequency range
Option L	AC100 to 240 V	50/ 60 Hz, ±4 Hz
	AC/DC24 V	50/ 60 Hz, ±4 Hz

Power consumption	Order code for "Output"	Maximum Power consumption
	Option H, I, J	30 VA/8 W

## Current consumption

**Transmitter**

Order code for "Power supply"	Maximum Current consumption	Maximum switch-on current
Option L: AC 100 to 240 V	145 mA	25 A (< 5 ms)
Option L: AC/DC 24 V	350 mA	27 A (< 5 ms)

## Power supply failure

- Totalizers stop at the last value measured.
- Configuration is retained in the plug-in memory (HistoROM DAT).
- Error messages (incl. total operated hours) are stored.

## Electrical connection

(→  35)

## Potential equalization

(→  38)

## Terminals

**Transmitter**

- Supply voltage cable: plug-in spring terminals for wire cross-sections 0.5 to 2.5 mm<sup>2</sup> (20 to 14 AWG)
- Signal cable: plug-in spring terminals for wire cross-sections 0.5 to 2.5 mm<sup>2</sup> (20 to 14 AWG)
- Electrode cable: spring terminals for wire cross-sections 0.5 to 2.5 mm<sup>2</sup> (20 to 14 AWG)
- Coil current cable: spring terminals for wire cross-sections 0.5 to 2.5 mm<sup>2</sup> (20 to 14 AWG)

**Sensor connection housing**

Spring terminals for wire cross-sections 0.5 to 2.5 mm<sup>2</sup> (20 to 14 AWG)

## Cable entries

**Cable entry thread**

- M20 x 1.5
- Via adapter:
  - NPT ½"
  - G ½"


**Cable gland**

- For standard cable: M20 × 1.5 with cable  $\phi$ 6 to 12 mm (0.24 to 0.47 in)
- For reinforced cable: M20 × 1.5 with cable  $\phi$ 9.5 to 16 mm (0.37 to 0.63 in)



If metal cable entries are used, use a grounding plate.

## Cable specification

(→  30)

## 16.6 Performance characteristics

## Reference operating conditions

**In accordance with DIN EN 29104**

- Fluid temperature: +28±2 °C (+82±4 °F)
- Ambient temperature range: +22±2 °C (+72±4 °F)
- Warm-up period: 30 min

**Installation**

- Inlet run > 10 × DN
- Outlet run > 5 × DN
- Sensor and transmitter grounded.
- The sensor is centered in the pipe.


Maximum measured error


**Error limits under reference operating conditions**


o.r. = of reading

**Volume flow**

±0.5 % o.r. ± 1 mm/s (0.04 in/s)

 Fluctuations in the supply voltage do not have any effect within the specified range.



 39 Maximum measured error in % o.r.

**Accuracy of outputs**

o.r. = of reading; o.f.s. = of full scale value

The outputs have the following base accuracy specifications.

*Current output*

Accuracy	Max. ±0.025 % o.f.s. or ±5 µA
----------	-------------------------------

*Pulse/frequency output*

Accuracy	Max. ±50 ppm o.r.
----------	-------------------

Repeatability

o.r. = of reading

**Volume flow**

Max. ±0.1 % o.r. ± 0.5 mm/s (0.02 in/s)

Influence of ambient temperature

o.r. = of reading; o.f.s. = of full scale value

**Current output**

Temperature coefficient	Typically ±50 ppm/°C o.r. or ±1 µA/°C
-------------------------	---------------------------------------



**Pulse/frequency output**

Temperature coefficient	Max.±0.5 ppm v.M./°C
-------------------------	----------------------


## 16.7 Installation







"Mounting requirements" (→  17)

## 16.8 Environment


Ambient temperature range	(→  19)
Storage temperature	<p>The storage temperature corresponds to the operating temperature range of the measuring transmitter and the appropriate measuring sensors.</p> <ul style="list-style-type: none"> <li>▪ Protect the measuring device against direct sunlight during storage in order to avoid unacceptably high surface temperatures.</li> <li>▪ Select a storage location where moisture cannot collect in the measuring device as fungus or bacteria infestation can damage the liner.</li> <li>▪ If protection caps or protective covers are mounted these should never be removed before installing the measuring device.</li> </ul>
Degree of protection	<p><b>Transmitter</b></p> <ul style="list-style-type: none"> <li>▪ As standard: IP66/67, type 4X enclosure</li> <li>▪ When housing is open: IP20, type 1 enclosure</li> </ul> <p><b>Sensor</b></p> <p>As standard: IP66/67, type 4X enclosure</p>
Shock resistance	Acceleration up to 2 g following IEC 60068-2-6
Vibration resistance	Acceleration up to 2 g following IEC 60068-2-6
Mechanical load	<ul style="list-style-type: none"> <li>▪ Protect the transmitter housing against mechanical effects, such as shock or impact; the use of the remote version is sometimes preferable.</li> <li>▪ Never use the transmitter housing as a ladder or climbing aid.</li> </ul>
Electromagnetic compatibility (EMC)	<ul style="list-style-type: none"> <li>▪ As per IEC/EN 61326 and NAMUR Recommendation 21 (NE 21)</li> <li>▪ Complies with emission limits for industry as per EN 55011 (Class A)</li> </ul> <p> For details refer to the Declaration of Conformity.</p>

## 16.9 Process

Medium temperature range	0 to +60 °C (+32 to +140 °F) for polyamide
Pressure-temperature ratings	<p> An overview of the pressure-temperature ratings for the process connections is provided in the "Technical Information" document</p>
Pressure tightness	Measuring tube: 0 mbar abs. (0 psi abs.) at a medium temperature of ≤ +60 °C (+140 °F)

Flow limit	<p>The diameter of the pipe and the flow rate determine the nominal diameter of the sensor. The optimum velocity of flow is between 2 to 3 m/s (6.56 to 9.84 ft/s). Also match the velocity of flow (v) to the physical properties of the fluid:</p> <ul style="list-style-type: none"> <li>■ v &lt; 2 m/s (6.56 ft/s): for abrasive fluids (e.g. potter's clay, lime milk, ore slurry)</li> <li>■ v &gt; 2 m/s (6.56 ft/s): for fluids producing buildup (e.g. wastewater sludges)</li> </ul> <p> A necessary increase in the flow velocity can be achieved by reducing the sensor nominal diameter.</p> <p> For an overview of the measuring range full scale values, see the "Measuring range" section (→  126)</p>
Pressure loss	<ul style="list-style-type: none"> <li>■ No pressure loss occurs if the sensor is installed in a pipe with the same nominal diameter.</li> <li>■ Pressure losses for configurations incorporating adapters according to DIN EN 545 (→  20)</li> </ul>
System pressure	(→  20)
Vibrations	(→  20)

## 16.10 Mechanical construction

Design, dimensions	 For the dimensions and installation lengths of the device, see the "Technical Information" document, "Mechanical construction" section
--------------------	--

Weight	<p><b>Compact version</b></p> <p>Weight data:</p> <ul style="list-style-type: none"> <li>■ Including the transmitter             <ul style="list-style-type: none"> <li>- Order code for "Housing", option M, Q: 1.3 kg (2.9 lbs)</li> <li>- Order code for "Housing", option A, R: 2.0 kg (4.4 lbs)</li> </ul> </li> <li>■ Excluding packaging material</li> </ul>
--------	---

*Weight in SI units*

EN 1092-1 (DIN 2501), JIS B2220		
DN [mm]	Weight [kg]	
	Order code for "Housing", option M, Q: Polycarbonate plastic	Order code for "Housing", option A, R: Aluminum, AlSi10Mg, coated
25	2.50	3.20
40	3.10	3.80
50	3.90	4.60
65	4.70	5.40
80	5.70	6.40
100	8.40	9.10

*Weight in US units*

ASME B16.5		
DN [in]	Weight [lbs]	
	Order code for "Housing", option M, Q: Polycarbonate plastic	Order code for "Housing", option A, R: Aluminum, AlSi10Mg, coated
1	5.51	7.06
1½	6.84	8.40
2	8.60	10.1
3	12.6	14.1
4	18.5	20.1

**Transmitter remote version***Wall-mount housing*

Depends on the material of the wall-mount housing:

- Polycarbonate plastic: 1.3 kg (2.9 lb)
- Aluminum, AlSi10Mg, coated: 2.0 kg (4.4 lb)

**Sensor remote version**

Weight data:

- Including sensor connection housing
- Excluding the connecting cable
- Excluding packaging material

*Weight in SI units*

EN 1092-1 (DIN 2501), JIS B2220	
DN [mm]	Weight [kg]
25	2.5
40	3.1
50	3.9
65	4.7
80	5.7
100	8.4

*Weight in US units*

ASME B16.5	
DN [in]	Weight [lbs]
1	5.5
1½	6.8
2	8.6
3	12.6
4	18.5

Measuring tube specification

**Pressure rating EN (DIN)**

Pressure rating PN 16								
DN		Mounting bolts			Length Centering sleeves		internal diameter Measuring tube	
[mm]	[in]		[mm]	[in]	[mm]	[in]	[mm]	[in]
25	1	4 × M12 ×	145	5.71	54	2.13	24	0.94
40	1 ½	4 × M16 ×	170	6.69	68	2.68	38	1.50
50	2	4 × M16 ×	185	7.28	82	3.23	50	1.97
65 <sup>1)</sup>	–	4 × M16 ×	200	7.87	92	3.62	60	2.36
65 <sup>2)</sup>	–	8 × M16 ×	200	7.87	– <sup>3)</sup>	–	60	2.36
80	3	8 × M16 ×	225	8.86	116	4.57	76	2.99
100	4	8 × M16 ×	260	10.24	147	5.79	97	3.82

- 1) EN (DIN) flange: 4-hole → with centering sleeves
- 2) EN (DIN) flange: 8-hole → without centering sleeves
- 3) A centering sleeve is not required. The device is centered directly via the sensor housing.

**ASME pressure rating**

Pressure rating Class 150								
DN		Mounting bolts			Length Centering sleeves		internal diameter Measuring tube	
[mm]	[in]		[mm]	[in]	[mm]	[in]	[mm]	[in]
25	1	4 × UNC ½" ×	145	5.70	– <sup>1)</sup>	–	24	0.94
40	1 ½	4 × UNC ½" ×	165	6.50	–	–	38	1.50
50	2	4 × UNC 5/8" ×	190.5	7.50	–	–	50	1.97
80	3	8 × UNC 5/8" ×	235	9.25	–	–	76	2.99
100	4	8 × UNC 5/8" ×	264	10.4	147	5.79	97	3.82

- 1) A centering sleeve is not required. The device is centered directly via the sensor housing.

**Pressure rating JIS**

Pressure rating 10K								
DN		Mounting bolts			Length Centering sleeves		internal diameter Measuring tube	
[mm]	[in]		[mm]	[in]	[mm]	[in]	[mm]	[in]
25	1	4 × M16 ×	170	6.69	54	2.13	24	0.94
40	1 ½	4 × M16 ×	170	6.69	68	2.68	38	1.50
50	2	4 × M16 ×	185	7.28	– <sup>1)</sup>	–	50	1.97
65	–	4 × M16 ×	200	7.87	–	–	60	2.36
80	3	8 × M16 ×	225	8.86	–	–	76	2.99
100	4	8 × M16 ×	260	10.24	–	–	97	3.82

- 1) A centering sleeve is not required. The device is centered directly via the sensor housing.

Materials

**Transmitter housing**


**Order code for "Housing"**

- Compact version, standard:
  - Option **A**: aluminum, AlSi10Mg, coated
  - Option **M**: polycarbonate plastic
- Compact version, inclined:
  - Option **Q**: polycarbonate plastic
  - Option **R**: aluminum, AlSi10Mg, coated
- Remote version (wall-mount housing):
  - Option **N**: polycarbonate plastic
  - Option **P**: aluminum, AlSi10Mg, coated

*Window material*

Transmitter housing material	Window material
Polycarbonate plastic	Plastic
Aluminum, AlSi10Mg, coated	Glass

**Cable entries/cable glands**



40 Possible cable entries/cable glands

- 1 Cable entry in transmitter housing, wall-mount housing or connection housing with internal thread M20 x 1.5
- 2 Cable gland M20 x 1.5
- 3 Adapter for cable entry with internal thread G 1/2" or NPT 1/2"

*Compact and remote versions and sensor connection housing*

Cable entry/cable gland	Material
Cable gland M20 x 1.5	Plastic
Remote version: cable gland M20 x 1.5 Option of reinforced connecting cable	<ul style="list-style-type: none"> <li>■ Sensor connection housing: Nickel-plated brass</li> <li>■ Transmitter wall-mount housing: Plastic</li> </ul>
Adapter for cable entry with internal thread G 1/2" or NPT 1/2"	Nickel-plated brass

**Device plug**

Electrical connection	Material
Plug M12x1	<ul style="list-style-type: none"> <li>■ Socket: Stainless steel, 1.4404 (316L)</li> <li>■ Contact housing: Polyamide</li> <li>■ Contacts: Gold-plated brass</li> </ul>

**Connecting cable for remote version**

Electrode and coil current cable

- Standard cable: PVC cable with copper shield
- Reinforced cable: PVC cable with copper shield and additional steel wire braided jacket

**Sensor housing**

Aluminum, AlSi10Mg, coated

**Sensor connection housing**

Aluminum, AlSi10Mg, coated

**Sensor cable entries**

*Order code for "Housing", option N "Remote, polycarbonate" or option P "Remote, coated aluminum"*

The various cable entries are suitable for hazardous and non-hazardous areas.

Electrical connection	Material
Cable gland M20 × 1.5	Nickel-plated brass
Thread G ½" via adapter	Nickel-plated brass
Thread NPT ½" via adapter	Nickel-plated brass

**Liner**


Polyamide

**Electrodes**

Stainless steel, 1.4435/F316L

**Process connections**

- EN 1092-1 (DIN 2501)
- ASME B16.5
- JIS B2220

 List of all available process connections

**Seals**

O-rings made from EPDM



**Accessories**

*Display protection*

Stainless steel, 1.4301 (304L)


*Ground disks*

Stainless steel ,1.4301/304

Mounting bolts	<b>Tensile strength</b> <ul style="list-style-type: none"> <li>■ Galvanized steel mounting bolts: strength category 5.6 or 5.8</li> <li>■ Stainless steel mounting bolts: strength category A2-70</li> </ul>
Fitted electrodes	2 measuring electrodes made of 1.4435 (316L)
Process connections	<ul style="list-style-type: none"> <li>■ EN 1092-1 (DIN 2501)</li> <li>■ ASME B16.5</li> <li>■ JIS B2220</li> </ul> <p> For information on the materials of the process connections (→  138)</p>

## 16.11 Operability

Local operation **Via display module**






A0020538

### Display elements

- 4-line display
- White background lighting; switches to red in event of device errors
- Format for displaying measured variables and status variables can be individually configured
- Permitted ambient temperature for the display:  $-20$  to  $+50$  °C ( $-4$  to  $+122$  °F)  
The readability of the display may be impaired at temperatures outside the temperature range.

### Operating elements


External operation via touch control; 3 optical keys: , , 

### Additional functionality

- Data backup function  
The device configuration can be saved in the display module.
- Data comparison function  
The device configuration saved in the display module can be compared to the current device configuration.
- Data transfer function  
The transmitter configuration can be transmitted to another device using the display module.

Remote operation

Via HART protocol



A0017124


41 Options for remote operation via HART protocol

- 1 Control system (e.g. PLC)
- 2 Field Communicator 475
- 3 Computer with operating tool (e.g. FieldCare, AMS Device Manager, SIMATIC PDM)
- 4 Commubox FXA195 (USB)
- 5 Field Xpert SFX350 or SFX370
- 6 VIATOR Bluetooth modem with connecting cable
- 7 Transmitter

Service interface

Service interface (CDI-RJ45)

HART



A0020481

- 1 Computer with Web browser (e.g. Internet Explorer) for accessing the integrated device Web server or with "FieldCare" operating tool with COM DTM "CDI Communication TCP/IP"
- 2 Standard Ethernet connecting cable with RJ45 plug
- 3 Service interface (CDI -RJ45) of the measuring device with access to the integrated Web server

Languages	<p>Can be operated in the following languages:</p> <ul style="list-style-type: none"> <li>■ Via local display: English, German, French, Spanish, Italian, Dutch, Portuguese, Polish, Russian, Turkish, Chinese, Japanese, Bahasa (Indonesian), Vietnamese, Czech</li> <li>■ Via "FieldCare" operating tool: English, German, French, Spanish, Italian, Chinese, Japanese</li> <li>■ Via Web browser English, German, French, Spanish, Italian, Dutch, Portuguese, Polish, Russian, Turkish, Chinese, Japanese, Bahasa (Indonesian), Vietnamese, Czech</li> </ul>
-----------	--

## 16.12 Certificates and approvals

CE mark	<p>The measuring system is in conformity with the statutory requirements of the applicable EC Directives. These are listed in the corresponding EC Declaration of Conformity along with the standards applied.</p> <p>Endress+Hauser confirms successful testing of the device by affixing to it the CE mark.</p>
C-Tick symbol	<p>The measuring system meets the EMC requirements of the "Australian Communications and Media Authority (ACMA)".</p>
Ex approval	<p>The devices are certified for use in hazardous areas and the relevant safety instructions are provided in the separate "Control Drawing" document. Reference is made to this document on the nameplate.</p>
Drinking water approval	<ul style="list-style-type: none"> <li>■ ACS</li> <li>■ KTW/W270</li> <li>■ NSF 61</li> <li>■ WRAS BS 6920</li> </ul>
Other standards and guidelines	<ul style="list-style-type: none"> <li>■ EN 60529 Degrees of protection provided by enclosures (IP code)</li> <li>■ EN 61010-1 Safety requirements for electrical equipment for measurement, control and laboratory use</li> <li>■ IEC/EN 61326 Emission in accordance with Class A requirements. Electromagnetic compatibility (EMC requirements).</li> <li>■ ANSI/ISA-61010-1 (82.02.01): 2004 Safety Requirements for Electrical Equipment for Measurement, Control and Laboratory Use - Part 1 General Requirements</li> <li>■ CAN/CSA-C22.2 No. 61010-1-04 Safety Requirements for Electrical Equipment for Measurement, Control and Laboratory Use - Part 1 General Requirements</li> <li>■ NAMUR NE 21 Electromagnetic compatibility (EMC) of industrial process and laboratory control equipment</li> <li>■ NAMUR NE 32 Data retention in the event of a power failure in field and control instruments with microprocessors</li> <li>■ NAMUR NE 43 Standardization of the signal level for the breakdown information of digital transmitters with analog output signal.</li> </ul>

- NAMUR NE 53  
Software of field devices and signal-processing devices with digital electronics
- NAMUR NE 105  
Specifications for integrating fieldbus devices in engineering tools for field devices
- NAMUR NE 107  
Self-monitoring and diagnosis of field devices
- NAMUR NE 131  
Requirements for field devices for standard applications

### 16.13 Application packages



Many different application packages are available to enhance the functionality of the device. Such packages might be needed to address safety aspects or specific application requirements.

The application packages can be ordered from Endress+Hauser either directly with the device or subsequently. Detailed information on the order code in question is available from your local Endress+Hauser sales center or on the product page of the Endress+Hauser website: [www.endress.com](http://www.endress.com).


Diagnostics functions	Package	Description
	HistoROM extended function	<p>Comprises extended functions concerning the event log and the activation of the measured value memory.</p> <p>Event log: Memory volume is extended from 20 message entries (basic version) to up to 100 entries.</p> <p>Data logging (line recorder):</p> <ul style="list-style-type: none"> <li>■ Memory capacity for up to 1000 measured values is activated.</li> <li>■ 250 measured values can be output via each of the 4 memory channels. The recording interval can be defined and configured by the user.</li> <li>■ Data logging is visualized via the local display or FieldCare.</li> </ul>

Heartbeat Technology	Package	Description
	Heartbeat Verification +Monitoring	<p><b>Heartbeat Monitoring:</b> Continuously supplies monitoring data, which are characteristic of the measuring principle, for an external condition monitoring system. This makes it possible to:</p> <ul style="list-style-type: none"> <li>■ Draw conclusions - using these data and other information - about the impact the measuring application has on the measuring performance over time.</li> <li>■ Schedule servicing in time.</li> <li>■ Monitor the product quality, e.g. gas pockets.</li> </ul> <p><b>Heartbeat Verification:</b> Makes it possible to check the device functionality on demand when the device is installed, without having to interrupt the process.</p> <ul style="list-style-type: none"> <li>■ Access via onsite operation or other operating interfaces, such as FieldCare for instance.</li> <li>■ End-to-end, traceable documentation of the verification results, including report.</li> <li>■ Makes it possible to extend calibration intervals in accordance with operator's risk assessment.</li> </ul>

### 16.14 Accessories

 Overview of accessories available for order (→  124)

## 16.15 Supplementary documentation

-  For an overview of the scope of the associated Technical Documentation, refer to the following:
- The CD-ROM provided for the device (depending on the device version, the CD-ROM might not be part of the delivery!)
  - The *W@M Device Viewer* : Enter the serial number from the nameplate ([www.endress.com/deviceviewer](http://www.endress.com/deviceviewer))
  - The *Endress+Hauser Operations App*: Enter the serial number from the nameplate or scan the 2-D matrix code (QR code) on the nameplate.

### Standard documentation

#### Brief Operating Instructions

Measuring device	Documentation code
Promag D 400	KA01112D

#### Technical Information

Measuring device	Documentation code
Promag D 400	TI01044D

### Supplementary device-dependent documentation

#### Safety Instructions

Contents	Documentation code

#### Special Documentation

Contents	Documentation code
Heartbeat Technology	SD01183D

#### Installation Instructions

Contents	Documentation code
Installation Instructions for spare part sets	 Overview of accessories available for order (→  124)

## 17 Appendix

### 17.1 Overview of the operating menu

The following tables provide an overview of the entire operating menu structure with menus and parameters. The page reference indicates where a description of the parameter can be found in the manual.




























#### 17.1.1 Main menu















<b>Main menu</b>	→	Display language	(→ 69)
		<b>Operation</b>	(→ 144)
		<b>Setup</b>	(→ 145)
		<b>Diagnostics</b>	(→ 149)
		<b>Expert</b>	(→ 153)






























#### 17.1.2 "Operation" menu
































<b>Operation</b>	→		
Display language			(→ 69)
Web server language			
Access status display			(→ 56)
Access status tooling			
Locking status			(→ 95)
		<b>Display</b>	→ (→ 80)
		Format display	(→ 81)
		Contrast display	(→ 51)
		Backlight	(→ 93)
		Display interval	(→ 93)
		<b>Totalizer handling</b>	→ (→ 100)
		Control Totalizer 1 to 3	(→ 101)
		Preset value 1 to 3	(→ 101)
		Reset all totalizers	(→ 100)



























### 17.1.3 "Setup" menu

<b>Setup</b> →	(→  69)
Device tag	(→  71)
<b>Status input</b> →	(→  71)
Assign status input	(→  71)
Active level	(→  71)
Response time status input	(→  71)
<b>Current output 1</b> →	
Assign current output	(→  73)
Mass flow unit	(→  73)
Volume flow unit	(→  73)
Current span	(→  73)
0/4 mA value	(→  73)
20 mA value	(→  73)
20 mA value	(→  73)
0/4 mA value	(→  73)
Failure mode	(→  73)
Failure current	(→  73)
<b>Pulse/frequency/switch output 1 to 2</b> →	(→  73)
Operating mode	(→  74)
Assign pulse output	(→  74)
Assign frequency output	(→  76)
Switch output function	(→  79)
Assign diagnostic behavior	(→  79)
Assign limit	(→  80)
Assign flow direction check	(→  80)
Assign status	(→  80)
Mass flow unit	(→  73)
Mass unit	(→  74)

Volume flow unit	(→  73)
Volume unit	(→  74)
Density unit	(→  73)
Unit totalizer	(→  80)
Unit totalizer	(→  80)
Unit totalizer	(→  80)
Value per pulse	(→  75)
Pulse width	(→  75)
Failure mode	(→  75)
Minimum frequency value	(→  77)
Maximum frequency value	(→  77)
Maximum frequency value	(→  77)
Minimum frequency value	(→  77)
Measuring value at minimum frequency	(→  77)
Measuring value at maximum frequency	(→  77)
Measuring value at maximum frequency	(→  77)
Measuring value at minimum frequency	(→  77)
Failure mode	(→  77)
Failure frequency	(→  77)
Switch-on value	(→  80)
Switch-off value	(→  80)
Switch-off value	(→  80)
Switch-on value	(→  80)
Switch-on delay	(→  80)
Switch-off delay	(→  80)
Failure mode	(→  80)
Invert output signal	(→  75)
<b>Display</b> →	(→  80)

Format display		(→  81)
Value 1 display		(→  81)
0% bargraph value 1		(→  81)
100% bargraph value 1		(→  81)
Value 2 display		(→  81)
Value 3 display		(→  82)
0% bargraph value 3		(→  82)
100% bargraph value 3		(→  82)
Value 4 display		(→  82)
<b>Output conditioning</b>	→	(→  83)
Display damping		(→  84)
Assign current output		(→  73)
Damping output 1		(→  84)
Measuring mode output 1		(→  85)
Assign frequency output		(→  76)
Damping output 1		(→  84)
Measuring mode output 1		(→  85)
Assign pulse output		(→  74)
Measuring mode output 1		(→  85)
Assign frequency output		(→  76)
Damping output 2		(→  84)
Measuring mode output 2		(→  85)
Assign pulse output		(→  74)
Measuring mode output 2		(→  85)
<b>Low flow cut off</b>	→	(→  85)
Assign process variable		(→  85)
On value low flow cutoff		(→  85)
Off value low flow cutoff		(→  86)
Pressure shock suppression		(→  86)

<b>Empty pipe detection</b>	→	(→  87)
Empty pipe detection		(→  87)
New adjustment		(→  87)
Progress		(→  87)
Switch point empty pipe detection		(→  87)
Response time part. filled pipe detect.		(→  87)
<b>HART input</b>	→	(→  82)
Capture mode		(→  83)
Device ID		(→  83)
Device type		(→  83)
Manufacturer ID		(→  83)
Burst command		(→  83)
Slot number		(→  83)
Timeout		(→  83)
Failure mode		(→  83)
Failure value		(→  83)
<b>Advanced setup</b>	→	(→  88)
Enter access code		(→  95)
<b>System units</b>	→	(→  89)
Volume flow unit		(→  73)
Volume unit		(→  74)
Temperature unit		(→  89)
Mass flow unit		(→  73)
Mass unit		(→  74)
Density unit		(→  73)
<b>Sensor adjustment</b>	→	(→  90)
Installation direction		(→  90)
<b>Totalizer 1 to 3</b>	→	(→  90)
Assign process variable		(→  90)
Unit totalizer		(→  80)
Totalizer operation mode		(→  90)

Failure mode		(→  90)
<b>Display</b>	→	(→  91)
Format display		(→  81)
Value 1 display		(→  81)
0% bargraph value 1		(→  81)
100% bargraph value 1		(→  81)
Decimal places 1		(→  92)
Value 2 display		(→  81)
Decimal places 2		(→  92)
Value 3 display		(→  82)
0% bargraph value 3		(→  82)
100% bargraph value 3		(→  82)
Decimal places 3		(→  92)
Value 4 display		(→  82)
Decimal places 4		(→  92)
Display language		(→  93)
Display interval		(→  93)
Display damping		(→  93)
Header		(→  93)
Header text		(→  93)
Separator		(→  93)
Backlight		(→  93)
<b>Administration</b>	→	
		<b>Define access code</b> → (→  95)
		Define access code (→  95)
		Confirm access code (→  95)
Device reset		(→  118)


### 17.1.4 "Diagnostics" menu

<b>Diagnostics</b>	→	(→  103)
Actual diagnostics		(→  115)

Previous diagnostics		(→ ⓘ 115)
Operating time from restart		(→ ⓘ 115)
Operating time		(→ ⓘ 0 )
<b>Diagnostic list</b>	→	(→ ⓘ 115)
Diagnostics 1 to 5		(→ ⓘ 115)
<b>Event logbook</b>	→	(→ ⓘ 116)
Filter options		(→ ⓘ 117)
<b>Device information</b>	→	(→ ⓘ 118)
Device tag		(→ ⓘ 119)
Serial number		(→ ⓘ 119)
Firmware version		(→ ⓘ 119)
Device name		(→ ⓘ 119)
Order code		(→ ⓘ 119)
Extended order code 1 to 3		(→ ⓘ 119)
ENP version		(→ ⓘ 119)
Device revision		(→ ⓘ 119)
Device ID		(→ ⓘ 119)
Device type		(→ ⓘ 119)
Manufacturer ID		(→ ⓘ 119)
IP address		(→ ⓘ 119)
Subnet mask		(→ ⓘ 120)
Default gateway		(→ ⓘ 120)
<b>Measured values</b>	→	
	<b>Process variables</b>	→ (→ ⓘ 98)
	Volume flow	(→ ⓘ 99)
	Mass flow	(→ ⓘ 99)
	<b>Totalizer 1 to 3</b>	→ (→ ⓘ 99)
	Totalizer value 1 to 3	(→ ⓘ 99)
	Totalizer overflow 1 to 3	(→ ⓘ 99)
	<b>Input values</b>	→ (→ ⓘ 99)
	Value status input	(→ ⓘ 99)


	<b>Output values</b> →	(→ 📄 99)
	Output current 1	(→ 📄 100)
	Measured current 1	(→ 📄 100)
	Pulse output 1	(→ 📄 100)
	Output frequency 1	(→ 📄 100)
	Switch status 1	(→ 📄 100)
	Output frequency 2	(→ 📄 100)
	Pulse output 2	(→ 📄 100)
	Switch status 2	(→ 📄 100)
	<b>Data logging <sup>1)</sup></b> →	(→ 📄 101)
	Assign channel 1 to 4	(→ 📄 102)
	Logging interval	(→ 📄 102)
	Clear logging data	(→ 📄 102)
	<b>Heartbeat <sup>2)</sup></b> →	(→ 📄 143)
	<b>Performing verification</b> →	
	Year	
	Month	
	Day	
	Hour	
	AM/PM	
	Minute	
	Verification mode	
	External device information	
	External reference voltage 1	
	External reference voltage 2	
	Start verification	
	Progress	
	Measured values	
	Output values	
	Status	

	Overall result	
	<b>Verification results</b>	→
	Date/time	
	Verification ID	
	Operating time	
	Overall result	
	Sensor	
	Sensor electronic module	
	I/O module	
	<b>Monitoring results</b>	→
	Noise	
	Coil current shot time	
	Reference electrode potential against PE	
<b>Simulation</b>		→ (→ 93)
	Assign simulation process variable	(→ 94)
	Value process variable	(→ 94)
	Simulation status input	(→ 94)
	Input signal level	(→ 94)
	Simulation current output 1	(→ 94)
	Value current output 1	(→ 94)
	Frequency simulation 1 to 2	(→ 94)
	Frequency value 1 to 2	(→ 94)
	Pulse simulation 1 to 2	(→ 94)
	Pulse value 1 to 2	(→ 94)
	Switch output simulation 1 to 2	(→ 94)
	Switch status 1 to 2	(→ 94)
	Simulation device alarm	(→ 94)
	Diagnostic event category	(→ 95)













	Simulation diagnostic event	(→  95)
--	-----------------------------	--

- 1) Order code for "Application package", option EA "Extended HistoROM", see Technical Information for device, "Application packages" section
- 2) Order code for "Application package", option EB "Heartbeat Verification + Monitoring", see the Special Documentation for the device







### 17.1.5 "Expert" menu

















The following tables provide an overview of the **Expert** menu (→  153) with its submenus and parameters. The direct access code to the parameter is given in brackets. The page reference indicates where a description of the parameter can be found in the manual.

#### Overview "Expert" menu

<b>Expert</b>	→		(→  44)
Direct access (0106)			(→  53)
Locking status (0004)			(→  98)
Access status display (0091)			(→  56)
Access status tooling (0005)			(→  96)
Enter access code (0092)			
		<b>System</b>	(→  153)
		<b>Sensor</b>	(→  155)
		<b>Input</b>	(→  158)
		<b>Output</b>	(→  158)
		<b>Communication</b>	(→  160)
		<b>Application</b>	(→  162)
		<b>Diagnostics</b>	(→  163)

#### "System" submenu


















<b>System</b>	→		
		<b>Display</b>	(→  91)
		Display language (0104)	(→  93)
		Format display (0098)	(→  81)
		Value 1 display (0107)	(→  81)
		0% bargraph value 1 (0123)	(→  81)
		100% bargraph value 1 (0125)	(→  81)









Decimal places 1 (0095)		(→  92)
Value 2 display (0108)		(→  81)
Decimal places 2 (0117)		(→  92)
Value 3 display (0110)		(→  82)
0% bargraph value 3 (0124)		(→  82)
100% bargraph value 3 (0126)		(→  82)
Decimal places 3 (0118)		(→  92)
Value 4 display (0109)		(→  82)
Decimal places 4 (0119)		(→  92)
Display interval (0096)		(→  93)
Display damping (0094)		(→  93)
Header (0097)		(→  93)
Header text (0112)		(→  93)
Separator (0101)		(→  93)
Contrast display (0105)		
Backlight (0111)		(→  93)
Access status display (0091)		
<b>Diagnostic handling</b>	→	(→  103)
Alarm delay (0651)		
	<b>Diagnostic behavior</b>	→
	Assign behavior of diagnostic no. 441 (0657)	
	Assign behavior of diagnostic no. 442 (0658)	
	Assign behavior of diagnostic no. 443 (0659)	
	Assign behavior of diagnostic no. 531 (0741)	
	Assign behavior of diagnostic no. 832 (0681)	

	Assign behavior of diagnostic no. 833 (0682)	
	Assign behavior of diagnostic no. 862 (0745)	
	Assign behavior of diagnostic no. 937 (0743)	
	Assign behavior of diagnostic no. 302 (0739)	
<b>Administration</b> →		
	<b>Define access code</b> →	(→ 95)
	Define access code (0093)	(→ 95)
	Confirm access code	(→ 95)
	Device reset (0000)	(→ 118)
	Activate SW option (0029)	
	Software option overview (0015)	

**"Sensor" submenu**

<b>Sensor</b> →		
	<b>Measured values</b> →	(→ 98)
	<b>Process variables</b> →	(→ 98)
	Volume flow (1847)	(→ 99)
	Mass flow (1838)	(→ 99)
	<b>Totalizer 1 to 3</b> →	(→ 99)
	Totalizer value 1 to 3 (0911-1 to 3)	(→ 99)
	Totalizer overflow 1 to 3 (0910-1 to 3)	(→ 99)
	<b>Input values</b> →	(→ 99)
	Value status input (1353)	(→ 99)
	<b>Output values</b> →	(→ 99)
	Output current 1 (0361)	(→ 100)

	Measured current 1 (0366)	(→  100)
	Pulse output 1 (0456)	(→  100)
	Output frequency 1 (0471)	(→  100)
	Switch status 1 (0461)	(→  100)
	Output frequency 2 (0471)	(→  100)
	Pulse output 2 (0456)	(→  100)
	Switch status 2 (0461)	(→  100)
	<b>System units</b> →	(→  89)
	Volume flow unit (0553)	(→  73)
	Volume unit (0563)	(→  74)
	Temperature unit (0557)	(→  89)
	Mass flow unit (0554)	(→  73)
	Mass unit (0574)	(→  74)
	Density unit (0555)	(→  73)
	Date/time format (2812)	
	<b>User-specific units</b> →	
	User volume text (0567)	
	User volume offset (0569)	
	User volume factor	
	User mass text	
	User mass offset (0562)	
	User mass factor (0561)	
	<b>Process parameters</b> →	(→  69)
	Filter options (6710)	
	Flow damping (6661)	
	Flow override (1839)	
	<b>Low flow cut off</b> →	
	Assign process variable (1837)	(→  85)
	On value low flow cutoff (1805)	(→  85)

	Off value low flow cutoff (1804)		(→  86)
	Pressure shock suppression (1806)		(→  86)
	<b>Empty pipe detection</b>	→	
	Empty pipe detection (1860)		(→  87)
	Switch point empty pipe detection (6562)		(→  87)
	Response time part. filled pipe detect. (1859)		(→  87)
	Empty pipe adjust value (6527)		
	Full pipe adjust value (6548)		
	Measured value EPD (6559)		
	<b>Empty pipe adjust</b>	→	
			<b>New adjustment (6560)</b> (→  87)
			<b>Progress (6571)</b> (→  87)
	<b>External compensation</b>	→	
	External value (6707)		
	External density (6630)		
	Fixed density (6623)		
	<b>Sensor adjustment</b>	→	
	Installation direction (1809)		(→  90)
	Integration time (6533)		
	Measuring period (6536)		
	<b>Process variable adjustment</b>	→	
	Volume flow offset (1841)		
	Volume flow factor (1846)		
	Mass flow offset (1831)		
	Mass flow factor (1832)		
	<b>Calibration</b>	→	


Nominal diameter (2807)
Calibration factor (6025)
Zero point (6195)

### "Input" submenu

<b>Input</b>	→	<b>Status input</b>	→	(→  99)
		Assign status input (1352)		(→  71)
		Value status input (1353)		(→  99)
		Active level (1351)		(→  71)
		Response time status input (1354)		(→  71)

### "Output" submenu














<b>Output</b>	→	<b>Current output 1</b>	→	(→  72)
		Assign current output (0359)		(→  73)
		Current span (0353)		(→  73)
		Fixed current (0365)		
		0/4 mA value (0367)		(→  73)
		20 mA value (0372)		(→  73)
		Measuring mode (0351)		
		Damping output (0363)		(→  84)
		Response time (0378)		
		Failure mode (0364)		(→  73)
		Failure current (0352)		(→  73)
		Output current 1 (0361)		(→  100)
		Measured current 1 (0366)		(→  100)
		<b>Pulse/frequency/switch output 1 to 2</b>	→	(→  73)
		Operating mode (0469)		(→  74)
		Assign pulse output (0460)		(→  74)


Value per pulse (0455)	(→  75)
Pulse width (0452)	(→  75)
Measuring mode (0351)	
Failure mode (0480)	(→  75)
Pulse output 1 to 2 (0456-1 to 2)	(→  100)
Assign frequency output (0478)	(→  76)
Minimum frequency value (0453)	(→  77)
Maximum frequency value (0454)	(→  77)
Measuring value at minimum frequency (0476)	(→  77)
Measuring value at maximum frequency (0475)	(→  77)
Measuring mode (0479)	
Damping output	(→  84)
Response time (0491)	
Failure mode (0451)	(→  77)
Failure frequency (0474)	(→  77)
Output frequency 1 (0471-1)	(→  100)
Switch output function (0481)	(→  79)
Assign diagnostic behavior (0482)	(→  79)
Assign limit (0483)	(→  80)
Switch-on value (0466)	(→  80)
Switch-off value (0464)	(→  80)
Assign flow direction check (0484)	(→  80)
Assign status (0485)	(→  80)
Switch-on delay (0467)	(→  80)
Switch-off delay (0465)	(→  80)
Failure mode (0486)	(→  80)

Switch status (0461)	(→ ⓘ 100)
Invert output signal (0470)	(→ ⓘ 75)


**"Communication" submenu**

<b>Communication</b> →		
	<b>HART input</b> →	(→ ⓘ 82)
		<b>Configuration</b> →
		Capture mode (7001) (→ ⓘ 83)
		Device ID (7007) (→ ⓘ 83)
		Device type (7008) (→ ⓘ 83)
		Manufacturer ID (7009) (→ ⓘ 83)
		Burst command (7006) (→ ⓘ 83)
		Slot number (7010) (→ ⓘ 83)
		Timeout (7005) (→ ⓘ 83)
		Failure mode (7011) (→ ⓘ 83)
		Failure value (7012) (→ ⓘ 83)
		<b>Input</b>
		Value (7003)
		Status (7004)
	<b>HART output</b> →	(→ ⓘ 65)
		<b>Configuration</b> →
		HART short tag (0220)
		Device tag (0215)
		HART address (0219)
		No. of preambles (0217)
		<b>Burst configuration</b> →
		<b>Burst configuration 1 to 3</b> →
		Burst mode 1 to 3 (0208-1 to 3) (→ ⓘ 67)
		Burst command 1 to 3 (0207-1 to 3) (→ ⓘ 67)
		Burst variable 0 (2033) (→ ⓘ 67)

	Burst variable 1 to 7 (2034-1 to 7)	(→  67)
	Burst trigger mode (2044)	(→  68)
	Burst trigger level (2043)	(→  68)
	Min. update period (2042)	(→  68)
	Max. update period (2041)	(→  68)
	<b>Information</b> →	(→  118)
	Device revision (0204)	(→  119)
	Device ID (0221)	(→  119)
	Device type (0222)	(→  119)
	Manufacturer ID (0223)	(→  119)
	HART revision (0205)	(→  65)
	HART descriptor (0212)	
	HART message (0216)	
	Hardware revision (0206)	
	Software revision (0224)	
	HART date code (0202)	
	<b>Output</b> →	(→  65)
	Assign PV (0234)	
	Primary variable (PV) (0201)	
	Assign SV (0235)	
	Secondary variable (SV) (0226)	
	Assign TV (0236)	
	Tertiary variable (TV) (0228)	
	Assign QV (0237)	
	Quaternary variable (QV) (0203)	
	<b>Web server</b> →	(→  57)














**"Application" submenu**



Unit totalizer (0915)	(→ 📖 80)
Totalizer operation mode	(→ 📖 90)
Control Totalizer 1 to 3 (0912-1 to 3)	(→ 📖 101)
Preset value 1 to 3 (0913-1 to 3)	(→ 📖 101)
Failure mode (0901)	(→ 📖 90)
<b>Concentration</b> →	
Concentration unit	
User concentration text	
User concentration factor	
User concentration offset	
A 0	
A 1 to 4	
B 1 to 3	

**"Diagnostics" submenu**

<b>Diagnostics</b> →	(→ 📖 103)
Actual diagnostics (0691)	(→ 📖 115)
Previous diagnostics (0690)	(→ 📖 115)
Operating time from restart (0653)	(→ 📖 115)
Operating time (0652)	(→ 📖 116)
<b>Diagnostic list</b> →	(→ 📖 115)
Diagnostics 1 to 5 (0692-1 to 5)	(→ 📖 115)
<b>Event logbook</b> →	(→ 📖 116)
Filter options (0705)	(→ 📖 117)
<b>Device information</b> →	(→ 📖 118)
Device tag (0011)	(→ 📖 119)
Serial number (0009)	(→ 📖 119)
Firmware version (0010)	(→ 📖 119)
Device name (0013)	(→ 📖 119)

Order code (0008)		(→  119)
Extended order code 1 to 3 (0023-1 to 3)		(→  119)
Configuration counter (0233)		
ENP version (0012)		(→  119)
IP address (7209)		(→  119)
Subnet mask (7211)		(→  120)
Default gateway (7210)		(→  120)
<b>Data logging</b> <sup>1)</sup>	→	(→  101)
Assign channel 1 to 4 (0851-1 to 4)		(→  102)
Logging interval (0856)		(→  102)
Clear logging data (0855)		(→  102)
<b>Min/max values</b>	→	
Reset min/max values (6151)		
	<b>Main electronic temperature</b>	→
	Minimum value (6547)	
	Maximum value (6545)	
	<b>Heartbeat</b> <sup>2)</sup>	→  143)
	<b>Heartbeat base settings</b>	→
	Plant operator (2754)	
	Location (2751)	
	<b>Performing verification</b>	→
	Year (2846)	
	Month (2845)	
	Day (2842)	
	Hour (2843)	
	AM/PM (2813)	
	Minute (2844)	
	Verification mode (12105)	

	External device information (12101)	
	External reference voltage 1 (12106)	
	External reference voltage 2 (12107)	
	Start verification (12127)	
	Progress (2808)	
	Status (12153)	
	Measured values (12102)	
	Output values (12103)	
	Overall result (12149)	
	<b>Verification results</b> →	
	Date/time (12142)	
	Verification ID (12141)	
	Operating time (12126)	
	Overall result (12149)	
	Sensor (12152)	
	Sensor electronic module (12151)	
	I/O module (12145)	
	<b>Monitoring results</b> →	
	Noise (12158)	
	Coil current shot time (12150)	
	Reference electrode potential against PE (12155)	
<b>Simulation</b> →		(→ 📖 93)
	Assign simulation process variable (1810)	(→ 📖 94)
	Value process variable (1811)	(→ 📖 94)
	Simulation status input (1355)	(→ 📖 94)
	Input signal level (1356)	(→ 📖 94)

Simulation current output 1 (0354)	(→ ⓘ 94)
Value current output 1 (0355)	(→ ⓘ 94)
Frequency simulation 1 to 2 (0472-1 to 2)	(→ ⓘ 94)
Frequency value 1 to 2 (0473-1 to 2)	(→ ⓘ 94)
Pulse simulation 1 to 2 (0458-1 to 2)	(→ ⓘ 94)
Pulse value 1 to 2 (0459-1 to 2)	(→ ⓘ 94)
Switch output simulation 1 to 2 (0462-1 to 2)	(→ ⓘ 94)
Switch status 1 to 2 (0463-1 to 2)	(→ ⓘ 94)
Simulation device alarm (0654)	(→ ⓘ 94)
Diagnostic event category (0738)	(→ ⓘ 95)
Simulation diagnostic event (0737)	(→ ⓘ 95)

- 1) Order code for "Application package", option EA "Extended HistoROM", see Technical Information for device, "Application packages" section  
 2) Order code for "Application package", option EB "Heartbeat Verification + Monitoring", see the Special Documentation for the device

# Index

## A

- Access authorization to parameters
  - Read access . . . . . 56
  - Write access . . . . . 56
- Access code . . . . . 56
  - Incorrect input . . . . . 56
- Adapters . . . . . 20
- Adapting the diagnostic behavior . . . . . 111
- Adapting the status signal . . . . . 111
- Ambient temperature
  - Influence . . . . . 132
- Ambient temperature range . . . . . 19
- AMS Device Manager . . . . . 63
  - Function . . . . . 63
- Application . . . . . 9, 126
- Applicator . . . . . 126
- Approvals . . . . . 141

## C

- C-Tick symbol . . . . . 141
- Cable entries
  - Technical data . . . . . 131
- Cable entry
  - Degree of protection . . . . . 40
- CE mark . . . . . 10, 141
- Certificates . . . . . 141
- Checklist
  - Post-connection check . . . . . 40
  - Post-installation check . . . . . 29
- Cleaning
  - Exterior cleaning . . . . . 121
  - Interior cleaning . . . . . 121
- Commissioning . . . . . 69
  - Advanced settings . . . . . 88
  - Configuring the measuring device . . . . . 69
- Communication-specific data . . . . . 65
- Connecting cable . . . . . 30
- Connecting the measuring device . . . . . 35
- Connection
  - see Electrical connection
- Connection examples, potential equalization . . . . . 38
- Connection preparations . . . . . 33
- Connection tools . . . . . 30
- Context menu
  - Closing . . . . . 51
  - Explanation . . . . . 51
  - Opening . . . . . 51
- Current consumption . . . . . 131

## D

- Declaration of Conformity . . . . . 10
- Define access code . . . . . 95, 96
- Degree of protection . . . . . 40, 133
- Design
  - Measuring device . . . . . 12
- Designated use . . . . . 9

- Device components . . . . . 12
- Device description files . . . . . 65
- Device documentation
  - Supplementary documentation . . . . . 8
- Device locking, status . . . . . 98
- Device name
  - Sensor . . . . . 15
  - Transmitter . . . . . 14
- Device repair . . . . . 122
- Device revision . . . . . 65
- Device type ID . . . . . 65
- Diagnostic behavior
  - Explanation . . . . . 107
  - Symbols . . . . . 107
- Diagnostic information
  - Design, description . . . . . 107, 110
  - FieldCare . . . . . 110
  - Light emitting diodes . . . . . 104
  - Local display . . . . . 106
  - Overview . . . . . 112
  - Remedial measures . . . . . 112
  - Web browser . . . . . 109
- Diagnostic list . . . . . 115
- Diagnostic message . . . . . 106
- Diagnostics
  - Symbols . . . . . 106
- DIP switch
  - see Write protection switch
- Direct access . . . . . 53
- Direct access code . . . . . 47
- Disabling write protection . . . . . 95
- Display
  - Current diagnostic event . . . . . 115
  - Previous diagnostic event . . . . . 115
  - see Local display
- Display area
  - For operational display . . . . . 46
  - In the navigation view . . . . . 48
- Display values
  - For locking status . . . . . 98
- Disposal . . . . . 122
- Document
  - Function . . . . . 6
  - Symbols used . . . . . 6
- Document function . . . . . 6
- Down pipe . . . . . 17
- Drinking water approval . . . . . 141

## E

- Electrical connection
  - Commubox FXA195 . . . . . 61, 140
  - Degree of protection . . . . . 40
  - Field Communicator . . . . . 61, 140
  - Handheld terminals . . . . . 61, 140
  - Measuring device . . . . . 30
  - Operating tools . . . . . 61, 140

Via HART protocol . . . . . 61, 140  
 Via service interface (CDI-RJ45) . . . . . 61  
 Web server . . . . . 61  
 Electromagnetic compatibility . . . . . 133  
 Enabling write protection . . . . . 95  
 Endress+Hauser services  
   Maintenance . . . . . 121  
   Repair . . . . . 122  
 Environment  
   Ambient temperature range . . . . . 19  
   Mechanical load . . . . . 133  
   Shock resistance . . . . . 133  
   Storage temperature . . . . . 133  
   Vibration resistance . . . . . 133  
 Error messages  
   see Diagnostic messages  
 Event history . . . . . 116  
 Events list . . . . . 116  
 Ex approval . . . . . 141  
 Extended order code  
   Sensor . . . . . 15  
   Transmitter . . . . . 14  
 Exterior cleaning . . . . . 121  
**F**  
 Field Communicator  
   Function . . . . . 64  
 Field Communicator 475 . . . . . 64  
 Field of application  
   Residual risks . . . . . 10  
 Field Xpert  
   Function . . . . . 62  
 Field Xpert SFX350 . . . . . 62  
 FieldCare . . . . . 62  
   Device description file . . . . . 65  
   Establishing a connection . . . . . 62  
   Function . . . . . 62  
   User interface . . . . . 63  
 Filtering the event logbook . . . . . 117  
 Firmware  
   Release date . . . . . 65  
   Version . . . . . 65  
 Firmware history . . . . . 120  
 Fitted electrodes . . . . . 139  
 Flow direction . . . . . 18  
 Flow limit . . . . . 134  
 Function check . . . . . 69  
 Function scope  
   AMS Device Manager . . . . . 63  
   Field Communicator . . . . . 64  
   Field Communicator 475 . . . . . 64  
   Field Xpert . . . . . 62  
   SIMATIC PDM . . . . . 63  
 Functions  
   see Parameter  
**G**  
 Galvanic isolation . . . . . 130

**H**  
 Hardware write protection . . . . . 96  
 HART input  
   Settings . . . . . 82  
 HART protocol  
   Device variables . . . . . 65  
   Measured variables . . . . . 65  
 Help text  
   Calling up . . . . . 54  
   Close . . . . . 54  
   Explanation . . . . . 54  
**I**  
 I/O electronics module . . . . . 12, 36  
 Identifying the measuring device . . . . . 13  
 Incoming acceptance . . . . . 13  
 Influence  
   Ambient temperature . . . . . 132  
 Information on the document . . . . . 6  
 Inlet runs . . . . . 19  
 Input . . . . . 126  
 Input mask . . . . . 49  
 Inspection  
   Installation . . . . . 29  
   Received goods . . . . . 13  
 Inspection check  
   Connection . . . . . 40  
 Installation conditions  
   Adapters . . . . . 20  
   Down pipe . . . . . 17  
   Inlet and outlet runs . . . . . 19  
   Mounting kit . . . . . 22  
   Mounting location . . . . . 17  
   Orientation . . . . . 18  
   Partially filled pipe . . . . . 18  
   System pressure . . . . . 20  
   Vibrations . . . . . 20  
 Installation dimensions . . . . . 19  
 Interior cleaning . . . . . 121  
**K**  
 Keypad lock  
   Disabling . . . . . 56  
   Enabling . . . . . 56  
**L**  
 Languages, operation options . . . . . 141  
 Line recorder . . . . . 101  
 Local display . . . . . 139  
   Editing view . . . . . 49  
   Navigation view . . . . . 47  
   see Diagnostic message  
   see In alarm condition  
   see Operational display  
 Low flow cut off . . . . . 130  
**M**  
 Main electronics module . . . . . 12  
 Maintenance tasks . . . . . 121

- Replacing seals . . . . . 121
- Manufacturer ID . . . . . 65
- Manufacturing date . . . . . 14, 15
- Materials . . . . . 137
- Maximum measured error . . . . . 132
- Measured variables
  - Calculated . . . . . 126
  - Measured . . . . . 126
  - see Process variables
- Measuring and test equipment . . . . . 121
- Measuring device
  - Configuration . . . . . 69
  - Conversion . . . . . 122
  - Design . . . . . 12
  - Disposal . . . . . 123
  - Integrating via HART protocol . . . . . 65
  - Mounting the sensor . . . . . 22
    - Arranging the mounting bolts and centering sleeves . . . . . 22
    - Mounting the ground cable/ground disks . . . . . 23
    - Mounting the seals . . . . . 23
    - Screw tightening torques . . . . . 23
  - Preparing for electrical connection . . . . . 33
  - Preparing for mounting . . . . . 21
  - Removing . . . . . 122
  - Repair . . . . . 122
  - Switch-on . . . . . 69
- Measuring principle . . . . . 126
- Measuring range . . . . . 126
- Measuring system . . . . . 126
- Measuring tube specification . . . . . 136
- Mechanical load . . . . . 133
- Media . . . . . 9
- Medium temperature range . . . . . 133
- menu
  - Diagnostics . . . . . 115
  - Operation . . . . . 98
  - Setup . . . . . 70
- Menus
  - For measuring device configuration . . . . . 69
  - For specific settings . . . . . 88
- Mounting . . . . . 17
- Mounting bolts . . . . . 139
- Mounting dimensions
  - see Installation dimensions
- Mounting kit . . . . . 22
- Mounting location . . . . . 17
- Mounting preparations . . . . . 21
- Mounting requirements
  - Installation dimensions . . . . . 19
- Mounting tools . . . . . 21
- N**
- Nameplate
  - Sensor . . . . . 15
  - Transmitter . . . . . 14
- Navigation path (navigation view) . . . . . 47
- Navigation view
  - In the submenu . . . . . 47
- In the wizard . . . . . 47
- Numeric editor . . . . . 49
- O**
- Operable flow range . . . . . 127
- Operating elements . . . . . 50, 107
- Operating keys
  - see Operating elements
- Operating menu
  - Menus, submenus . . . . . 43
  - Overview of menus with parameters . . . . . 144
  - Structure . . . . . 43
  - Submenus and user roles . . . . . 44
- Operating philosophy . . . . . 44
- Operation . . . . . 98
- Operation options . . . . . 42
- Operational display . . . . . 45
- Operational safety . . . . . 10
- Order code . . . . . 14, 15
- Orientation (vertical, horizontal) . . . . . 18
- Outlet runs . . . . . 19
- Output . . . . . 128
- Output signal . . . . . 128
- Overview
  - Operating menu . . . . . 144
- P**
- Packaging disposal . . . . . 17
- Parameter
  - Changing . . . . . 55
  - Enter a value . . . . . 55
- Parameter settings
  - Burst configuration 1 to 3 (submenu) . . . . . 66
  - Configuration (submenu) . . . . . 82
  - Current output 1 to 2 (wizard) . . . . . 72
  - Data logging (submenu) . . . . . 101
  - Device information (submenu) . . . . . 118
  - Diagnostics (menu) . . . . . 115
  - Display (submenu) . . . . . 91
  - Display (wizard) . . . . . 80
  - Empty pipe detection (wizard) . . . . . 87
  - For the status input . . . . . 71
  - Input values (submenu) . . . . . 99
  - Low flow cut off (wizard) . . . . . 85
  - Operation (submenu) . . . . . 100
  - Output conditioning (wizard) . . . . . 83
  - Output values (submenu) . . . . . 99
  - Process variables (submenu) . . . . . 98
  - Pulse/frequency/switch output 1 to 2 (wizard)
    - 73, . . . . . 75, . . . . . 77
  - Sensor adjustment (submenu) . . . . . 90
  - Setup (menu) . . . . . 70
  - Simulation (submenu) . . . . . 93
  - Status input (submenu) . . . . . 71
  - System units (submenu) . . . . . 89
  - Totalizer (submenu) . . . . . 99
  - Totalizer 1 to 3 (submenu) . . . . . 90
  - Web server (submenu) . . . . . 60
- Partially filled pipe . . . . . 18

- Performance characteristics . . . . . 131
- Post-connection check (checklist) . . . . . 40
- Post-installation check . . . . . 69
- Post-installation check (checklist) . . . . . 29
- Potential equalization . . . . . 38, 131
- Power consumption . . . . . 130
- Power supply failure . . . . . 131
- Pressure loss . . . . . 134
- Pressure tightness . . . . . 133
- Pressure-temperature ratings . . . . . 133
- Process conditions
  - Flow limit . . . . . 134
  - Medium temperature . . . . . 133
  - Pressure loss . . . . . 134
  - Pressure tightness . . . . . 133
- Process connections . . . . . 139
- Product safety . . . . . 10
- Protecting parameter settings . . . . . 95
- R**
- Read access . . . . . 56
- Reading measured values . . . . . 98
- Recalibration . . . . . 121
- Reference operating conditions . . . . . 131
- Registered trademarks . . . . . 8
- Remedial measures
  - Calling up . . . . . 108
  - Closing . . . . . 108
- Remote operation . . . . . 140
- Remote version
  - Connecting the signal cables . . . . . 36
- Repair . . . . . 122
  - Notes . . . . . 122
- Repair of a device . . . . . 122
- Repeatability . . . . . 132
- Replacement
  - Device components . . . . . 122
- Replacing seals . . . . . 121
- Requirements for personnel . . . . . 9
- Returning devices . . . . . 122
- S**
- Safety . . . . . 9
- Screw tightening torques . . . . . 23
- Sensor
  - Mounting . . . . . 22
- Serial number . . . . . 14, 15
- Service interface (CDI-RJ45) . . . . . 140
- Setting the operating language . . . . . 69
- Settings
  - Adapting the measuring device to the process conditions . . . . . 100
  - Advanced display configurations . . . . . 91
  - Current output . . . . . 72
  - Device reset . . . . . 118
  - Device tag . . . . . 70
  - Empty pipe detection (EPD) . . . . . 87
  - HART input . . . . . 82
  - Local display . . . . . 80
  - Low flow cut off . . . . . 85
  - Operating language . . . . . 69
  - Output conditioning . . . . . 83
  - Pulse/frequency/switch output . . . . . 73
  - Resetting the totalizer . . . . . 100
  - Sensor adjustment . . . . . 90
  - Simulation . . . . . 93
  - Status input . . . . . 71
  - System units . . . . . 89
  - Totalizer . . . . . 90
  - Totalizer reset . . . . . 100
- Shock resistance . . . . . 133
- Showing data logging . . . . . 101
- Signal on alarm . . . . . 129
- SIMATIC PDM . . . . . 63
  - Function . . . . . 63
- Software release . . . . . 65
- Spare part . . . . . 122
- Spare parts . . . . . 122
- Special connection instructions . . . . . 40
- Standards and guidelines . . . . . 141
- Status area
  - For operational display . . . . . 45
  - In the navigation view . . . . . 47
- Status signals . . . . . 106, 109
- Storage conditions . . . . . 16
- Storage temperature . . . . . 16
- Storage temperature range . . . . . 133
- Structure
  - Operating menu . . . . . 43
- submenu
  - Advanced setup . . . . . 88
  - Burst configuration 1 to 3 . . . . . 66
  - Configuration . . . . . 82
  - Data logging . . . . . 101
  - Device information . . . . . 118
  - Display . . . . . 91
  - Input values . . . . . 99
  - Operation . . . . . 100
  - Output values . . . . . 99
  - Process variables . . . . . 98
  - Sensor adjustment . . . . . 90
  - Simulation . . . . . 93
  - Status input . . . . . 71
  - System units . . . . . 89
  - Totalizer . . . . . 99
  - Totalizer 1 to 3 . . . . . 90
  - Web server . . . . . 60
- Submenu
  - Define access code . . . . . 95
  - Events list . . . . . 116
  - Overview . . . . . 44
  - Process variables . . . . . 98
- Supplementary documentation . . . . . 143
- Supply voltage . . . . . 130
- Symbols
  - For communication . . . . . 45
  - For correction . . . . . 49
  - For diagnostic behavior . . . . . 45

- For locking . . . . . 45
  - For measured variable . . . . . 46
  - For measurement channel number . . . . . 46
  - For menus . . . . . 48
  - For parameters . . . . . 48
  - For status signal . . . . . 45
  - For submenu . . . . . 48
  - For wizard . . . . . 48
  - In the status area of the local display . . . . . 45
  - In the text and numeric editor . . . . . 49
  - System design
    - Measuring system . . . . . 126
    - see Measuring device design
  - System integration . . . . . 65
  - System pressure . . . . . 20
- T**
- Technical data, overview . . . . . 126
  - Temperature range
    - Ambient temperature range for display . . . . . 139
    - Storage temperature . . . . . 16
  - Terminal assignment . . . . . 32, 36
  - Terminals . . . . . 131
  - Text editor . . . . . 49
  - Tool tip
    - see Help text
  - Tools
    - Electrical connection . . . . . 30
    - For mounting . . . . . 21
    - Transport . . . . . 16
  - Transmitter
    - Connecting the signal cables . . . . . 36
    - Turning the display module . . . . . 28
    - Turning the housing . . . . . 26
  - Transporting the measuring device . . . . . 16
  - Troubleshooting
    - General . . . . . 103
  - Turning the display module . . . . . 28
  - Turning the electronics housing
    - see Turning the transmitter housing
  - Turning the transmitter housing . . . . . 26
- U**
- Use of the measuring device
    - Borderline cases . . . . . 9
    - Incorrect use . . . . . 9
    - see Designated use
  - User roles . . . . . 44
- V**
- Version data for the device . . . . . 65
  - Vibration resistance . . . . . 133
  - Vibrations . . . . . 20
- W**
- W@M . . . . . 121, 122
  - W@M Device Viewer . . . . . 13, 122
  - Weight
    - Compact version . . . . . 134
    - Sensor remote version . . . . . 135
  - Transport (notes) . . . . . 16
  - wizard
    - Current output 1 to 2 . . . . . 72
    - Define access code . . . . . 95
    - Display . . . . . 80
    - Empty pipe detection . . . . . 87
    - Low flow cut off . . . . . 85
    - Output conditioning . . . . . 83
    - Pulse/frequency/switch output 1 to 2 . . . . . 73, 75, 77
  - Workplace safety . . . . . 10
  - Write access . . . . . 56
  - Write protection
    - Via access code . . . . . 95
    - Via write protection switch . . . . . 96
  - Write protection switch . . . . . 96

[www.addresses.endress.com](http://www.addresses.endress.com)

---